




Model

11996BQ65ES

Revision 2 Updated April 02, 2024(wr)

Parts Manual



362 Industrial Park Drive
Lawrenceville, GA 30046
+1 (770-963) 7369
www.atlatt.com

Atlanta Attachment Company, Inc.

Confidential and Proprietary Information

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.

All materials contained herein are additionally protected by United States Copyright law and may not be used, disclosed, reproduced, distributed, published, or sold without the express written consent of Atlanta Attachment Company, which consent may be withheld in Atlanta Attachment Company's sole discretion. You may not alter or remove any copyright, trademark, or other notice from copies of these materials.

IMPORTANT

It is important to read and understand the information contained within this manual before attempting to operate the machine. Atlanta Attachment Co., Inc. shall not be held liable for damage resulting from misuse of the information presented within and reserves the right to change the information contained within, without prior notification.

Patents & Patents Pending

The sale of this product does not sell or otherwise transfer any license or other rights under any U.S. Patent or other corresponding foreign patent.

This equipment is manufactured under one or more of the following patents:

4,280,421 • 4,432,294 • 4,466,367 • 4,644,883 • 5,134,947 • 5,159,889 • 5,203,270 •
5,373,798 • 5,437,238 • 5,522,332 • 5,524,563 • 5,562,060 • 5,634,418 • 5,647,293
•5,657,711 • 5,743,202 • 5,865,135 • 5,899,159 • 5,915,319 • 5,918,560 • 5,924,376
•5,979,345 • 6,035,794 • 6,055,921 • 6,202,579 • 6,279,869 • 6,295,481 • 6,494,225
•6,523,488 • 6,574,815 • 6,802,271 • 6,834,603 • 6,968,794 • 6,994,043 • 7,543,364
•7,574,788 • 7,647,876 • 7,735,439

Foreign Patents: 9-520,472 • 0,537,323 • 92,905,522.6 • 96,936,922.2 • 2,076,379 •
2,084,055

Other U.S. and Foreign Patents Pending.

Contents

| | |
|--|-----------|
| CONFIDENTIAL AND PROPRIETARY INFORMATION | 0 |
| CONTENTS..... | 1 |
| SAFETY INSTRUCTION | 0 |
| Important Notices..... | 3 |
| Maintenance | 5 |
| 1. INSTALLATION | 8 |
| PARTS AND COMPONENTS | 8 |
| TECHNICAL DATA..... | 9 |
| FOOTPRINT | 9 |
| MACHINE IDENTIFICATION LABEL | 9 |
| 2. SERVICE..... | 10 |
| LOCKOUT/TAGOUT PROGRAM..... | 10 |
| NOTES: | 12 |
| 3. ASSEMBLY DRAWINGS & PARTS LISTS..... | 13 |
| 11996BQ65ES AUTO COLLAR & BAND, DC1500, SBUS..... | 14 |
| 1996011 THREE ROTARY THREAD BRAKE ASSEMBLY | 15 |
| 4003-500B THREAD BRAKE SENSOR ASSEMBLY | 16 |
| 1996A-02Q65 SEWING HEAD DETAIL..... | 17 |
| 1975-400Y CUTTER & FOOT LIFT COMP. | 18 |
| 1975-400MG CUTTER ASSEMBLY | 20 |
| 1966GD CONSOLE, SBUS, EFKA..... | 21 |
| 1996-10B TRANSFER SUB-ASSEMBLY | 23 |
| 1996-15A INDEXING TABLE | 25 |
| 26238 Leg Sub-Assembly | 27 |
| 1996-12 STACKER DOOR ASSEMBLY | 28 |
| 1996-08B FEED ASSEMBLY | 30 |
| 1996-06 CONVEYOR MOUNT ASSEMBLY..... | 32 |
| 1996-05 TOP CONVEYOR ASSEMBLY..... | 35 |
| 1996-07 Front Conveyor Assembly | 37 |
| 97-1700A TOUCH SCREEN ASSEMBLY..... | 39 |
| 1278-6010 Start/Stop Button Assembly..... | 40 |
| 1996005 CONTROL BOX, PNEUMATIC/ELECTRIC | 41 |
| 1996007 PNEUMATIC CONTROL PANEL..... | 43 |
| 1996-01D TABLE STAND AND MOTOR..... | 45 |
| 0411-1300 WASTE CONTAINER ASSEMBLY..... | 47 |
| 1996-17 BAND STOP SUB-ASSEMBLY..... | 48 |
| 1996-16 ROLL MOUNT SUB-ASSEMBLY | 49 |
| 1996-11B FOLD BAND SUB-ASSEMBLY..... | 50 |
| 3800P-002 FOOT SWITCH ASSEMBLY..... | 52 |
| 1996ES-WD WIRING DIAGRAM, POWER, SERIAL BUS | 53 |
| 1996B-PD PNEUMATIC DIAGRAM | 54 |

Safety Instruction



This part of the Instruction Material is provided for the safe use of your equipment. It contains important information to help work safely with the unit and describes the dangers inherent in machinery. Some of these dangers are obvious, while others are less evident.

Mandatory Information

All persons operating and/or working on the Workstation should read and understand all parts of the Safety Instructions. This applies, in particular, for persons who only operate and/or work on the unit occasionally (e.g. for maintenance and repair). Persons who have difficulty reading must receive particularly thorough instruction.

Scope of the Instruction Material

The Instruction Material comprises:

- Safety information
- Operator Instructions
- Electrical and Pneumatic diagrams

And may also include.

- A list of recommended spare parts
- Instruction Manual(s) for components made by other manufacturers
- The layout and installation diagram containing information for installation

Intended Use

Our machines are designed and built in line with the state of the art and the accepted safety rules. However, all machines may endanger the life and limb of their users and/or third parties and be damaged or cause damage to other property, particularly if they are operated incorrectly or used for purposes other than those specified in the Instruction Manual.

Exclusion of Misuse



Non-conforming uses include, for example, using the equipment for something other than it was designed for, as well as operation without duly installed safety equipment. The risk rests exclusively with the end user.

Conforming use of the machine includes compliance with the technical data, information, and regulations in all parts of the complete Instruction Material, as well as compliance with the maintenance regulations. All local safety and

accident prevention regulations must also be observed.

Liability

The machine should only be operated when in perfect working order, with due regard for safety and the potential dangers, as well as in accordance with the Instruction Material. Faults and malfunctions capable of impairing safety should be remedied immediately. We cannot accept any liability for personal injury or property damage due to operator errors or non-compliance with the safety instructions contained in this booklet. The risk rests exclusively with the end user.

The Instruction Material should always be kept near the machine so that it is accessible to all concerned.

The local, general, statutory, and other binding regulations on accident prevention and environmental protection must also be observed in addition to the Instruction Material. The operating staff must be instructed accordingly. This obligation also includes the handling of dangerous substances and provision/use of personal protective equipment.

Safety

The Instruction Material should be supplemented by instructions, including supervisory and notification duties with due regard for special operational features, such as the organization of work, work sequences, the personnel deployed, etc.

The personnel's awareness of the dangers and compliance with the safety regulations should be checked at irregular intervals.

Choice and Qualification of Personnel

Ensure that work on the machine is only carried out by reliable persons who have been appropriately trained for such work - either within the company, by our field staff or at our office - and who have not only been duly appointed and authorized but are also fully familiar with the local regulations. Work on the machine should only be carried out by skilled personnel, under the management and supervision of a duly qualified engineer.

This not only applies when the machine is used for production, but also for special work associated with its operation (start-up and maintenance), especially when it concerns work on the hydraulic or electrical systems, as well as on the software/serial bus system.

Training

Everyone working on or with the machine should be duly trained and informed with regard to correct use of the safety equipment, the foreseeable dangers which may arise during operation of the machine and the safety precautions to be taken. In addition, the personnel should be instructed to check all safety mechanisms at regular intervals.

Responsibilities

Clearly define exactly who is responsible for operating, setting-up, servicing and repairing the machine. Define the responsibilities of the machine operator and authorize him to refuse any instructions by third parties if they run contrary to the machine's safety. This applies in particular for the operators of machines linked to other equipment. Persons receiving training of any kind may only work on or with the machine under the constant supervision of an experienced operator. Note the minimum age limits permitted by law.

A Word to the Operator

The greatest danger inherent in our machines:
is that of fingers, hands or loose clothing being drawn into a machine by live, coasting, or rotating tools or assemblies or of being cut by sharp tools or burned by hot elements.

Always be conscious of these dangers!

Safety Equipment on the Machines



All machines are delivered with safety equipment, which shall not be removed or bypassed during operation.

The correct functioning of safety equipment on machines and systems should be checked every day and before every new shift starts, after maintenance and repair work, when starting up for the first time and when restarting (e.g. after prolonged shutdowns).

If safety equipment has to be dismantled for setting-up, maintenance or repair work, such safety equipment shall be replaced and checked immediately upon completing the maintenance or repair work.

All protective mechanisms shall be fitted and fully operational whenever the machine is at a standstill or if it has been shut down for a longer period of time.

Safety

Damage

If any changes capable of impairing safety are observed in the machine or its mode of operation, such as malfunctions, faults or changes in the machine or tools, appropriate steps must be taken immediately, the machine switched off and a proper lockout tagout procedure followed. The machine should be examined for obvious damage and defects at least once per shift. Damage found shall be immediately remedied by a duly authorized person before resuming operation of machine.

The machine should only be operated when in perfect working order and when all protective mechanisms and safety equipment, such as detachable protective mechanisms, emergency STOP systems, etc. are in place and operational.

Faults or Errors

The machine must be switched off and all moving or rotating parts allowed to come to a standstill and secured against accidental restart before starting to remedy any faults or errors.


Signs on the Machine

Safety and danger signs on the machine should be observed and checked at regular intervals to ensure that they are complete and undamaged. They should be clearly visible and legible at all times.

Clothing, Jewelry, Protective Equipment

Long loose hair, loose-fitting clothes, gloves, and jewelry, including rings, should be avoided in order to avoid injuries due to being caught, drawn in and wound up inside the machine.

Protective Eyewear



Protective eyewear that has been tested by the local authorities should be worn whenever there is a possibility of loose or flying objects or particles such as when cleaning the machine with compressed air.

Tools

Always count the number of tools in your possession before starting work on the machine. This will allow you to check that no tools have been left behind inside the machine. Never leave a tool in the machine while working.

Oils, Lubricants, Chemicals

Note the applicable safety regulations for the product used.

No Smoking, Fire, Explosion Hazard

Smoking and open flame (e.g. welding work) should be prohibited in the production area due to the risk of fire and explosions.

Workplace

A clear working area without any obstructions whatsoever is essential for safe operation of the machine. The floor should be level and clean, without any waste.

The workplace should be well lit, either by the general lighting or by local lights.

Emergency STOP

The emergency STOP buttons bring all machine movements to a standstill. Make sure you know exactly where they are located and how they work. Try them out. Always ensure easy access to the nearest emergency STOP button while working on the machine.

First Aid

1. Keep calm even when injured.
2. Clear the operator from the danger zone. The decision of what to do and whether to seek additional assistance rests entirely with you, particularly if someone has been trapped.
3. Give First Aid. Special courses are offered by such organizations as the employers' liability insurance association. Your colleagues should be able to rely on you and vice versa.
4. Call an ambulance. Do you know the telephone numbers for the ambulance service, police and fire service?

Important Notices

Reporting and Fighting Fires

Read the instructions posted in the factory with regard to reporting fires and the emergency exits. Make sure you know exactly where the fire extinguishers and sprinkler systems are located and how they are operated. Pass on the corresponding information to the firemen when they arrive. Ensure there are enough signs to avoid fire hazards.

The following fire extinguishers may be used:

- Dry powder extinguishers, ABC fire-extinguishing powder.
- Carbon dioxide fire extinguishers to DIN 14461 for electronic components. Great care must be exercised when using carbon dioxide fire extinguishers in confined, badly ventilated rooms (see DIN 14406 and 14270).

Isolate the machine from the power supply if a fire breaks out. Do not use water on burning electrical parts until it is absolutely certain that they have been completely disconnected from the power supply. Burning oils, lubricants, plastics, and coatings on the machine can give off gases and vapors that may be harmful to your health.

A qualified person should be consulted to repair the damage after a fire.

Electrical Power Supply



Before undertaking any maintenance or repair work on the machine, switch off the electrical power to the machine at the main source and secure it with a padlock so that it cannot be switched on again without authorization.

In practice, this may mean that the technician, electrician, and operator all attach their own padlock to the master switch simultaneously so that they can carry out their work safely. Locking extension plates should be available for multiple locks if required. The primary purpose for a lockout/tagout

procedure is to protect workers from injury caused by unexpected energizing or start-up of equipment.

Energy sources (electrical/pneumatic/hydraulic, etc.) for the equipment shall be turned off or disconnected and the switches locked or labeled with a warning tag. It is the responsibility of the employer to establish control procedures. Follow lockout/tagout procedures before, setup and/or any service or maintenance work is performed, including lubrication, cleaning, or clearance of jams.

Safety

Caution: The machine is still not completely de-energized even when the master switch is off.

- Electricity - The machine is always isolated from the electrical power supply whenever the master switch has been switched off. However, this does not apply for the power supply in the control cabinet, nor for equipment that does not draw its power via the master switch.
- Pneumatic / hydraulic energy - Almost all our machines carry compressed air. In addition to switching off the master switch, the air supply must also be disconnected, and the machine checked to ensure it is depressurized before starting any work on the machine; otherwise the machine may execute uncontrolled movements.
- Kinetic energy - Note that some motors or spindles, for example, may continue to run or coast run on after being switched off.
- Potential energy - Individual assemblies may need to be secured if necessary for repair work.

Delivery of the Machine/Packaging

Note any markings on the packaging, such as weights, lifting points and special information. Avoid temperature fluctuations. Condensation may damage the machine.

Transport Damage

The packaging and machine must immediately be examined for signs of damage in transit. Such damage must be reported to the shipper/transporter within the applicable time limits. Contact Atlanta Attachment Company and/or your transport insurer immediately, if signs of damage are visible. Never operate a damaged machine.

Interim Storage

If the machine has to be stored temporarily, it must be oiled or greased and stored in a dry place where it is protected from the weather in order to avoid damage. A corrosion-inhibiting coating should be applied if the machine has to be stored for a longer period of time and additional precautions taken to avoid corrosion.

Transporting the Machine

Disconnect the machine from all external connections and secure any loose assemblies or parts. Never step under a suspended load. When transporting the machine or assemblies in a crate, ensure that the ropes or arms of a forklift truck are positioned as close to the edge of the crate as possible. The center of gravity is not necessarily in the middle of the crate. Note the accident prevention regulations, safety instructions and local regulations governing transport of the machine and its assemblies.

Only use suitable transport vehicles, hoisting gear and load suspension devices that are in perfect working order and of adequate carrying capacity. Transport should only be entrusted to duly qualified personnel.

Never allow the straps to rest against the machine enclosure and never push or pull sensitive parts of the machine. Ensure that the load is always properly secured. Before or immediately after loading the machine, secure it properly and affix corresponding warnings.

All transport guards and lifting devices must be removed before the machine is started up again. Any parts that are to be removed for transport must be carefully refitted and secured before the machine is started up again.

Safety

Workplace Environment

Our machines are designed for use in enclosed rooms: Permissible ambient temperature approx. 5 - 40 °C (40 - 104 °F). Malfunctions of the control systems and uncontrolled machine movements may occur at temperatures outside this range.

Protect against climatic influences, such as electrostatic charges, lightning strikes, hail, storm damage, high humidity, salinity of the air in coastal regions.

Protect against influences from the surroundings: no structure-borne vibrations, no grinding dust, or chemical vapors.

Protect against unauthorized access.

Ensure that the machine and accessories are set up in a stable position.

Ensure easy access for operation and maintenance (Instruction Manual and layout diagram); also verify that the floor is strong enough to carry the weight of the machine.

Local Regulations

Particular attention must be paid to local and statutory regulations, etc. when installing machines and the plant (e.g. with regard to the specified escape routes). Note the safety zones in relation to adjacent machines.

Maintenance

General Safety Instructions

The machine shall be switched off, come to a standstill, and be secured so that it cannot be switched on again inadvertently before starting any maintenance work whatsoever. Use proper lockout/tagout procedures to secure the machine against inadvertent startup.

Remove any oil, grease, dirt and waste from the machine, particularly from the connections and screws, when starting the maintenance and/or repair work. Do not use any corrosive-cleaning agents. Use lint-free rags.

Retighten all screw connections that have to be loosened for the maintenance and repair work. Any safety mechanisms that have to be dismantled for setting-up, maintenance or repair purposes must be refitted and checked immediately after completing the work.

Maintenance, Care, Adjustment

The activities and intervals specified in the Instruction Manual for carrying out adjustments, maintenance and inspections must be observed, and parts replaced as specified.

All hydraulic and pneumatic lines should be examined for leaks, loose connections, rubbing and damage whenever the machine is serviced. Any defects found must be remedied immediately.

Waste, Disassembly, Disposal

Waste products should be cleared from the machine as soon as possible as not to create a fire hazard.

Ensure that fuels and operating lubricants, as well as replacement parts are disposed of in a safe and ecologically acceptable manner. Note the local regulations on pollution control.

When scrapping (disassembling) the machine and its assemblies, ensure that these materials are disposed of safely. Either commission a specialist company familiar with the local regulations or note the local regulations when disposing of these materials yourself. Materials should be sorted properly.

Repair

Replacement Parts

We cannot accept any liability whatsoever for damage due to the use of parts made by other manufacturers or due to unqualified repair or modification of the machine.

Safety

Repair, Electrical

The power supply must be switched off (master switch off) and secured so that it cannot be switched on again inadvertently before starting any work on live parts.

Those parts of the machine and plant on which inspection, maintenance or repair work is to be carried out must be isolated from the power supply, if specified. The isolated parts must first be checked to determine that they are truly de-energized before being grounded and short-circuited. Adjacent live parts must also be isolated.

The protective measures implemented (e.g. grounding resistance) must be tested before restarting the machine after all assembly or repair work on electric parts.

Signal generators (limit switches) and other electrical parts on the safety mechanisms must not be removed or bypassed. Only use original fuses or circuit overloads with the specified current rating. The machine must be switched off immediately if a fault develops in the electrical power supply.

The electrical equipment of our machines must be checked at regular intervals and any defects found must be remedied immediately.

If it is necessary to carry out work on live parts, a second person should be on hand to operate the emergency OFF switch or master switch with voltage release in the event of an emergency.

The working area should be cordoned off and marked by a warning sign. Only use electrically insulated tools.

Ventilation/Hazardous Gases

It is the end users responsibility to ensure adequate ventilation is provided to exhaust any and all noxious or hazardous gases that may be present in the working environment.

Hydraulic and Pneumatic Systems

Work on hydraulic or pneumatic equipment shall only be carried out by persons with training, knowledge, and experience of hydraulic systems. Pressure lines shall be depressurized before starting any repair work.

General Liability

Liability for machine damage and personal injury is extinguished completely if any unauthorized conversions or modifications are undertaken. The machine must not be modified, enlarged or converted in any way capable of affecting safety without the manufacturer's prior approval.

Starting Machine Movements

Read the Instruction Manual carefully to establish which keys and functions start machine movements.

A Word to the End User

The end user has sole responsibility to enforce the use of safety procedures and guards on the machine. Any other safety devices or procedures due to local regulations should be retrofitted in accordance to these regulations and/or the EC Directive on the safety of machines.

Operator's position must always be readily accessible. Escape routes must always be kept clear and safety areas should be identified.

Safety Precautions

Safety should be a constant concern for everyone. Always be careful when working with this equipment. While normal safety precautions were taken in the design and manufacture of this equipment, there are some potential safety hazards.

Everyone involved with the operation and maintenance of this equipment should read and follow the instructions in this manual. Operate the equipment only as stated in this manual. Incorrect use could cause damage to the equipment or personal injury.

Safety

It is the owner's responsibility to make certain that the operator reads and understands this manual before operating this equipment. It is also the owner's responsibility to make certain that the operator is a qualified and physically able individual, properly trained in the operation of this equipment.

Specific safety warning decals are located on the equipment near the immediate areas of potential hazards. These decals should not be removed or obliterated. Replace them if they become non-readable.


- ALWAYS keep safety shields and covers in place, except for servicing.
- ALWAYS operate equipment in daylight or with adequate working lights.
- Follow daily and weekly checklists, making sure hoses are tightly secured and bolts are tightened.
- ALWAYS watch and avoid holes or deep depressions.

ALWAYS wear adequate eye protection when servicing the hydraulic system and battery.

- NEVER operate a poorly maintained machine.
- NEVER allow persons to operate this machine without proper instruction.
- NEVER put hands or feet under any part of the machine while it is running.
- NEVER attempt to make any adjustments or repairs to the machine while running. Repairs or maintenance should be performed by trained personnel only.
- NEVER work under the machine unless it is safely supported with stands, blocks or a hoist and blocks.
- NEVER touch hot parts of machine.

1. INSTALLATION

NOTE: It is important that the machine technician read the Installation Manual and is familiar with all the functions and safety concerns of the unit before Installing and operating.



Parts and Components

| Part Number | Description | Part Number | Description |
|-------------|--|-------------|--------------------------------------|
| 1 | 1996-01D Table Stand Motor | 17 | WWFS1/4 Washer, Flat |
| 2 | 1996005 Electric Box Assy | 18 | 1996B-PD Diagram, Pneumatic |
| 3 | 97-1700A Control Box Assy | 19 | SSHC01192 Screw, Hex, 1/4-20 x 3 |
| 4 | 1996-05 Top Conveyor Assy | 20 | 1996ES-WD Diagram, wiring |
| 5 | 1996-06 Conveyor MT Kit | 21 | SSTS98040 Screw, Truss, 10-32 x 5/8 |
| 6 | 1996-08B Feed Assy | 22 | NNK10-32 Kep nut |
| 7 | 1996-12 Stacker Door | 23 | 1996-038 Plate, SLK Loop |
| 8 | 1996010 Cable Package | 24 | 1996-300A Guillotine Assy |
| 9 | 1996-15A Indexing Table | 25 | SSHC01160 Screw, Hex, 1/4-20 x 2-1/2 |
| 10 | 1996-Label Label Package | 26 | NNK1/4-20 Kep nut |
| 11 | SSFP01048 Screw, Phillips, 1/4-20 x 3/4 | 27 | 1996-23 Stripper Fingers |
| 12 | SSPS95128 screw, Pan Slotted, 10-24 x 2 | 28 | 1996007 Panel, Pneu Control |
| 13 | WWFS10 Washer | 29 | FFSM312LVQ Photocell |
| 14 | SSZS93032 Screw, sheet metal 10-16 x 1/2 | 30 | 265155A Holder, eye |
| 15 | 1996-10B Transfer Sub-assy | 31 | 1740BB-43 Rod, straight |
| 16 | WWL1/4 Washer, 1/4 lock | 32 | 28201 Rod, connector |

Operation Instructions

Technical Data

| | |
|-----------------------------------|--------------|
| Voltage (v/ph/hz) | 220v 1ph |
| Current (amps) | 5 |
| Air pressure (psi) | 90 |
| Air consumption (cfm) | 10 |
| Shipping weight (lbs) | 1100 |
| Shipping dimensions (w/l/h, inch) | 96 x 55 x 60 |

Production: Approximately 487 pieces per hour. Estimate based on cycle time, material changeover, and machine program time.

Cycle time: Approx. 17" (43.2 cm) strip - .066 min 30" (76.2 cm) strip .086 min

Changeover time: Approx. 30 seconds, by the operator

Capacity: Width minimum 2" (5.08 cm) to 8" (20.32 cm) roll or 4"(dual roll).

Band Length: 15" (38.1 cm) to 52" (132 cm) (7 1/2" (19.05 cm) to 26" (66.04 cm) folded)

Seamer: Yamato 8003 3 thread (504 stitch)

Controls trim-off: 1/4" (6.4 mm) o 1/8" (3.2 mm)


Cut length: Programmable in 1/10" increments

Tolerances

Alignment: Side +/-1/16" (1.2mm), Ends +/-1/16" (1.2mm),
Length Repeatability: +/-1/8" (3.2 mm) (rib knit). Length Is Adjustable to Nearest 1/10 (2,5mm)
Cutting Accuracy: Within 1/8" (3.2 mm) of programmed length
Seam ply alignment: Within 1/8" (3.2 mm) obtainable

Footprint

Machine footprint is 78" x 54" (198x137 cm) Leave enough free space around to be able to open all doors and have access for maintenance.



Machine Identification Label

Machine identification is located on top of the table behind the sewing head. Its contents are the machine class and the Serial Number. Ex: 218427031707


Serial number is divided as follow.

First number identify the order number 218427

Next number month of manufacturing (03)

Next number the year of manufacturing (17)

Following a correlative number 07



2. SERVICE

NOTE: Maintenance should only be performed by trained, qualified personnel.

Lockout/Tagout Program

"Lockout/Tagout (LOTO)" refers to specific practices and procedures to safeguard employees from the unexpected energization or startup of machinery and equipment, or the release of hazardous energy during service or maintenance activities. This requires that a designated individual turns off and disconnects the machinery or equipment from its energy source(s) before performing service or maintenance and that the authorized employee(s) either lock or tag the energy-isolating device(s) to prevent the release of hazardous energy and take steps to verify that the energy has been isolated effectively. The following references provide information about the LOTO process.

| | | | | |
|---|---|---------------------|---------------|----------------|
| Equipment Energy Control Procedure Lockout/Tagout Program | | | | |
| Description: Band / Collar Maker | | Model: 1996B | | |
| Manufacturer: Atlanta Attachment Co. | | Location: | | |
| | | | | |
| Energy | | Location | Magnitude | Control Method |
| Electrical: | X | Disconnect/Ctrl Box | 220V | Lockout & Tag |
| Pneumatic: | X | Main Regulator | 80 PSI | Lockout & Tag |
| Gravity: | X | Belts | | |
| Remember to Release All Stored Energy! | | | | |
| Shutdown Procedure: | | | | |
| Inform all affected personnel that the machine will be in Lockout status. Turn the power and pneumatic disconnects to the OFF position. Fill out the tag with necessary information of the Lockout. Install the Lockout device. Verify all stored electrical energy has been released by pressing the power on button. Also, use meter to test circuits in the electrical panel to insure stored energy is released there as well. Perform necessary maintenance, services and/or repairs. | | | | |
| Startup Procedure: | | | | |
| Inform all affected personnel that the Lockout of this machine is being removed. Replace any guards or safety devices which may have been removed during maintenance. Remove the Lockout device and tag. Turn the power and pneumatic disconnects to the ON position. Push the green button on the back of the control panel to turn the machine on. Inform all affected personnel that the Lockout has been removed and that the machine is ready for normal production operation. | | | | |

Approved By: _____

Date: _____

Notes:

Parts List

3. Assembly Drawings & Parts Lists

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.




Atlanta
PARTS DEPOT

One-Stop Shopping
For Expendable Replacement Parts for AAC & Other Bedding Equipment Suppliers
Toll Free: **1-866-885-5100**
www.atlantapartsdepot.com • sales@atlantapartsdepot.com

11996BQ65ES Auto Collar & Band, DC1500, SBUS


AAC Drawing Number 192206B Rev 0



| NO | QTY | PART # | DESCRIPTION |
|----|-----|-------------|---------------------------|
| 1 | 1 | 1996GD | AUTO COLLAR & BAND UNIT |
| 2 | 1 | 1996A-02Q65 | JUKI SEWING HEAD & DETAIL |
| 3 | 1 | 1996011 | THREAD ASSEMBLY |
| 4 | 1 | 1996A-EFKA | PACKAGE, EFKA DC1500 |
| 5 | 1 | 1996ES-WD | WIRING DIAGRAM |
| 6 | 1 | 1959-161 | 3 POS THREAD PLATE ASSY |

1996011 Three Rotary Thread Brake Assembly

AAC Drawing Number 1996011 Rev 0




| NO | QTY | PART # | DESCRIPTION |
|----|-----|-----------|---------------------------|
| 1 | 1 | 0411-069C | BRKT,THREAD BRK DETECTION |
| 2 | 1 | 0411-070 | CLAMP, SENSOR BRACKET |
| 3 | 3 | 4003-500B | THREAD BREAK SENSOR ASSY |
| 4 | 6 | SSBC98024 | 10-32 X 3/8 BUTTON CAP SC |
| 5 | 2 | SSSC98048 | 10-32 X 3/4 SOC CAP |
| 6 | 8 | WWFS10 | WASHER, FLAT, #10, SAE |
| 7 | 2 | WWL10 | WASHER,LOCK,#10 |

Parts List

4003-500B Thread Brake Sensor Assembly

AAC Drawing Number 9002422 Rev 4




| NO | QTY | PART # | DESCRIPTION |
|----|-----|-----------|---------------------------|
| 1 | 1 | 4003-501A | BRACKET,ENCODER MOUNT |
| 2 | 1 | 4003-501B | BRKT,AUX TENSION SPRING |
| 3 | 1 | 4003-502A | WHEEL,THREAD SENSOR |
| 4 | 2 | 4003-504 | THREAD GUIDE, IN/OUT |
| 5 | 2 | 4003-BYW2 | THREAD TENSION, EYELET |
| 6 | 1 | EENC025 | ENCODER,SBUS,025,1/8 |
| 7 | 2 | MMKC34 | CERAMIC EYELET FOR THREAD |
| 8 | 1 | SSBC80012 | BHCS #6-32X..25L |
| 9 | 2 | SSBC98024 | 10-32 X 3/8 BUTTON CAP SC |
| 10 | 2 | WWFS10 | WASHER, FLAT, #10, SAE |

Parts List

1996A-02Q65 Sewing Head Detail

AAC Drawing Number 191054B Rev 0




| NO | QTY | PART # | DESCRIPTION | NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|------------------------------|----|-----|-------------|-----------------------------|
| 1 | 1 | MM1631481 | FUNNEL | 8 | 1 | 1975-400Y | CUTTER AND FOOTLIFT COMP. |
| 2 | 1 | 26276E | LABEL | 9 | 4 | 23275 | ISOLATOR MOUNT |
| 3 | 1 | 311-128 | TAPE MOUNTING | 10 | 1 | 4059-PM63 | MOTOR PULLEY |
| 4 | 4 | SSSC01064 | SCREW, SOCKET CAP 1/4-20 X 1 | 11 | 1 | 311-129 | TAPE MOUNTING |
| 5 | 1 | ZX3835 | V BELT | 12 | 1 | 217-J001A | CHUTE, CHAIN SCRAP, 3/4 CUT |
| 6 | 1 | AAQME-5-8 | ELBOW | 13 | 1 | SIUKI-6916S | SEWING HEAD |
| 7 | 1 | 1975-400MG | CUTTER ASSEMBLY, 3/4 CUT | 14 | 1 | AAV#TBV400 | CHAIN & WASTE VAC |

Parts List

1975-400Y Cutter & Foot lift Comp.

AAC Drawing Number 9006412 Rev 5




1975-400Y parts list

| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|---------------------------|
| 1 | 1 | 1975-452 | MOUNT, COMB. CYLINDER |
| 2 | 2 | WWF1/4 | WASHER, FLAT, 1/4", COM |
| 3 | 2 | SSM7151210 | SCREW, 15/64-28X7/16 |
| 4 | 2 | WWF10 | WASHER, FLAT, #10, COM |
| 5 | 2 | NNH10-32 | HEX-NUT 10-32 REG. |
| 6 | 1 | 1976-048 | STUD, CYLINDER MOUNT |
| 7 | 1 | CCSC33/16 | COLLAR,SET,3/16" |
| 8 | 1 | 1975-213A | CYL,AIR,DA,9/16 B,1S |
| 9 | 1 | CCCL3F | CLAMP COLLAR- 3/16 |
| 10 | 1 | 1975-408 | LINK, DRIVE |
| 11 | 1 | WWFF1/4A | WASHER,FLAT,FELT |
| 12 | 1 | MM92390A15 | PIN,CLEVIS, 14"D X 3/4"L |
| 13 | 1 | MM98335A04 | SPRING CLIP |
| 14 | 1 | 1975-451 | SPACER, CUTTER BODY |
| 15 | 2 | SSSC85024 | 6-40 X 3/8 SOC CAP SC |
| 16 | 1 | 1975-445 | GAURD, MATERIAL |
| 17 | 2 | SSTS85016 | #6-40 X 1/4 TRUSS HEAD |
| 18 | 2 | AAQME-5-10 | AIR ELBOW, 10-32 X 5/32 |
| 19 | 1 | AAC7DP-1 | CYL.,AIR,DA 3/4 BORE,1STR |
| 20 | 1 | NNJ5/8-18 | NUT-HEX JAM 5/8-18 |
| 21 | 1 | NNH1/4-28 | NUT,HEX,1/4-28 |
| 22 | 1 | 11200 | BUMPER,1/4-28 |
| 23 | 1 | AAQME-5-8 | QUICK MALE ELBOW |

Parts List

1975-400MG Cutter Assembly

AAC Drawing Number 191731C Rev 1




| NO | QTY | PART # | DESCRIPTION |
|----|-----|--------------|-------------------------------|
| 1 | 1 | ATC2-Y2302 | UPPER CUTR ASSY |
| 2 | 1 | RRLC026CD15S | SPRING |
| 3 | 1 | 1976-002 | RETAINER |
| 4 | 1 | ATC2-Y2303 | LOWER CUTTER |
| 5 | 2 | SSSC70016 | SCREW, SOCKET, CAP 4-40 X .25 |
| 6 | 1 | 1975-432 | CUTTER BODY |
| 7 | 1 | 1975-407 | CLEVIS |

Parts List

1966GD Console, SBUS, EFKA

AAC Drawing Number 192205B Rev 2




1966GD parts list

| Part Number | Description | Part Number | Description |
|-------------|-------------|-------------|---|
| 1 | 1996-01D | 17 | WWFS1/4 Washer, Flat |
| 2 | 1996005 | 18 | 1996B-PD Diagram, Pneumatic |
| 3 | 97-1700A | 19 | SSHC01192 Screw, Hex, 1/4-20 x 3 |
| 4 | 1996-05 | 20 | 1996ES-WD Diagram, wiring |
| 5 | 1996-06 | 21 | SSTS98040 Screw, Truss, 10-32 x 5/8 |
| 6 | 1996-08B | 22 | NNK10-32 Kep nut |
| 7 | 1996-12 | 23 | 1996-038 Plate, SLK Loop |
| 8 | 1996010 | 24 | 1996-300A Guillotine Assy |
| 9 | 1996-15A | 25 | SSHC01160 Screw, Hex, 1/4-20 x 2-1/2 |
| 10 | 1996-Label | 26 | NNK1/4-20 Kep nut |
| 11 | SSFP01048 | 27 | 1996-23 Stripper Fingers |
| 12 | SSPS95128 | 28 | 1996007 Panel, Pneu Control |
| 13 | WWFS10 | 29 | FFSM312LVQ Photocell |
| 14 | SSZS93032 | 30 | 265155A Holder, eye |
| 15 | 1996-10B | 31 | 1740BB-43 Rod, straight |
| 16 | WWL1/4 | 32 | 28201 Rod, connector |

1996-10B Transfer Sub-Assembly

AAC Drawing Number 192118C Rev 4




1996-10B part list

| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|-----------------------------------|
| 1 | 1 | 265160A | BASE, EMERG |
| 2 | 1 | AACMGQ2075 | CYL.,AIR DUAL ROD |
| 3 | 1 | AACR203010 | AIR CYLINDER |
| 4 | 2 | AA198RA408 | FLOW CONTROL |
| 5 | 2 | AAQME-5-8 | QUICK MALE ELBOW |
| 6 | 8 | NNH10-32 | HEX NUT, 10-32 |
| 7 | 4 | SSPS70048 | SCREW, PAN HD SLOTTED 4-40 X 3/4 |
| 8 | 4 | SSSC98144 | SCREW, SOCKET CAP 10-32 X 2 1/4 |
| 9 | 1 | SSHC10064 | SCREW, HEX CAP 5/16-18 X 1 |
| 10 | 8 | WWFS10 | SAE FLAT WASHER |
| 11 | 8 | WWL10 | WASHER, LOCK |
| 12 | 4 | SSSCM6X20 | SCREW, SOCKET CAP M6 X 20 |
| 13 | 11 | SSCM5X16 | SCREW, SOCKET CAP 5MM X 16MM LONG |
| 14 | .9' | MM93085K15 | GROM. STRIP, RUB. |
| 15 | 4 | AAF3/16 | CLAMP, BLACK |
| 16 | 2 | 0411-3123 | BLOCK, MOUNTING |
| 17 | 4 | SSSC98040 | SCREW, SOCKET CAP 10-32 X 5/8 |
| 18 | 1 | 1996-101A | BEAM, TRANSFER |
| 19 | 1 | 1996-102A | PLATE, TRANSFER |
| 20 | 1 | 350-5913 | ROD, 1/2" |
| 21 | 1 | 1996-104 | PAD, TRANSFER |
| 22 | 1 | 1996-107 | UNCURLER BLOW TUBE |
| 23 | 2 | SSSC98032 | SCREW, SOCKET CAP 10-32 X 1/2 |
| 24 | 2 | FFSM312LVQ | ELECTRIC EYE |
| 25 | 3 | 265155A | HOLDER, EYE |
| 26 | 2 | SSSC70016 | SCREW, SOCKET CAP 4-40 X 1/4 |
| 27 | 1 | A-U | ROD CONNECTOR |
| 28 | 1 | 1996-103A | ROD, 1/2" 90 DEGREES X 2 |
| 29 | 4 | SSSCM5X10 | SCREW, SOCKET CAP M5 X 10 |

Parts List

1996-15A Indexing Table

AAC Drawing Number 191083 Rev 0



1996-15A Parts list


| QTY. RECD. | ITEM NO. | DESCRIPTION | PART NO. STOCK SIZE |
|------------|----------|----------------------------------|---------------------|
| 1 | 29 | SAE FLAT WASHER | WWFS10 |
| 12 | 28 | NUT, KEP | NNK1/4-20 |
| 4 | 27 | IFG ASSFMRIY | 26238 |
| 4 | 26 | LEG MOUNT | 1996-152 |
| 1 | 25 | CYL MOUNT BRKT | 26196 |
| 2 | 24 | BUTTON VALVE BRACKET | 1904-13 |
| 1 | 23 | MATERIAL STOP | 025-030 |
| 1 | 22 | MATERIAL PUSHER | 025-029 |
| 1 | 21 | GUIDE BLOCK | 025-028 |
| 1 | 20 | SLIDE TONGUE | 1996-153 |
| 1 | 19 | TABLE TOP | 1996-151 |
| 12 | 18 | BOLT, CARRIAGE 1/4-20 x 1 1/2 | SSBK01096 |
| 1 | 17 | PNEUMATIC DIAGRAM | 1996-154 |
| 8 | 16 | 1/4 LOCK WASHER | WWL1/4 |

| QTY. RECD. | ITEM NO. | DESCRIPTION | PART NO. STOCK SIZE |
|------------|----------|--|---------------------|
| 24 | 15 | 1/4 WASHER | WWFS1/4 |
| 2 | 14 | SCREW, SOCKET CAP 10-32 x 1 1/2 | SSSC98032 |
| 12 | 13 | SCREW, HEX CAP 1/4-20 x 3/4 | SSHC01048 |
| 2 | 12 | SCREW, FLAT ALLEN CAP 10-32 x 1 1/2 | SSFC98032 |
| 2 | 11 | 5/16-24 JAM NUT | NNJ5/16-24 |
| 2 | 10 | N.O. SWITCH | FF23F439 |
| 8 | 9 | 5/32 AIRLINE | AATP5/32 |
| 1 | 8 | 1 1/4 SIRAP | MM2255 |
| 2 | 7 | EDGE GUIDE | 311-127 |
| 13 | 6 | SCREW, HEX SHEET METAL NO. 10 x 1 1/2 | SSZH#10032 |
| 2 | 5 | NO. 10 WASHER | WWF10 |
| 1 | 4 | PIVOT BRACKET | AAFFD-167 |
| 2 | 3 | SCREW, PAN SLOTTED 10-32 x 1 | SSPS98064 |
| 1 | 2 | AIR CYLINDER | AAC6DP-18 |
| 2 | 1 | FLOW CONT | AA198RA508 |

Parts List

26238 Leg Sub-Assembly

AAC Drawing Number 9001599 Rev 2




| NO | QTY | PART # | DESCRIPTION |
|----|-----|-----------|------------------|
| 1 | 1 | 26127 | LEG FOR AP-26-02 |
| 2 | 1 | MMFB4444 | FOOT, RUBBER |
| 3 | 1 | NNH1/2-13 | NUT,HEX,1/2-13 |

Parts List

1996-12 Stacker Door Assembly

AAC Drawing Number 191379C Rev 5




1996-12 parts list

| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|------------------------------------|
| 1 | 1 | BBAW-5Z | ROD END BEARING |
| 2 | 5' | MM100-1/8 | DOOR TRIM-BLK |
| 3 | 2 | MM2X897 | BLOCK, PILLOW |
| 4 | 1 | AAQUT-4-4 | QUICK UNION T |
| 5 | 1 | AAQPR-5-4 | REDUCER |
| 6 | 4 | NNH5/16-18 | NUT, HEX |
| 7 | 1 | NEE5/16-18 | ELASTIC NUT |
| 8 | 5 | SSHC10112 | SCREW, HEX CAP 5/16-18 X 1 3/4 |
| 9 | 11 | WWFS5/16 | SAE FLAT WASHER |
| 10 | 8 | WWF5/16 | SAE FLAT WASHER |
| 11 | 4 | WWL5/16 | WASHER, LOCK |
| 12 | 6 | SSSC98048 | SCREW, SOCKET CAP 10-32 X 3/4 |
| 13 | 10 | WWL10 | WASHER, LOCK |
| 14 | 1 | 23105 | ROD, STRAIGHT |
| 15 | 3 | 23112A6 | HINGE |
| 16 | 1 | 23634 | MOD DAMPER CYL |
| 17 | 2 | AAQME-4-8 | QUICK MALE ELBOW |
| 18 | 1 | 23112A1 | SCREEN |
| 19 | 1 | 1996-121 | LEVER |
| 20 | 1 | 23112A3 | STIFFENER |
| 21 | 1 | 23112A4 | MOUNT |
| 22 | 1 | 23112A5 | SUPPORT |
| 23 | 4 | SSSC98024 | SCREW, SOCKET CAP 10-32 X 3/8 |
| 24 | 18 | SSPP98024 | SCREW, PAN HD PHILLIPS 10-32 X 3/8 |
| 25 | 18 | WWB1/4 | BONDED WASHER |
| 26 | 2 | AA3000F-07 | FLOW CONTROL, AIR |
| 27 | 1 | NNJ5/16-24 | JAM NUT |
| 28 | 1 | 273-4-503 | 1/4 LEATHER WASHER |

Parts List

1996-08B Feed Assembly

AAC Drawing Number 192116C Rev 5



1996-08B parts list


| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|-----------------------------------|
| 21 | 2 | 1996-087 | MOUNT, FAB EDGE GUIDE |
| 22 | 1 | 1996-088 | FABRIC GUIDE, RIGHT |
| 23 | 1 | 1996-089 | FABRIC GUIDE, LEFT |
| 24 | 4 | SSSC98056 | SCREW, SOCKET CAP 10-32X 7/8 |
| 25 | 2 | SSSS01024 | SCREW, SOCKET, SET 1/4-20 X 3/8 |
| 26 | 3 | TTCLJAPPK1 | KNOB, 10-32 |
| 27 | 6 | WWL1/4 | WASHER, LOCK |
| 28 | 6 | WWFS1/4 | SAE FLAT WASHER |
| 29 | | | |
| 30 | 2 | 3517 | BEARING, BRONZE, THRUST |
| 31 | 4 | SSHC01048 | SCREW, HEX CAP 1/4-20 X 3/4 |
| 32 | 2 | 1917-22 | MOUNT, BOTTOM ROLL |
| 33 | 3 | SSPS98096 | SCREW, PAN SLOTTED, 10-32 X 1-1/2 |
| 34 | 3 | WWSI10 | WASHER, LOCK, INTERNAL TOOTH |
| 35 | 4 | SSSC01064 | SCREW, SOCKET CAP 1/4-20 X 1 |
| 36 | 2 | SSHC01040 | SCREW, HEX CAP 1/4-20 X 5/8 |
| 37 | 16 | WWL10 | WASHER, LOCK |
| 38 | 8 | SSPS90024 | SCREW, PAN HD SLOTTED 8-32 X 3/8 |
| 39 | 12 | SSSC98040 | SCREW, SOCKET CAP 10-32 X 5/8 |
| 40 | 1 | 1996002 | UNCURL WIRE |

| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|----------------------|
| 1 | 1 | A-4-032A | EDGE GUIDE |
| 2 | 1 | EE540201B1 | MOTOR WITH GEAR HD. |
| 3 | 1 | 1996-21 | DOUBLE PULLER |
| 4 | 1 | GG100XL037 | BELT, GEAR |
| 5 | 1 | 1996-088A | RIGHT CENTER GUIDE |
| 6 | 1 | 1535E-079 | PULLEY, GEAR 22T |
| 7 | 1 | 1996-22 | BOT ROLLER, URETHANE |
| 8 | 1 | 1917-21 | SHAFT, BOT ROLLER |
| 9 | 1 | 1996-089A | LEFT CENTER GUIDE |
| 10 | 1 | 1996-314 | PLATE, PREFEED |
| 11 | 1 | 1996-123 | LOWER CENTER BRKT |
| 12 | 1 | 1996-122 | UPPER CENTER BRKT |
| 13 | 1 | 1996-0812 | MOUNT, BAND PUL MTR |
| 14 | | | |
| 15 | 4 | 1996-24 | SUPPORT, F & C ASSY |
| 16 | | | |
| 17 | 2 | 1996017 | ROD, CRS |
| 18 | 16 | WWFS10 | SAE FLAT WASHER |
| 19 | 1 | 1995-017 | PULLEY, MOTOR |
| 20 | 4 | 1996-086 | MOUNT, FABRIC GUIDE |

Parts List

1996-21 Double Puller Assembly

AAC Drawing Number 191754C Rev 1



| QTY. RECD. NO. | ITEM NO. | DESCRIPTION | PART NO. STOCK SIZE |
|----------------|----------|-------------------------------|---------------------|
| 2 | 10 | ALIGNMENT PLATE | 350198 |
| 2 | 9 | ALIGNMENT BRACKET | 350199 |
| 2 | 8 | 1/4 x 2" DOWEL PIN | IID016X128 |
| 4 | 7 | SCR, FLAT SLOTTED #8-32 x 1/4 | SSFS90016 |
| 2 | 6 | FELT WASHER | WWFF1/2 |
| 2 | 5 | ROLLER YOKE | 3511AZ096M |
| 2 | 4 | SHAFT, ROLLER | 3513-300 |
| 2 | 3 | ROLLER, AL | 3514A5 |
| 4 | 2 | THRUST WASHER | 3517 |
| 2 | 1 | SCR, SOCKET CAP 5/16-24 x 1 | SSSC20064 |

| QTY. RECD. NO. | ITEM NO. | DESCRIPTION | PART NO. STOCK SIZE |
|----------------|----------|-------------------------------------|---------------------|
| 4 | 20 | SCREW, PAN HEAD SLOTTED 8-32 x 3/16 | SSPS90012 |
| 1 | 19 | DOUBLE BLOWER | 1996-2104 |
| 2 | 18 | 1/2" CLAMP COLLAR | CCCL8F |
| 4 | 17 | SCR, SOCKET CAP #8-32 x 1/2 | SSSC90032 |
| 4 | 16 | #8 LOC WASHER | WWL8 |
| 8 | 15 | #8 FLAT WASHER | WWF8 |
| 1 | 14 | BRACKET | 1996-2101 |
| 2 | 13 | AIR CYLINDER | AACFSD091 |
| 4 | 12 | QUICK CONN. ELBOW | AAQME-5-8 |
| 4 | 11 | SCR, TRUSS SLOTTED #8-40 x 3/16 | SSTS85012 |


1996-06 parts list

| NO | QTY | PART # | DESCRIPTION |
|------|-----|------------|---|
| 1 | 1 | AAQME-5-8 | QUICK MALE EL |
| 2 | 1 | AAC7D-1 | AIR CYLINDER |
| 3 | 5 | TTCL1BPPK1 | TORQ KNOB |
| 4 | 1 | 11200 | BUMPER |
| 5 | 1 | 265018 | LIFT CYL BRKT |
| 6 | 1 | 265019 | LIFT CYL MOUNT |
| 7 | 1 | 1996-063 | CONV. MNT PLATE |
| 8 | 4 | SSHC01056 | SCREW, HEX CAP 1/4-20 X 7/8 |
| 9 | 2 | WWSE1/4 | WASHER, STAR |
| 10 | 8 | WWL1/4 | WASHER, LOCK |
| 11 | 2 | SSHC01040 | SCREW, HEX CAP 1/4-20 X 5/8 |
| 12 | 3 | NNH1/4-20 | NUT, HEX |
| 13 | 1 | 1996-061 | PLATE, CONV ADJUSTER |
| 14 | 2 | SSFS01048 | SCREW, FLAT SLOTTED 1/4-20 X 3/4 |
| 15 | 4 | SSFC10056 | SCREW, FLAT CAP 5/16-18 X 7/8 |
| 16 | 4 | NNH5/16-18 | NUT, HEX |
| 17 | 4 | WWFS5/16 | WASHER, FLAT SAE |
| 18 | 2 | RRLC045G5 | SPRING |
| 19 | 2 | 23056 | SUPPORT, WELDMENT |
| 19.1 | 2 | SSSS01012 | SCREW, SOCKET SET 1/4-20 X 3/16 |
| 20 | 1 | 1996-066 | SHAFT, HEX |
| 21 | 2 | SSFC95176F | SCREW, FLAT CAP 10-24 X 2 3/4 (FULL THRD) |
| 22 | 1 | NNE5/16-18 | ELASTIC NUT |
| 23 | 4 | NNH10-24 | NUT, HEX |
| 24 | 1 | 1996-062 | PLATE, CONV. SWG OUT |
| 25 | 1 | 1996-064 | ADJUSTER, CONV SWG OUT |
| 26 | 1 | SSHC01032 | SCREW, HEX CAP 1/4-20 X 1/2 |
| 27 | 4 | WWFS10 | WASHER, FLAT |
| 28 | 2 | MM2X897 | PILLOW BLOCK |
| 29 | 11 | WWFS1/4 | WASHER, FLAT SAE |
| 30 | 1 | NNJ1/4-28 | NUT, JAM |
| 31 | 1 | SSHC10128 | SCREW, HEX CAP 5/16-18 X 2 |
| 32 | 1 | WWF5/16 | WASHER, FLAT |
| 33 | 1 | WWFE020 | WASHER, LG FENDER |
| 34 | 4 | WWL5/16 | LOCK WASHER |
| 35 | 1 | TT552514 | TERM,RING,1/4",14-16GA |
| 36 | 2' | FF3077-28 | WIRE,STR,#16,PVC,GRN/YEL |

Parts List

1996-05 Top Conveyor Assembly

AAC Drawing Number 191372C Rev 4




1996-05 parts list

| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|--|
| 1 | 2 | MM8407A138 | "E " RING, 1/2 |
| 2 | 1 | PP24XLB37M | GEAR PULLEY, MOD |
| 3 | 4 | SSAS016048 | SCREW, SOCKET SHOULDER 1/4 X 3/4. 10-24 |
| 4 | 2 | SSAS020016 | SCREW, ALLEN SHOULDER 5/16 X 1/4, 1/4-20 |
| 5 | 16 | SSSC01024 | SCREW, SOCKET CAP 1/4-20 X 3/8 |
| 6 | 1 | 1996-051 | BRKT, BEARING LFT |
| 7 | 1 | 1996-052 | BRKT, BEARING RGT |
| 8 | 4 | 1996-053 | SPACER |
| 9 | 1 | 1996-054 | ROLLER |
| 10 | 1 | 1996-055 | SHAFT, DRV 0.5X4.0 |
| 11 | 2 | 1996-056 | SLIDE PLATE, CONV |
| 12 | 1 | 1996-057 | BELT, URETHANE |
| 13 | 1 | 1996-07 | FRONT CONVEYOR |
| 14 | 1 | 26006 | BELT GUARD |
| 15 | 1 | 26017 | MOUNT,STEP MOTOR |
| 16 | 1 | AP-22E-103 | STEP MOTOR MOD |
| 17 | 1 | PP12XL037 | GEAR, PULLEY |
| 18 | 2 | SSHHC01048 | SCREW, HEX CAP 1/4-20 X 3/4 |
| 19 | 2 | WWL1/4 | 1/4 LOCK WASHER |
| 20 | 2 | SSSC98048 | SCREW, SOCKET CAP 10-32 X 3/4 |
| 21 | 2 | NNK10-32 | 10-32 KEP NUTS |
| 22 | 1 | GG120XL037 | BELT, GEAR |
| 23 | 1 | AA2000F-03 | FLOW CONTROL, AIR |
| 24 | 4 | SSPS80016 | SCREW, PAN HD SLOTTED 6-32 X 1/4 |
| 25 | 2 | BBIL005 | BALL BEARING |
| 26 | 2 | SSSC98032 | SCREW, SOCKET CAP 10-32 X 1/2 |
| 27 | 2 | WWFS1/4 | WASHER,FLAT |
| 28 | 4 | RRLC026E1 | SPRING |

Parts List

1996-07 Front Conveyor Assembly

AAC Drawing Number 191374C Rev 5




1996-07 parts list

| QTY. RECD. | ITEM NO. | DESCRIPTION | PART NO. STOCK SIZE |
|------------|----------|--|---------------------|
| 2 | 40 | WASHER, NO. 8 | WWF8 |
| 1 | 39 | SCREW, SOCKET CAP 10-32 x 5/8 | SSSC98040 |
| 2 | 38 | AIRLINE CLAMP | AAF3/16 |
| 1 | 37 | SCREW, SOCKET CAP 8-32 x 1 1/4 | SSSC90080 |
| 2 | 36 | SCREW, PAN HD SLOTTED 10-32 x 1 1/4 | SSPS98080 |
| 6 | 35 | SCREW, SOCKET CAP 8-32 x 3/4 | SSSC90048 |
| 6 | 34 | 10 SAE FL WASHER | WWFS10 |
| 2 | 33 | 10 LOCK WASHER | WWL10 |
| 2 | 32 | SCREW, SOCKET CAP 10-32 x 3/4 | SSSC98048 |
| 2 | 31 | SCREW, SOCKET CAP 10-32 x 1/2 | SSSC98032 |
| 3 | 30 | SCREW, SOCKET CAP 8-32 x 1/2 | SSSC90032 |
| 2 | 29 | SCREW, PAN HD SLOTTED 8-32 x 1 1/2 | SSPS90032 |
| 3 | 28 | QUICK MALE ELBOW | AAQME-5-10 |
| 1 | 27 | SUPPORT RFRING | 265064 |
| 1 | 26 | RT FRT PLATE | 265061 |
| 1 | 25 | LFT FRT PLATE, TOP | 265060 |
| 1 | 24 | PULLEY, MOD. 18T | 26183 |
| 2 | 23 | ADAPTER PLATE | 26181 |
| 1 | 22 | BRACKET, CYLINDER | 26180 |
| 2 | 21 | BUSHING,IDL PULLEY | 26179 |
| 1 | 20 | 1D LER, TENSION | 26169 |
| 1 | 19 | COLLAR, 3/16" CLAMP | CCCL3F |
| 4 | 18 | 8-32 HEX NUT | NNH8-32 |
| 1 | 17 | LOCK PIN | 1996-077 |
| 1 | 16 | SHAFT,FRT CNV PIV | 1996-076 |
| 1 | 15 | SPACER, FNT CONV | 1996-075 |
| 1 | 14 | PULLEY, PIVOT BELT | 1996-074 |
| 1 | 13 | TUBE, CNV MNTD | 1996-073 |
| 1 | 12 | GUIDE, BELT | 1996-072 |
| 1 | 11 | MNT PLT, FT CONV | 1996-071 |
| 2 | 10 | 10-32 HEX NUT | NNH10-32 |
| 4 | 9 | 10-32 KEP NUT | NNK10-32 |
| 1 | 8 | COLLER KEY | MM98355A04 |
| 1 | 7 | GEAR BELT, 125T | GGD250XL37 |
| 1 | 6 | BEARING, BRONZE | BBTT602 |
| 1 | 5 | THRUST WASHER | BBTRA411 |
| 1 | 4 | HARD. STEEL WASH | BCD1-2 |
| 1 | 3 | HUMPHREY CLEVIS | AAFCT-8 |
| 1 | 2 | PIVOT BRACKET | AAFBP-8C |
| 1 | 1 | CYLINDER, AIR 1/2 | AAC8DP-1 |

Parts List

97-1700A Touch Screen Assembly

AAC Drawing Number 192617C Rev 5




| ITEM NO. | QTY. | PART NUMBER | DESCRIPTION |
|----------|------|-------------|--------------------------------|
| 1 | 1 | 1278-6010 | START/STOP BUTTON ASSY |
| 2 | 1 | 13351060 | MOUNT, 10" TOUCH SCREEN |
| 3 | 1 | 28201 | CONNECTOR, ROD, LARGE |
| 4 | 1 | 4082105 | TOUCHSCREEN, 10", SUB ASSEMBLY |
| 5 | 1 | 97-1711 | TUBE, 3/4 OD X 30.0L |
| 6 | 1 | AP-1721 | STAND BASE, COMPLETE |
| 7 | 1 | CCCL12F | CLAMP COLLAR- 3/4 |
| 8 | 10' | EE16-3C2406 | CABLE, 3 COND |
| 9 | 4 | SSPS90040 | 8-32 X 5/8 PAN HD |
| 10 | 4 | SSSCM3X12 | M3-0.5X12 ,SOCKET CAP |
| 11 | 2 | TTH6324K63 | HANDLE, THREADED, M8 X 20MM |
| 12 | 4 | WWFM3 | FLAT WASHER, M3 |
| 13 | 4 | WWLM3 | WASHER, LOCK, M3 |

Parts List

1278-6010 Start/Stop Button Assembly

AAC Drawing Number 191058B Rev 3




| NO | QTY | PART # | DESCRIPTION |
|----|-----|-----------|-----------------------|
| 1 | 1 | EEPCB65GM | ENCLOSURE MODIF. |
| 2 | 1 | EEPMTS44 | E-STOP BUTTON |
| 3 | 1 | EEPF3 | START BUTTON |
| 4 | 2 | EEA3L | MOUNTING LATCH |
| 5 | 1 | EE3X01 | CONTACT BLOCK N.C. |
| 6 | 1 | EE3X10 | CONTACT BLOCK N.O. |
| 7 | 1 | EE15Y | LEGEND PLATE |
| 8 | 1 | FF3210 | STRAIN RELIEF, 9MMHUB |
| 9 | 1 | 4080-4214 | CABLE, 1.5 FT |
| 10 | 1 | 4080-4215 | CABLE |

Parts List

1996005 Control Box, Pneumatic/Electric

AAC Drawing Number 1996005 Rev 1




1996005 parts list

| ITEM | QTY. | PART NUMBER | DESCRIPTION |
|------|------|---------------|---------------------------------------|
| 1 | 1 | 1996-035 | BRACKET SPEED CONTROL MT. |
| 2 | 1 | 1996006 | PNEUMATIC/ ELEC. BOX |
| 3 | 1 | 3210159 | COVER, TRANSFORMER |
| 4 | 1 | 4030 | TRANSFORMER,220 INPUT |
| 5 | 3 | 4080-110 | MODULE,QUAD INPUT |
| 6 | 1 | 4080-120 | MODULE,SBUS, DUAL OPTO-ISO, INPT |
| 7 | 1 | 4080-130 | MODULE,QUAD OPTO-ISO |
| 8 | 1 | 4080-140 | MODULE,QUAD OUTPUT |
| 9 | 1 | 4080-200 | MODULE,AIR PRESSURE |
| 10 | 1 | 4080-4617 | CABLE, SBUS |
| 11 | 1 | 4080-900 | SBUS MODULE, USB GATEWAY, INTERFACE |
| 12 | 1 | 4080-940 | MODULE,TERMINATOR |
| 13 | 1 | 4082004 | PC POWER BLOCK BRACKET |
| 14 | 4 | EECLIPFIX | ANCHOR,DIN RAIL |
| 15 | 1 | EECN25RB6 | CONTACTOR,IEC,24VAC COIL |
| 16 | 2 | EEDC2X2 | COVER,WIRE DUCT |
| 17 | 2 | EEDF2X2 | DUCT,WIRE,2X2, MOD |
| 18 | 1 | EEM30U3M | DISCONNECT ASSY, 3PH, 30A |
| 19 | 1 | EESPA210-3.40 | DISCONNECT SHAFT,MOD |
| 20 | 1 | EETS35X7.5A | DIN RAIL-AMERICAN |
| 21 | 1 | EETS35X7.5A | DIN RAIL-AMERICAN |
| 22 | 6 | FF1724 | STRAIN RELIEF |
| 23 | 8 | FF264-341 | TERMBLK,WAGO,TOP,DUAL,GRY |
| 24 | 1 | FF264-347 | TERMBLK,WAGO,TOP,DUAL,GRN |
| 25 | 1 | FF264-371 | TERMBLK,WAGO,TOP,END |
| 26 | 1 | FF89F957 | RELAY,SSR,24VAC,25A |
| 27 | 1 | FFFAZD21NA | BREAKER,1P,2A,UL489,240VT-MAG |
| 28 | 3 | FFFAZD22NA | BREAKER,2P, 2A,UL489,240VT-MAG |
| 29 | 2 | FFFAZD42NA | BREAKER,2P,4A,UL489,240VT-MAG,D-CURVE |
| 30 | 1 | FFRAV781BW | MODULE, TVS, 240 VAC |
| 31 | 1 | FFTX28 | TRANSFORMER,28V,2AMP |
| 32 | 21 | SSPP80024 | # 6-32X3/8 PAN PHILLIPS |
| 33 | 23 | WWF6S | WASHER, FLAT, #6 |

1996007 Pneumatic Control Panel

AAC Drawing Number 1996007 Rev 0




1996007 parts list

| ITEM | QTY. | PART NUMBER | DESCRIPTION |
|------|------|-------------|------------------------------|
| 1 | 1 | 1996004 | PANEL, PNEUMATIC , SBUS 1996 |
| 2 | 4 | 4080-140 | MODULE, QUAD OUTPUT |
| 3 | 1 | 4080-950 | MODULE, POWER |
| 4 | 1 | 4080-990B | POWER SUPPLY, SBUS, |
| 5 | 1 | AAE1996-16 | SOLENOID ASSY, 8 STATION |
| 6 | 3 | AAQMC-5-8 | QU. MALE CONN 5/32X1/8 |
| 7 | 3 | AAQME-4-8 | QUICK MALE ELBOW, 1/4T |
| 8 | 3 | AAQME-5-8 | QUICK MALE ELBOW |
| 9 | 3 | AAV125B | PILOT VALVE |
| 10 | 1 | EE64151B | FERRITE CORE, SPLIT, CABLE |
| 11 | 2 | EEDC2X2 | COVER, WIRE DUCT |
| 12 | 2 | EEDF2X2 | DUCT, WIRE, 2X2, MOD |
| 13 | 16 | FF100F2202 | CONNECTOR, 2 PIN, RED |
| 14 | 16 | FFSC10002 | COVER, STRAIN RELIEF |
| 15 | 3 | MM4554K11 | PLUG, 1/8" PIPE |
| 16 | 10 | SSPP80020 | #6-32 X 5/16 PAN PHILLIPS |
| 17 | 2 | SSPS80080 | #6-32 X 1 1/4 LG PAN HD |
| 18 | 2 | SSPS80128 | #6-32 X 2 PAN HD SLID |
| 19 | 14 | WWF6S | WASHER, FLAT, #6 |

Parts List

1996-01D Table Stand and Motor

AAC Drawing Number 192204B Rev 3




1996-01D parts list

| QTY. RECD. | ITEM NO. | DESCRIPTION | PART NO. STOCK SIZE |
|------------|----------|---|----------------------------|
| 1 | 30 | FOLD BAND SUB-ASSY | 1996-11B |
| 1 | 29 | FRAME WELDMT, CONSOLE | 1996-019 |
| 1 | 28 | BRKT, AIR REGULATOR | 1996-018 |
| 1 | 27 | PLATE, CONVEYOR | 1 |
| 1 | 26 | DOOR, FRONT | 1996-016 |
| 1 | 25 | DOOR, RIGHT REAR | 1996009 |
| 1 | 24 | PANEL, LEFT AT STKR | 1996-014 |
| 1 | 23 | DOOR, RIGHT SIDE | 1996-013 |
| 10 | 22 | LOCK WASHER | WWL1/4 |
| 1 | 21 | TOP, STACKER TBL | 1996-011 |
| 1.5 | 20 | GROMMET STRIP | MM93085K15 |
| 1 | 19 | FOOT PEDAL ASSY | 3800P-002 |
| 3 | 18 | WASHER, LOCK | WWL5/16 |
| 6 | 17 | WASHER, FLAT | WWF5/16 |
| 6 | 16 | SCREW, SHT MTL #10 X 2 | SSZH#10128 |
| 18 | 15 | SCREW, SHT MTL 10-16 X 1/2 (SELF DRILL) | SSZS93032 |
| 3 | 14 | SCREW, HEX CAP 5/16-18 X 1 1/4 | SSHC10080 |
| 10 | 13 | SCREW, HEX CAP 1/4-20 X 3/4 | SSHC01048 |
| 3 | 12 | NUT, HEX | NNH5/16-18 |
| 4 | 11 | NUT, HEX | NNH1/2-13 |
| 4 | 10 | LATCH, ADJ LEVER | MM40450010 |
| 3 | 9 | SCREW, PAN SHEET METAL #12 X 1 | SSZP#12064 |
| 4 | 8 | CASTER, RUBBER | MM503022LB |
| 2 | 7 | CAP, SQ END BLK | MM132-1202 |
| 2 | 6 | NUT PLATE | 1975-412A |
| 2 | 5 | EYE MOUNT, FRAME | 1996-105 |
| 4 | 4 | SCREW, PAN HD SLOT 4-40 X 3/4 | SSPS70048 |
| 2 | 3 | UNION, BULKHEAD | AAQB-5-5 |
| 1 | 2 | FILTER, AIR MICRO LG | AA198-5106 |
| 2 | 1 | QUICK MALE ELBOW | AAQME-4-4 |
| 1 | 60 | PC GATEWAY MOUNT | 4082007 |
| 1 | 59 | GATEWAY PC | EEJBC375CG |
| 1 | 58 | MTNG BKT | 1996012 |
| 1 | 57 | STEPPER BOX | AP-28-800GF |
| 8 | 56 | NUT, JAM, 1/2-20 | NNJ1/2-20 |
| 4 | 55 | THREADED STUD 1/2-20 x 2.81 L | 265072C |
| 1 | 54 | PLATE, HD/MTR MNT | 1996-012 |
| 4 | 53 | SCREW, HEX CAP 1/4-20 x 2-1/2 | SSHC01160 |
| 4 | 52 | WASHER, THRUST | BBTRA411 |
| 2 | 51 | BEARING, THRUST | BBNTA411 |
| 1 | 50 | SCREW, HEX CAP 1/4-20 x 1 1/4 | SSHC01080 |
| 3 | 49 | WASHER, FLAT | WWF10 |
| 2 | 48 | HEX NUT | NNH1/4-20 |
| 1 | 47 | BRACKET, CYL | 1278-6310 |
| 1 | 46 | COVER, REAR F & C | 1996-0111 |
| 1 | 45 | COVER, F & C ASSY | 1996-0110 |
| 1 | 44 | DOOR | 23113 |
| 3 | 43 | NUT, KEP | NNK1/4-20 |
| 12 | 42 | SAE FLAT WASHER | WWFS1/4 |
| 2 | 41 | SCREW, SOCKET CAP 1/4-20 X 1 1/2 | SSSC01032 |
| 1 | 40 | V BELT | ZX3832 |
| 1 | 39 | WASTE CONTAINER ASSEM | O411-1300 |
| 0 | 38 | EKKA, DC MOTOR PANASONIC MOTOR | 4059-DC1500A 4059-D9-N5 |
| 1 | 37 | TAKE-UP STRP SUB-ASSY | 1996-19 |
| 1 | 36 | FLOW CONTROL BANK | 1996-18 |
| 1 | 35 | BAND STOP SUB-ASSY | 1996-17 |
| 2 | 34 | PHOTOCELL, 10-30VDC | FFSM312LVQ |
| 4 | 33 | MOUNT, ISOLATOR | 265072B |
| 4 | 32 | LEG | 26127 |
| 1 | 31 | ROLL MOUNT SUB-ASSY | 1996-16 |

Parts List

0411-1300 Waste Container Assembly

AAC Drawing Number 191225C Rev 10




| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|--------------------------------|
| 1 | 1 | MMTC32GTAN | CONTAINER, WASTE |
| 2 | 2 | MM5415K16 | HOSE CLAMP |
| 3 | 1 | MM16300 | TUBE CLAMP |
| 4 | 1 | MMRPL150 | PLAIN ELBOW |
| 5 | 2 | MMTC32GLN | 1 1/2 CONDUIT LOCK NUT |
| 6 | 1 | MMTC32GR | REDUCER |
| 7 | 1 | NNK1/4-20 | NUT |
| 8 | 2 | 26285A | FILTER, WASTE SYS |
| 9 | 8 | SSPS90064 | SCREW, PAN HD SLOTTED 8-32 X 1 |
| 10 | 6FT | MMFH150 | FLEX HOSE |
| 11 | 1 | SSHC01032 | SCREW, HEX CAP 1/4-20 X 1/2 |
| 12 | 1 | WWF1/4 | WASHER, FLAT |
| 13 | 8 | NNK8-32 | 8-32 KEP-NUT |

Parts List

1996-17 Band Stop Sub-Assembly

AAC Drawing Number 191423C Rev 3




NOTES:
 ▲ USE LOCKTITE RED(262)

| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|-------------------------------|
| 1 | 1 | 1996-171 | BLOCK, SLIDE, B S |
| 2 | 1 | 1996-172 | PLATE, BASE, B S |
| 3 | 2 | 1996-173 | MOUNT, B S ADJUSTER |
| 4 | 1 | 1996-174 | STOP, BAND TWIST |
| 5 | 1 | 1996-175 | ROD, THREADED |
| 6 | 2 | 1996-176 | ROD, D2 |
| 7 | 2 | SSSS80016 | SCREW, SOCKET, SET 6-32 X 1/4 |
| 8 | 4 | SSFC80024 | SCREW, FLAT ALLEN 6-32 X 3/8 |
| 9 | 2 | SSBC98016 | SCREW, BUTTON CAP 10-32 X 1/4 |
| 10 | 2 | SSSC98024 | SCREW, SOCKET CAP 10-32 X 3/8 |
| 11 | 2 | WWFS10 | WASHER, FLAT SAE |
| 12 | 2 | WWL10 | WASHER, LOCK |
| 13 | 3 | NNH10-24 | HEX NUT |
| 14 | 1 | TTCL1BPPK1 | KNOB |

Parts List

1996-16 Roll Mount Sub-Assembly

AAC Drawing Number 191383C Rev 4




| NO | QTY | PART# | DESCRIPTION |
|----|-----|------------|---------------------------------|
| 1 | 2 | SSSC98112 | SCREW, SOCKET CAP 10-32 X 1 3/4 |
| 2 | 1 | SSHC10032 | SCREW, HEX CAP 5/16-18X 1/2 |
| 3 | 2 | WWFS10 | 10 SAE FLAT WASHER |
| 4 | 1 | 1278-6587 | ROD, EMER STOP |
| 5 | 1 | 4012-04-12 | 14" ROD FOR 12" |
| 6 | 1 | 265160A | BASE, EMER OFF SW |
| 7 | 2 | 28201 | CROSS BLOCK (LG) |
| 8 | 4 | 781-1-1224 | BALL BEARING DISC |
| 9 | 2 | NNK10-32 | 10-32 KEP NUT |
| 10 | 1 | 1996-0818 | ROD, STRAIGHT |
| 11 | 2 | 4012-03 | TENSION ROD HLDR |
| 12 | 3 | 23196 | ROD, STRAIGHT |
| 13 | 1 | 8732-0896 | 1/2 X 14 ROD |
| 14 | 2 | A-U | ROD CONNECTOR |
| 15 | 2 | SSSS98032 | SCREW, SOCKET SET 10-32 X 1/2 |
| 16 | 2 | 1996-161 | ROD, POINT ON END |

Parts List

1996-11B Fold Band Sub-Assembly

AAC Drawing Number 192119C Rev 3




1996-11B parts list

| NO | QTY | PART # | DESCRIPTION | NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|---|----|-----|------------|----------------------------------|
| 1 | 1 | AAC7DP-3 | CYL, AIR 3/4 | 34 | 8 | WWFS6 | WASHER, FLAT SAE |
| 2 | 1 | AAC8DP-3 | CYL, AIR 9/16 | 35 | 2 | WWL10 | WASHER, LOCK |
| 3 | 2 | AAFBP-8C | BRKT, PIVOT | 36 | 4 | SSPS90024 | SCREW, PAN HD SLOTTED 8-32 X 3/8 |
| 4 | 2 | BBAW-3Z | BEARING, ROD END | 37 | 2 | 1278-7055A | PROX SW, W/PLUG |
| 5 | 1 | BBAW-4 | ROD END, PRECISION | 38 | 1 | AAC8DP-.5 | CYL, AIR, DA |
| 6 | 2 | MM132-1202 | CAP, SQ END BLK | 39 | 1 | 1996-111 | WELDMT, FOLD ASSY |
| 7 | 2 | MM2X897 | BLOCK, PILLOW | 40 | 1 | 1996-1110 | BEARING BLK, BAND |
| 8 | 4 | NNH5/16-24 | NUT, HEX | 41 | 1 | 1996-1111 | BEARING SUPT, BAND |
| 9 | 2 | NNH6-32 | NUT, HEX | 42 | 1 | 1996-1112 | BRKT, CYL MT |
| 10 | 4 | NNK1/4-20 | NUT, KEP | 43 | 1 | 1996-124 | PLATE, BAND HOLD |
| 11 | 6 | NNK10-32 | NUT, KEP | 44 | 1 | 1996-1114 | SHAFT |
| 12 | 4 | NNH8-32 | #8-32 HEX NUT | 45 | 1 | 1996-1115A | BRKT, PROX SW |
| 13 | 3 | NNK6-32 | NUT, KEP | 46 | 1 | 1996-1116 | COVER, FIH ASSY |
| 14 | 4 | SSFC80024 | SCREW, FLAT ALLEN 6-32 X 3/8 | 47 | 1 | 1996-112 | LEVER, CYL ROD |
| 15 | 4 | WWF8 | #8 FLAT WASHER | 48 | 1 | 1996-113 | WELDMT, FOLD ASSY |
| 16 | 1 | SSHC01064 | SCREW, HEX CAP 1/4-20 X 1 | 49 | 1 | 1996-114 | WELDMT, UPPER FOLD |
| 17 | 2 | SSHC01160 | SCREW, HEX CAP 1/4-20 X 2 1/2 | 50 | 1 | 1996-115 | ANGLE, FOLD JAW ASSY |
| 18 | 4 | SSHC10112 | SCREW, HEX CAP 5/16-18 X 1 3/4 | 51 | 1 | 1996-116 | HINGE, FOLDER ASSY |
| 19 | 1 | SSSC01064 | SCREW, SOC CAP 1/4-20 X 1 | 52 | 2 | 1996-117 | BRKT, CYL ROD PIVOT |
| 20 | 2 | SSPS80016 | SCREW, PAN HD SLOT 6-32 X 1/4 | 53 | 1 | 1996-118 | JAW, BOTTOM FOLDER |
| 21 | 4 | SSPS80024 | SCREW, PAN HD SLOT 6-32 X 3/8 | 54 | 1 | 1996-119 | JAW, UPPER FOLDER |
| 22 | 4 | SSPP98032 | SCREW, BUTTON CAP 10-32 X 1/2 | 55 | 1 | NNJ1/4-20 | NUT, JAM |
| 23 | 4 | SSSC01048 | SCREW, SOCKET CAP 1/4-20 X 3/4 | 56 | 2 | AAQME-5-8 | QUICK MALE ELBOW |
| 24 | 1 | SSSC10064 | SCREW, SOCKET CAP 5/16-18 X 1 | 57 | 4 | AAQME-5-10 | QUICK MALE ELBOW |
| 25 | 2 | SSSC80024 | SCREW, SOCKET CAP 6-32 X 3/8 | 58 | 1 | CCCL3F | 3/16 CLAMP COLLAR |
| 26 | 7 | SSSC98048 | SCREW, SOCKET CVAP 10-32 X 3/4 | 59 | 2 | 1996-125 | PRESSURE TABS |
| 27 | 1 | SSSC98096 | SCREW, SOCKET CAP 10-32 X 1 1/2 | 60 | 4 | BBTRA411 | WASHER, THRUST |
| 28 | 2 | SSSC98112 | SCREW, SOCKET CAP 10-32 X 1 3/4 | 61 | 2 | BBNTA411 | BEARING, THRUST |
| 29 | 4 | WWL8 | #8 LOCK WASHER | 62 | 1 | 1278-6310 | MOUNT, CYLINDER |
| 30 | 4 | SSZS93032 | SCREW, SHT MTL 10-16 X 1/2 (SELF DRILL) | 63 | 1 | SSHC01080 | SCREW, HEX CAP 1/4-20 X 1-1/4 |
| 31 | 11 | WWFS1/4 | WASHER, FLAT | 64 | 2 | SSSC98024 | SCREW, SOC CAP 1/4-20 X 3/8 |
| 32 | 18 | WWFS10 | WASHER, SAE FLAT | 65 | 2 | 23154 | SPACER |
| 33 | 9 | WWFS/16 | WASHER, FLAT | | | | |

Parts List

3800P-002 Foot Switch Assembly


AAC Drawing Number 190638C Rev 7



| NO | QTY | PART # | DESCRIPTION |
|----|-----|------------|------------------------------|
| 1 | 3FT | MM6970T64 | 3/4" ABRASIVE TAPE |
| 2 | 0 | 3844P-119B | LABEL, FOOT-LIFT |
| 3 | 1 | NNK6-32 | KEP NUT |
| 4 | 4 | SSFC80016 | SCREW, FLAT ALLEN 6-32 X 1/4 |
| 5 | 1 | 1278-5051 | PLATE, FOOT PEDAL |
| 6 | 2 | 1278-6161 | FOOT PEDAL MOD. |
| 7 | 0 | 3844P-119A | LABEL, START-SEW |
| 8 | 1 | 3800P-C02 | CABLE, GEN |
| 9 | 1 | AAF3/8 | PLASTIC CLAMP |
| 10 | 1 | SSFC80024 | SCREW, FLAT ALLEN 6-32 X 3/8 |
| 11 | 4 | TT1818 | FEMALE QUICK SLIDE |

Parts List

1996B-PD Pneumatic Diagram



Warranty

Atlanta Attachment Company (AAC) Statement of Warranty

Manufactured Products

Atlanta Attachment Company warrants manufactured products to be free from defects in material and workmanship for a period of eight hundred (800) hours of operation or one hundred (100) days whichever comes first. Atlanta Attachment Company warrants all electrical components of the Serial Bus System to be free from defects in material or workmanship for a period of thirty-six (36) months.

Terms and Conditions:

- AAC Limited Warranty becomes effective on the date of shipment.
- AAC Warranty claims may be made by telephone, letter, fax, or e-mail. All verbal claims must be confirmed in writing.
- AAC reserves the right to require the return of all claimed defective parts with a completed warranty claim form.
- AAC will, at its option, repair or replace the defective machine and parts upon return to AAC.
- AAC reserves the right to make the final decision on all warranty coverage questions.
- AAC warranty periods as stated are for eight hundred (800) hours or one hundred (100) days whichever comes first.
- AAC guarantees satisfactory operation of the machines on the basis of generally accepted industry standards, contingent upon proper application, installation, and maintenance.
- AAC Limited Warranty may not be changed or modified and is not subject to any other warranty expressed or implied by any other agent, dealer, or distributor unless approved in writing by AAC in advance of any claim being filed.

What Is Covered

- Electrical components that are not included within the Serial Bus System that fail due to defects in material or workmanship, which are manufactured by AAC are covered for a period of eight hundred (800) hours.
- Mechanical parts or components that fail due to defects in material or workmanship, which are manufactured by AAC.
- Purchased items (sewing heads, motors, etc.) will be covered by the manufacturers (OEM) warranty.
- AAC will assist in the procurement and handling of the manufacturers (OEM) claim.

What Is Not Covered

- Parts that fail due to improper usage, lack of proper maintenance, lubrication and/or modification.
- Damages caused by; improper freight handling, accidents, fire, and issues resulting from unauthorized service and/or personnel, improper electrical, plumbing connections.
- Normal wear of machine and parts such as Conveyor belts, "O" rings, gauge parts, cutters, needles, etc.
- Machine adjustments related to sewing applications and/or general machine operation.
- Charges for field service.
- Loss of time, potential revenue, and/or profits.
- Personal injury and/or property damage resulting from the operation of this equipment.

Declaración de Garantía

Productos Manufacturados

Atlanta Attachment Company garantiza que los productos de fabricación son libres de defectos de material y de mano de obra durante un periodo de ochocientos (800) horas de operación o cien (100) días cual llegue primero. Atlanta Attachment Company garantiza que todos los componentes del Serial bus son libres de defectos de material y de mano de obra durante un periodo de treinta y seis (36) meses.

Términos y Condiciones:

- La Garantía Limitada de AAC entra en efecto el día de transporte.
- Reclamos de la Garantía de AAC pueden ser realizados por teléfono, carta, fax o correo electrónico. Todo reclamo verbal tiene que ser confirmado vía escrito.
- AAC reserva el derecho para exigir el retorno de cada pieza defectuosa con un formulario de reclamo de garantía.
- AAC va, según su criterio, reparar o reemplazar las máquinas o piezas defectuosas devueltas para AAC.
- AAC reserva el derecho para tomar la decisión final sobre toda cuestión de garantía.
- Las garantías de AAC tiene una validez de ochocientas (800) horas o cien (100) días cual llega primero.
- AAC garantiza la operación satisfactoria de sus máquinas en base de las normas aceptadas de la industria siempre y cuando se instale use y mantenga de forma apropiada.
- La garantía de AAC no puede ser cambiado o modificado y no está sujeto a cualquier otra garantía implicado por otro agente o distribuidor menos al menos que sea autorizado por AAC antes de cualquier reclamo.

Lo Que Está Garantizado

- Componentes eléctricos que no están incluidos dentro del sistema Serial Bus que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un período de ochocientas (800) horas.
- Componentes mecánicos que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un periodo de ochocientas (800) horas.
- Componentes comprados (Motores, Cabezales,) son protegidos debajo de la garantía del fabricante.
- AAC asistirá con el manejo de todo reclamo de garantía bajo la garantía del fabricante.

Lo Que No Está Garantizado

- Falla de repuestos a la raíz de uso incorrecto, falta de mantenimiento, lubricación o modificación.
- Daños ocurridos a raíz de mal transporte, accidentes, incendios o cualquier daño como resultado de servicio por personas no autorizados o instalaciones incorrectas de conexiones eléctricas o neumáticas.
- Desgaste normal de piezas como correas, anillos de goma, cuchillas, agujas, etc.
- Ajustes de la máquina en relación con las aplicaciones de costura y/o la operación en general de la máquina.
- Gastos de Reparaciones fuera de las instalaciones de AAC
- Pérdida de tiempo, ingresos potenciales, y/o ganancias.
- Daños personales y/o daños a la propiedad como resultado de la operación de este equipo.



Atlanta Attachment Company Inc.
362 Industrial Park Drive
Lawrenceville, GA 30046
Phone: +1 (770) 963-7369
www.atlatt.com

Printed in USA
Digital Version of this Manual Available at:
http://atlatt.com/tech_manuals.php