




Model 1390BA

Revision 0 Released October 10, 2023(wr)

Technical Manual & Parts Lists



Atlanta Attachment Company

362 Industrial Park Drive

Lawrenceville, GA 30046

770-963-7369 • www.atlatt.com

ATLANTA ATTACHMENT COMPANY, INC.

Confidential and Proprietary Information

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.

All materials contained herein are additionally protected by United States Copyright law and may not be used, disclosed, reproduced, distributed, published, or sold without the express written consent of Atlanta Attachment Company, which consent may be withheld in Atlanta Attachment Company's sole discretion. You may not alter or remove any copyright, trademark, or other notice from copies of these materials.

IMPORTANT

It is important to read and understand the information contained within this manual before attempting to operate the machine. Atlanta Attachment Co., Inc. shall not be held liable for damage resulting from misuse of the information presented within, and reserves the right to change the information contained within, without prior notification.

Contents

Important Safety Instruction	1
Liability	2
Safety Equipment on the Machines	3
Protective Eyewear	4
Important Notices.....	5
Maintenance	7
Repair	8
A Word to the End User.....	9
Safety Precautions.....	9
1. INSTALLATION	10
Component Identification	10
Machine Layout	11
A. Infeed End	11
B. Machine Controls	11
C. Alignment Area.....	11
D. Seal Area.....	11
E. Outfeed End.....	11
F. Optional:	11
Machine Specifications.....	11
Power Requirements.....	12
Physical Specs:.....	12
Pressure Gauge Settings:.....	12
Mattress Size Limitations:	12
Machine Safety.....	13
WARNING 1	14
WARNING 2	14
WARNING 3	14
Lockout/Tagout Program.....	15
2. OPERATION.....	16
Machine Start (Cold).....	16
Machine Start (Warm).....	16
Film Loading.....	17
Bottom Film Loading	17
Top Film Loading.....	18

Boot Film Loading	19
Film Routing.....	20
Film Splicing.....	21
Machine Controls	22
Main Screen.....	22
Piece Count.....	22
Manual.....	22
Manual 1.....	23
Manual 2.....	23
Manual 3.....	23
Manual 4.....	24
Manual 5.....	24
Manual 8.....	24
Manual 9.....	25
Manual 10.....	25
Manual 14.....	25
Setup.....	26
System Information	26
Security	26
Show All Settings	27
Advance Settings	27
Advanced Setup.....	29
VFD Drives	30
Advanced Manual Menu	32
Other Operator Controls	34
Light Tower Indicator.....	35
3. SERVICE.....	26
Motor Drives and Settings.....	26
Motor Drive Parameters.....	27
Seal Bar Maintenance and Replacement	28
Side Sealing Bars.....	30
Symptoms and adjustments of the cross-seal Bar	32
Cross Bar chain tension	33
Replacing silicone rubber padding:	33

Side Seal and Cross Seal Bladder Adjustments	34
Adjusting the Seal bar Pressure	35
Upper Seal Bar Element Replacement	37
Shimming the Seal Bar	42
Mattress Size Adjustments	43
Maintenance.....	43
Daily	43
Weekly	44
Monthly	44
Quarterly	44
Bi-Annually	44
Operator Shift Maintenance Charts	44
Technician Maintenance Charts	44
Lockout Procedure.....	51
Troubleshooting	52
Sensor Adjustments.....	53
Conveyor Connection for the 1390BA.....	54
Mattress Speed Cycle	55
Speed Cycle.....	55
4. ASSEMBLY DRAWINGS AND PARTS LISTS.....	56
11390BA Auto Pack 24-8	57
1390170 Tape Roller Handle Assembly	60
1390449 Top Boot Roll Holder Assembly	61
1390457 Lower Caster Mount.....	62
1390475 Bottom Boot Roll Holder Assembly	63
1390500 Lower Roll Holder Frame	64
13901331 PC HMI Assembly.....	65
13901390 Exit Assembly.....	66
13901279 Input Conveyor	90
13061105 Valve Assembly.....	92
1391054 Roll Holder Frame.....	93
1391056 Lower Roll Feed	95
1391057 Roller Take-up Assembly	96
1391269 Outfeed Pressure Roller	97

13901280 Input Conveyor Assembly # 4	98
1390BA-PD Pneumatic Diagram	139
1390BA-WD1 Wiring Diagram, Power	140
1390BA-WD2 Wiring Diagram, SBUS.....	141
1390BA-WD3 Wiring Diagram, Pause & E-Stop	142
1390BA-WD4 Wiring Diagram, Safety	143
5. TRAINING	140
Atlanta Attachment Company (AAC) Statement of Warranty	141
Manufactured Products.....	141
Terms and Conditions:.....	141
What Is Covered	141
What Is Not Covered	141
Productos Manufacturados.....	142
Términos y Condiciones:	142
Lo Que Está Garantizado	142
Lo Que No Está Garantizado.....	142

Important Safety Instruction



This part of the Instruction Material is provided for the safe use of your equipment. It contains important information to help work safely with the unit and describes the dangers inherent in machinery. Some of these dangers are obvious, while others are less evident.

Mandatory Information

All persons operating and/or working on the 1390B Auto pack should read and understand all parts of the Safety Instructions. This applies, in particular, for persons who only operate and/or work on the unit occasionally (e.g. for maintenance and repair). Persons who have difficulty reading must receive particularly thorough instruction.

Scope of the Instruction Material

- The Instruction Material comprises:
- Safety information
- Operator Instructions
- Electrical and Pneumatic diagrams

And may also include.

- A list of recommended spare parts
- Instruction Manual(s) for components made by other manufacturers
- The layout and installation diagram containing information for installation

Intended Use

Our machines are designed and built in line with the state of the art and the accepted safety rules. However, all machines may endanger the life and limb of their users and/or third parties and be damaged or cause damage to other property, particularly if they are operated incorrectly or used for purposes other than those specified in the Instruction Manual.

Exclusion of Misuse



Non-conforming uses include, for example, using the equipment for something other than it was designed for, as well as operation without duly installed safety equipment. The risk rests exclusively with the end user.

Conforming use of the machine includes compliance with the technical data, information, and regulations in all parts of the complete Instruction Material, as well as compliance with the maintenance regulations. All local safety and accident prevention regulations must also be observed.

Liability

The machine should only be operated when in perfect working order, with due regard for safety and the potential dangers, as well as in accordance with the Instruction Material. Faults and malfunctions capable of impairing safety should be remedied immediately. We cannot accept any liability for personal injury or property damage due to operator errors or non-compliance with the safety instructions contained in this booklet. The risk rests exclusively with the end user.

The Instruction Material should always be kept near the machine so that it is accessible to all concerned.

The local, general, statutory, and other binding regulations on accident prevention and environmental protection must also be observed in addition to the Instruction Material. The operating staff must be instructed accordingly. This obligation also includes the handling of dangerous substances and provision/use of personal protective equipment.

The Instruction Material should be supplemented by instructions, including supervisory and notification duties with due regard for special operational features, such as the organization of work, work sequences, the personnel deployed, etc.

The personnel's awareness of the dangers and compliance with the safety regulations should be checked at irregular intervals.

Choice and Qualification of Personnel

Ensure that work on the machine is only carried out by reliable persons who have been appropriately trained for such work - either within the company, by our field staff or at our office - and who have not only been duly appointed and authorized but are also fully familiar with the local regulations. Work on the machine should only be carried out by skilled personnel, under the management and supervision of a duly qualified engineer.

This not only applies when the machine is used for production, but also for special work associated with its operation (start-up and maintenance), especially when it concerns work on the hydraulic or electrical systems, as well as on the software/serial bus system.

Training

Everyone working on or with the machine should be duly trained and informed with regard to correct use of the safety equipment, the foreseeable dangers which may arise during operation of the machine and the safety precautions to be taken. In addition, the personnel should be instructed to check all safety mechanisms at regular intervals.

Responsibilities

Clearly define exactly who is responsible for operating, setting-up, servicing and repairing the machine. Define the responsibilities of the machine operator and authorize him to refuse any instructions by third parties if they run contrary to the machine's safety. This applies in particular for the operators of machines linked to other equipment. Persons receiving training of any kind may only work on or with the machine under the constant supervision of an experienced operator. Note the minimum age limits permitted by law.

A Word to the Operator

The greatest danger inherent in our machines: is that of fingers, hands or loose clothing being drawn into a machine by live, coasting, or rotating tools or assemblies or of being cut by sharp tools or burned by hot elements.

ALWAYS BE CONSCIOUS OF THESE DANGERS!

Safety Equipment on the Machines



All machines are delivered with safety equipment, which shall not be removed or bypassed during operation.

The correct functioning of safety equipment on machines and systems should be checked every day and before every new shift starts, after maintenance and repair work, when starting up for the first time and when restarting (e.g. after prolonged shutdowns).

If safety equipment has to be dismantled for setting-up, maintenance or repair work, such safety equipment shall be replaced and checked immediately upon completing the maintenance or repair work.

All protective mechanisms shall be fitted and fully operational whenever the machine is at a standstill or if it has been shut down for a longer period of time.

Damage

If any changes capable of impairing safety are observed in the machine or its mode of operation, such as malfunctions, faults or changes in the machine or tools, appropriate steps must be taken immediately, the machine switched off and a proper lockout tagout procedure followed. The machine should be examined for obvious damage and defects at least once per shift. Damage found shall be immediately remedied by a duly authorized person before resuming operation of machine.

The machine should only be operated when in perfect working order and when all protective mechanisms and safety equipment, such as detachable protective mechanisms, emergency STOP systems, etc. are in place and operational.

Faults or Errors

The machine must be switched off and all moving or rotating parts allowed to come to a standstill and secured against accidental restart before starting to remedy any faults or errors.


Signs on the Machine

Safety and danger signs on the machine should be observed and checked at regular intervals to ensure that they are complete and undamaged. They should be clearly visible and legible at all times.

Clothing, Jewelry, Protective Equipment

Long loose hair, loose-fitting clothes, gloves, and jewelry, including rings, should be avoided in order to avoid injuries due to being caught, drawn in and wound up inside the machine.

Protective Eyewear



Protective eyewear that has been tested by the local authorities should be worn whenever there is a possibility of loose or flying objects or particles such as when cleaning the machine with compressed air.

Tools

Always count the number of tools in your possession before starting work on the machine. This will allow you to check that no tools have been left behind inside the machine. Never leave a tool in the machine while working.

Oils, Lubricants, Chemicals

Note the applicable safety regulations for the product used.

No Smoking, Fire, Explosion Hazard

Smoking and open flame (e.g. welding work) should be prohibited in the production area due to the risk of fire and explosions.

Workplace

A clear working area without any obstructions whatsoever is essential for safe operation of the machine. The floor should be level and clean, without any waste.

The workplace should be well lit, either by the general lighting or by local lights.

Emergency STOP

The emergency STOP buttons bring all machine movements to a standstill. Make sure you know exactly where they are located and how they work. Try them out. Always ensure easy access to the nearest emergency STOP button while working on the machine.

First Aid

1. Keep calm even when injured.
2. Clear the operator from the danger zone. The decision of what to do and whether to seek additional assistance rests entirely with you, particularly if someone has been trapped.
3. Give First Aid. Special courses are offered by such organizations as the employers' liability insurance association. Your colleagues should be able to rely on you and vice versa.
4. Call an ambulance. Do you know the telephone numbers for the ambulance service, police, and fire service?

Important Notices

Reporting and Fighting Fires

Read the instructions posted in the factory with regard to reporting fires and the emergency exits. Make sure you know exactly where the fire extinguishers and sprinkler systems are located and how they are operated. Pass on the corresponding information to the firemen when they arrive. Ensure there are enough signs to avoid fire hazards.

The following fire extinguishers may be used:

- Dry powder extinguishers, ABC fire-extinguishing powder.
- Carbon dioxide fire extinguishers to DIN 14461 for electronic components. Great care must be exercised when using carbon dioxide fire extinguishers in confined, badly ventilated rooms (see DIN 14406 and 14270).

Isolate the machine from the power supply if a fire breaks out. Do not use water on burning electrical parts until it is absolutely certain that they have been completely disconnected from the power supply. Burning oils, lubricants, plastics, and coatings on the machine can give off gases and vapors that may be harmful to your health.

A qualified person should be consulted to repair the damage after a fire.

Electrical Power Supply



Before undertaking any maintenance or repair work on the machine, switch off the electrical power to the machine at the main source and secure it with a padlock so that it cannot be switched on again without authorization.

In practice, this may mean that the technician, electrician, and operator all attach their own padlock to the master switch simultaneously so that they can carry out their work safely. Locking extension plates should be available for multiple locks if required. The primary purpose for a lockout/tagout procedure is to protect workers from injury caused by unexpected energizing or start-up of equipment.

Energy sources (electrical/pneumatic/hydraulic, etc.) for the equipment shall be turned off or disconnected and the switches locked or labeled with a warning tag. It is the responsibility of the employer to establish control procedures. Follow lockout/tagout procedures before, setup and/or any service or maintenance work is performed, including lubrication, cleaning, or clearance of jams.

Caution: The machine is still not completely de-energized even when the master switch is off.

- Electricity - The machine is always isolated from the electrical power supply whenever the master switch has been switched off. However, this does not apply for the power supply in the control cabinet, nor for equipment that does not draw its power via the master switch.
- Pneumatic / hydraulic energy - Almost all our machines carry compressed air. In addition to switching off the master switch, the air supply must also be disconnected, and the machine checked to ensure it is depressurized before starting any work on the machine; otherwise the machine may execute uncontrolled movements.

Information

- Kinetic energy - Note that some motors or spindles, for example, may continue to run or coast run on after being switched off.
- Potential energy - Individual assemblies may need to be secured if necessary for repair work.

Delivery of the Machine/Packaging

Note any markings on the packaging, such as weights, lifting points and special information. Avoid temperature fluctuations. Condensation may damage the machine.

Transport Damage

The packaging and machine must immediately be examined for signs of damage in transit. Such damage must be reported to the shipper/transporter within the applicable time limits. Contact Atlanta Attachment Company and/or your transport insurer immediately, if signs of damage are visible. Never operate a damaged machine.

Interim Storage

If the machine has to be stored temporarily, it must be oiled or greased and stored in a dry place where it is protected from the weather in order to avoid damage. A corrosion-inhibiting coating should be applied if the machine has to be stored for a longer period of time and additional precautions taken to avoid corrosion.

Transporting the Machine

Disconnect the machine from all external connections and secure any loose assemblies or parts. Never step under a suspended load. When transporting the machine or assemblies in a crate, ensure that the ropes or arms of a forklift truck are positioned as close to the edge of the crate as possible. The center of gravity is not necessarily in the middle of the crate. Note the accident prevention regulations, safety instructions and local regulations governing transport of the machine and its assemblies.

Only use suitable transport vehicles, hoisting gear and load suspension devices that are in perfect working order and of adequate carrying capacity. Transport should only be entrusted to duly qualified personnel.

Never allow the straps to rest against the machine enclosure and never push or pull sensitive parts of the machine. Ensure that the load is always properly secured. Before or immediately after loading the machine, secure it properly and affix corresponding warnings.

All transport guards and lifting devices must be removed before the machine is started up again. Any parts that are to be removed for transport must be carefully refitted and secured before the machine is started up again.

Workplace Environment

Our machines are designed for use in enclosed rooms: Permissible ambient temperature approx. 5 - 40 °C (40 - 104 °F). Malfunctions of the control systems and uncontrolled machine movements may occur at temperatures outside this range.

Protect against climatic influences, such as electrostatic charges, lightning strikes, hail, storm damage, high humidity, salinity of the air in coastal regions.

Information

Protect against influences from the surroundings: no structure-borne vibrations, no grinding dust, or chemical vapors.

Protect against unauthorized access.

Ensure that the machine and accessories are set up in a stable position.

Ensure easy access for operation and maintenance (Instruction Manual and layout diagram); also verify that the floor is strong enough to carry the weight of the machine.

Local Regulations

Particular attention must be paid to local and statutory regulations, etc. when installing machines and the plant (e.g. with regard to the specified escape routes). Note the safety zones in relation to adjacent machines.

Maintenance

General Safety Instructions

The machine shall be switched off, come to a standstill, and be secured so that it cannot be switched on again inadvertently before starting any maintenance work whatsoever. Use proper lockout/tagout procedures to secure the machine against inadvertent startup.

Remove any oil, grease, dirt, and waste from the machine, particularly from the connections and screws, when starting the maintenance and/or repair work. Do not use any corrosive-cleaning agents. Use lint-free rags.

Retighten all screw connections that have to be loosened for the maintenance and repair work. Any safety mechanisms that have to be dismantled for setting-up, maintenance or repair purposes must be refitted and checked immediately after completing the work.

Maintenance, Care, Adjustment

The activities and intervals specified in the Instruction Manual for carrying out adjustments, maintenance and inspections must be observed, and parts replaced as specified.

All hydraulic and pneumatic lines should be examined for leaks, loose connections, rubbing and damage whenever the machine is serviced. Any defects found must be remedied immediately.

Waste, Disassembly, Disposal

Waste products should be cleared from the machine as soon as possible as not to create a fire hazard.

Ensure that fuels and operating lubricants, as well as replacement parts are disposed of in a safe and ecologically acceptable manner. Note the local regulations on pollution control.

When scrapping (disassembling) the machine and its assemblies, ensure that these materials are disposed of safely. Either commission a specialist company familiar with the local regulations or note the local regulations when disposing of these materials yourself. Materials should be sorted properly.

Repair

Replacement Parts

We cannot accept any liability whatsoever for damage due to the use of parts made by other manufacturers or due to unqualified repair or modification of the machine.

Repair, Electrical

The power supply must be switched off (master switch off) and secured so that it cannot be switched on again inadvertently before starting any work on live parts.

Those parts of the machine and plant on which inspection, maintenance or repair work is to be carried out must be isolated from the power supply, if specified. The isolated parts must first be checked to determine that they are truly de-energized before being grounded and short-circuited. Adjacent live parts must also be isolated.

The protective measures implemented (e.g. grounding resistance) must be tested before restarting the machine after all assembly or repair work on electric parts.

Signal generators (limit switches) and other electrical parts on the safety mechanisms must not be removed or bypassed. Only use original fuses or circuit overloads with the specified current rating. The machine must be switched off immediately if a fault develops in the electrical power supply.

The electrical equipment of our machines must be checked at regular intervals and any defects found must be remedied immediately.

If it is necessary to carry out work on live parts, a second person should be on hand to operate the emergency OFF switch or master switch with voltage release in the event of an emergency. The working area should be cordoned off and marked by a warning sign. Only use electrically insulated tools.

Ventilation/Hazardous Gases

It is the end user's responsibility to ensure adequate ventilation is provided to exhaust any and all noxious or hazardous gases that may be present in the working environment.

Hydraulic and Pneumatic Systems

Work on hydraulic or pneumatic equipment shall only be carried out by persons with training, knowledge, and experience of hydraulic systems. Pressure lines shall be depressurized before starting any repair work.

General Liability

Liability for machine damage and personal injury is extinguished completely if any unauthorized conversions or modifications are undertaken. The machine must not be modified, enlarged, or converted in any way capable of affecting safety without the manufacturer's prior approval.

Starting Machine Movements

Read the Instruction Manual carefully to establish which keys and functions start machine movements.

A Word to the End User

The end user has sole responsibility to enforce the use of safety procedures and guards on the machine. Any other safety devices or procedures due to local regulations should be retrofitted in accordance with these regulations and/or the EC Directive on the safety of machines.

Operator's position must always be readily accessible. Escape routes must always be kept clear and safety areas should be identified.

Safety Precautions

Safety should be a constant concern for everyone. Always be careful when working with this equipment. While normal safety precautions were taken in the design and manufacture of this equipment, there are some potential safety hazards.

Everyone involved with the operation and maintenance of this equipment should read and follow the instructions in this manual.

Operate the equipment only as stated in this manual. Incorrect use could cause damage to the equipment or personal injury.

It is the owner's responsibility to make certain that the operator reads and understands this manual before operating this equipment. It is also the owner's responsibility to make certain that the operator is a qualified and physically able individual, properly trained in the operation of this equipment.

Specific safety warning decals are located on the equipment near the immediate areas of potential hazards. These decals should not be removed or obliterated. Replace them if they become non-readable.

- ALWAYS keep safety shields and covers in place, except for servicing.
- ALWAYS operate equipment in daylight or with adequate working lights.
- Follow daily and weekly checklists, making sure hoses are tightly secured and bolts are tightened.
- ALWAYS watch and avoid holes or deep depressions.
- ALWAYS wear adequate eye protection when servicing the hydraulic system and battery.
- NEVER operate a poorly maintained machine.
- NEVER allow persons to operate this machine without proper instruction.
- NEVER put hands or feet under any part of the machine while it is running.
- NEVER attempt to make any adjustments or repairs to the machine while running. Repairs or maintenance should be performed by trained personnel only.
- NEVER work under the machine unless it is safely supported with stands, blocks or a hoist and blocks.
- NEVER touch hot parts of machine.

1. INSTALLATION

Component Identification




Figure 1

Installation

Machine Layout

Refer to Figure 1 on page 10.

A. Infeed End

1. Top Film Roll storage
2. Top Boot Roll support bar
3. Bottom Film Roll storage
4. Bottom Boot Roll support bar

B. Machine Controls

5. Touch Screen
6. Pause/Stop Cable
7. Side Doors
8. A Output Emergency Stops
8. B Input Emergency Stops

C. Alignment Area

- Right Side - Fixed
- Left Side - Adjustable

D. Seal Area

9. Cross Seal
 10. Right Side Seal – Fixed
 11. Left Side Seal – Adjustable
- Compression option (not shown.)

E. Outfeed End

F. Optional:

Overhead roll holder and hoist Option for loading the Top Film rolls.

Machine Specifications

Capacity & Production Specs.

Max. Width of Infeed	85”
Min. Width of Infeed	72”
Max Height under Pressure Roller:	21”
Roll capacity, top & bottom (12” dia)	4
Infeed/outfeed conveyor height (inch)	36.5
Overall height	103
Max Film width (inch)	120
Film width: Top (inch)	108
Film width: Bottom (inch)	100
Boot roll dia (inch)	10-12
Machine Weight (lbs.)	16,000
Shipping weight (lbs.)	18,000

Production Rate:

- 3.25 Queens/min. (without compression)
- 2.50 Queens/min. (with compression)

Installation

NOTE: The machine has 3 adjustable width settings. They are typically set to 84" for Cal-Kings, 80" for Queen, XL Full and Twin beds, and 76" for regular Full and Twin beds. If required, the width settings can be set to any three positions desired, within the 72"-85" range. There is an optional 4th setting available.

Power Requirements

Volts	208-240 Delta 3-phase 50/60 Hz
Amps	30A/Leg
Air Consumption in SCFM	35 SCFM
Air Pressure	80 Psi
Power and Air Connection	Left, Mid, Side

Physical Specs:

Infeed/Outfeed Conveyor Height	36"
Overall Dimensions	152"w X 240"l X 103"h
Overall Height w/ Hoist Option	13'
Weight (w/o Crane or Compression)	16000lbs
Max Film Width Top or Bottom	120"
Typical Film Width - Top (Up To 16in Bed Thk.)	112" w/o Compression 108" w/ Compression
Typical Film Width - Bottom	102"
Roll Capacity (Top & Bottom)	4 Rolls (12" Dia.)
Max. Left Side Boot Length	Boot Roll Dia. 10" Nom., 12" Max 36"
Max. Right Side Boot Length	30"

Pressure Gauge Settings:

Main Pressure	70-80psi
Film Roll Brake Pressure	5 -10psi
Input light Press. Roller (white PVC)	50psi
Output left Side Seal Pos. Cylinder	50psi

Mattress Size Limitations:

(With Raised Seal Bars / 118" top roll)

feed in 80" side.....	21" mattress height
feed in 84" side.....	19" mattress height

(w/o Raised Seal Bars / 118" top roll)

feed in 80" side.....	18" mattress height
feed in 84" side.....	16" mattress height

Machine Safety

The 1390BA Auto-Pack is large machine and has many powerful drives and mechanisms.

ANYONE assigned to operate and/or maintain this machine must be properly trained by an Atlanta Attachment technician, or a trained and qualified factory mechanic. Operation and/or maintenance of this machine by untrained personnel may result in a serious injury or even death.

ANYONE assigned to operate and/or maintain this machine, must read, understand, and follow the safety instructions and guidelines listed below mentioned in following pages.

ANYONE assigned to operate or maintain this machine **MUST READ AND BE FAMILIAR** with the location and operation of ALL operator machine controls, with particular emphasis on the following:

Main Electrical Power ON/OFF switch


Main Air Supply ON/OFF valve

Four Emergency-Stops, located on:

- Main Control Box
- Remote Operator Box
- Left Output post
- Right Output post

Machine STOPS include:

- The Input PULL CABLE STOP
- The main panel STOP push button
- The Remote Operator Panel STOP push button
- The two side Access Doors.



Installation

WARNING 1

In auto mode, this machine can start automatically at any time. Therefore, when the machine is turned on:

- NEVER ENTER INSIDE THE MACHINE
- NEVER CRAWL UNDER THE MACHINE
- NEVER CLIMB ON TOP OF THE MACHINE
- NEVER REACH INSIDE THE MACHINE FOR ANY REASON
- NEVER PLACE ANY PART OF YOUR BODY INSIDE THE MACHINE

WARNING 2

In manual mode, this machine may be prompted to execute any of its functions. Therefore, to prevent injury or machine damage, only a properly trained operator or mechanic should use the machine in this mode of operation.

WARNING 3

To perform any machine maintenance always follow steps below:

1. FIRST, POWER DOWN THE MACHINE AND LOCK-OUT THE ELECTRICAL AND THE PNEUMATIC POWER SOURCES.
2. WAIT UNTIL SEAL BARS COOL OFF SUFFICIENTLY (APROX. 3 HOURS) BEFORE SERVICING THE SEAL BARS OR THE NEARBY AREAS OF THE MACHINE.

NOTE: If machine maintenance is absolutely necessary before seal bars have sufficiently cooled off, a service person must wear OSHA approved safety gear to protect him/her from a potential burn.

Lockout/Tagout Program



"Lockout/Tagout (LOTO)" refers to specific practices and procedures to safeguard employees from the unexpected energization or startup of machinery and equipment, or the release of hazardous energy during service or maintenance activities. This requires that a designated individual turns off and disconnects the machinery or equipment from its energy source(s) before performing service or maintenance and that the authorized employee(s) either lock or tag the energy-isolating device(s) to prevent the release of hazardous energy and take steps to verify that the energy has been isolated effectively. The following references provide information about the LOTO process.

Equipment Energy Control Procedure Lockout/Tagout Program				
Description:		Auto Pack Workstation	Model:	1390BA
Manufacturer:		Atlanta Attachment Co.	Location	
Energy				
Location		Magnitude		Control Method
Electrical:		Disconnect/Ctrl Box	480V 3-Ph	Lockout & Tag
Pneumatic:		Main Regulator	90 PSI	Lockout & Tag
Gravity:		Cut bar Assy, presser belt Assy, Seal Bar assembly, Plastic Holder Clamp		
Remember to Release All Stored Energy!				
Shutdown Procedure:				
<ol style="list-style-type: none"> 1. Inform all affected personnel that the machine will be in Lockout status. 2. Turn the power and pneumatic disconnects to the OFF position. 3. Fill out the tag with necessary information of the Lockout. 4. Install the Lockout device. 5. Verify all stored electrical energy has been released by pressing the power on button . Also, use meter to test circuits in the electrical panel to insure stored energy is released there as well. Perform necessary maintenance, services and/or repairs. 				
Startup Procedure:				
<ol style="list-style-type: none"> 1. Inform all affected personnel that the Lockout of this machine is being removed. 2. Replace any guards or safety devices which may have been removed during maintenance. 3. Remove the Lockout device and tag. 4. Turn the power and pneumatic disconnects to the ON position. 5. Push the green button on the back of the control panel to turn the machine on. 6. Inform all affected personnel that the Lockout has been removed and that the machine is ready for normal production operation. 				

Approved By: _____

Date: _____

2. OPERATION

Machine Start (Cold)

1. Turn the Main On/Off switch to the ON position. See Fig. 3.
2. Turn the Main Air valve to the ON position. The pressure gauge should be set to 80 PSI. See Fig. 4.
3. Press the green POWER ON push button. See Fig. 5.

The Seal Bars begin to heat up at this point. It takes approx. 30 minutes to get the Seal Bars to their operating temperature.

Note: The Standard machine Temperature Settings are:

- Side Seal Bars - 325 °F (w/o boot film)
- Side Seal Bars - 345 °F (w/ boot film)
- Cross Seal Bar - 345 °F

Note: Under the normal machine conditions, the start screen will appear on the touch screen. When the green light on the light tower is on, the machine has reached operating temperature and is ready to run. If the green light does not illuminate, it usually indicates that one or more Emergency Stops are not reset, or other error condition exists. Refer to “Light Tower Indicator” on page 35 of this manual for further light tower color explanation.

4. Wait for all three Seal Bars to heat up to their preset temperatures. It will take approx. 20-30 minutes depending on the room temperature.

Note: The Seal Bars will not seal properly until they reach their proper temperature.

After a short delay (approx. 5 sec.) the INPUT belts will turn on. Machine is now ready for production.

5. Press the Start button on the touch screen. See Fig 6.

Machine Start (Warm)

1. Wait for all three Seal Bars to heat up to their preset temperatures. It will take approx. 20-30 minutes depending on the room temperature.

Note: The Seal Bars will not seal properly until they reach their proper temperature.

2. Press the Start button on the touch screen. See Fig 6.
After a short delay (approx. 5 sec.) the INPUT belts will turn on. Machine is now ready for production.

Note: If the machine does not start and you do not get an error message on the screen, refer to the LIGHT TOWER INDICATOR on page 35 of this manual for additional information.




Fig. 3



Fig. 4




Fig. 5




Fig. 6

Film Loading

Bottom Film Loading

The standard 1390BA machine comes with a pull-out Bottom Film Roll storage rack that can handle up to (3) 12” diameter x 120” long rolls of plastic film.

The Bottom Film Rack can be assembled two ways so it can be pulled out to the left or to the right of the machine for loading.

To load the rack:

1. Pull out the (2) locating/locking pins to (one on each side of the machine) unlock the rack from the rest of the machine.
2. Pull the rack out from under the machine far enough to load the rolls of film. Load three rolls using a standard forklift or other means.

Important note!

The film rolls must be loaded such that they unwind clockwise, looking from the left side of the machine (see “Film Routing” on page 20).

3. Roll the rack back under the machine and insert the locating/locking pins.

The Bottom Film Roll Rack assembly has two roll release rods which allow the operator to advance one roll of film at a time into the Bottom Film Roll Cradle. The release rods are extended to the right end of the rack, so the rolls can be advanced with the rack assembly locked in place.




Figure 8

Operation

Top Film Loading

The standard 1390BA machine comes with a Top Film Roll storage rack that can handle up to (4) 12” diameter x 120” long rolls of plastic film.

Important note! The film rolls must be loaded such that they unwind counterclockwise, looking from the left side of the machine (see “Film Routing” on page 20).

Besides the standard top film roll rack, Atlanta Attachment Company offers two options to aid in the loading and storage of the Top Film Rolls:

1. Crane option - For installations with a limited space on each side of the machine. The crane lifting mechanism can be swiveled 360 degrees from the shown position this allows any orientation of rolls on the floor next to the machine.
2. Extended Top Roll Rack option - For installations where the rolls can only be loaded from the Output End of the machine. This option allows loading of up to (18) 12” diameter rolls on top of the machine. The Extended Roll Rack option excludes the Crane option due to space limitations on top of the machine.

If the side space is not limited, an operator can load the Top Film using a standard forklift. The standard Top Film Roll Rack has (2) roll film release rods to allow the rolls to be advanced one at a time.




Figure 9

Operation

Boot Film Loading

The standard 1390BA machine comes with (4) Boot film Support Bars. See Figure 10. They are pivot mounted on a main support and each have a ratchet type mechanism. This design allows the operator to easily rotate the bar down to a lower, more ergonomic loading position. Once loaded, it is easy to rotate the boot roll into its working position. In addition, for more ergonomic loading, all boots load from outside - in. **Important note! All boot rolls must be loaded to unwind from the top of the roll.**

The right-side Boot bars will support rolls up to 12" diameter x 30" long. The Left Side Boot bars will support rolls up to 12" diameter x 36" long. Each Support Bar has two (Boot locating) collars. The inner collars are adjusted once during the initial installation and remain fixed thereafter. Their purpose is to properly locate the boot in reference to the corresponding Top or Bottom film edge. The outer collars are designed to prevent the boot roll from moving side to side. They have a ratchet type handle designed to lock the collar in place and to allow easy removal to remove and replace boot rolls. The outer collars should be clamped against the boot roll in such a way to allow the roll to rotate without much drag.




Figure 10

Operation

Film Splicing

1. When the plastic film runs out (from any roll), cut off the last 3 to 4 feet of it in order to eliminate any plastic that was adhered to the core and may have glue residue left on it. Make sure that there is no adhesive left on the film. If not removed, the adhesive will likely stick to the puller roller and wrap around causing a potential machine jam and/or machine component damage. In order to have enough film to make the splice, it may be necessary to reverse feed the roll being spliced. Before any reverse feeding top or bottom film rolls, one must feed the other film roll forward approximately the same amount.

2. Pull the emergency stop cord.

3. Use a handheld splicing tool (located in a cage on the back side of the main control box) to join the trailing edge of the old roll with the leading edge of the new roll. A specially designed splicing bar is mounted to the input end of the machine to aid the operator in holding film plies together and flat during the splicing process. This bar has (2) long angles mounted on it for guiding the sealing tool and for holding the film ends flat and in alignment.



4. Lift the two angles up and rest them against one another. Insert the old film's trailing edge (approx. 3 to 4 inches of it) under the angles. Clamp the corners using the round magnets at each end.

5. Pull enough plastic from the new roll and insert it under the angles on top of the old film.

6. Align the two edges and reuse the magnets to hold both corners together.

7. Lower the guide angles down and use the splicing tool to join the films. Press the tool wheel lightly against the ridge and slowly follow it to the other side. Repeat the same on the other side of the ridge on the way back.

8. Reset emergency switch by pulling the blue button.




Machine Controls

Note: It is recommended that the emergency stop and power on buttons be used for normal, everyday machine power up and power down needs. The main On/Off/Lockout switch should be used to turn the machine on or off during maintenance or other extended power down situations.


Main Screen

This is the main screen. From this screen you can start the machine, see the temperature of all three seal bars, and view the piece count. You can also access the setup, manual and piece count screens.



Piece Count


From this screen you can reset the piece count and/or the optional External count display.



Manual

Pressing the Manual button on the Main screen will display the Manual screens, which provides controls for top and bottom film (loading, unloading, tracking, pleat correction) as well as the infeed conveyor and cross sealing.

Pressing the individual buttons will allow quick control to specific features or by pressing the right and left arrows at the top of the main screen will toggle through all screens from Manual 1 through Manual 14.



Operation

Manual 1

Provides controls for the Infeed Conveyor.

Infeed Conveyor

← ADVANCED MANUAL 1 INFEED CONVEYOR →		
Error code 0	Load % 0	Modbus Retries 50
Clear Drive Error	Reverse -25.0 Hz	
Speed 1 Forward 25.0 Hz	Speed 2 Forward 20.0 Hz	
Speed 3 Forward 40.0 Hz	Speed 4 Forward 54.0 Hz	Gate Up
Reset	Language?	Exit

Manual 2

Provides controls for Infeed

Infeed

← ADVANCED MANUAL 2 INFEED →			
Left Matt Ready Eye	Center Matt Ready Eye	Right Matt Ready Eye	
Left Size Position 1			
Size Adjust Out	Size Adjust In	Top Roller Down	Top Roll Down Sensor
Left Pause	Air Jets	Gate Up	Right Pause
Reset	Language?	Exit	

Manual 3

Provides controls for the Top Film

Top Film Feed

← ADVANCED MANUAL 3 TOP FILM →		
Error code 0	Load % 0	Modbus Retries 240
Clear Drive Error	Reverse -20.0 Hz	Film Out
Speed 1 Forward 20.0 Hz	Speed 2 Forward 40.0 Hz	Slack Sensor 5
Speed 3 Forward 50.0 Hz	Speed 4 Forward 60.0 Hz	Film Low
Reset	Language?	Exit

Operation

Manual 4

Provides controls for the Bottom Film

Bottom Film Feed

← ADVANCED MANUAL 4 BOTTOM FILM →		
Error code 0	Load % 0	Modbus Retries 78
Clear Drive Error	Reverse -20.0 Hz	Film Out
Speed 1 Forward 20.0 Hz	Speed 2 Forward 46.9 Hz	Slack Sensor 1
Speed 3 Forward 56.0 Hz	Speed 4 Forward 60.0 Hz	Film Low
Reset	Language?	Exit

Manual 5

Provides controls for the Cross Seal

Cross Seal

← ADVANCED MANUAL 5 CROSS SEAL →		
Cross Seal Left Clear	Cross Seal Temp 80.6	Cross Seal Right Clear
Cross Seal Heat		
Cross Seal Down Sensor		
Cross Seal Down		
Reset	Language?	Exit

Manual 8

Provides controls for the Outfeed Conveyor

Outfeed Conveyor


← ADVANCED MANUAL 8 OUTFEED CONVEYOR →		
Error code 0	Load % 0	Modbus Retries 63
Clear Drive Error	Reverse -25.0 Hz	Outfeed Center Slow Eye
Speed 1 Forward 25.0 Hz	Speed 2 Forward 20.0 Hz	Outfeed Center Stop Eye
Speed 3 Forward 40.0 Hz	Speed 4 Forward 54.0 Hz	Outfeed Top Roller Down
Reset	Language?	Exit

Operation

Manual 9

Provides controls for the Outfeed Size Adjustments


Outfeed Sizing



Manual 10

Provides controls for the Side Seals


Side Seals



Manual 14

Provides controls for the System.

System



Operation


Setup

Pressing the Setup button on the Main screen will bring you to the Setup screen. From here you can access advanced settings, advanced setup, and advanced manual controls.


Note: When in the Advanced Manual screen, the heat to the seal bars is turned off.

Use extreme caution when in Advanced Manual mode.


Setup Screen – Operator Level



Setup Screen – Mechanic or higher level





System Information



Security

Raise or Lower Security from Operator level to Engineering level as required with input of code.



Operation

Show All Settings

Show All Settings

↓	1390BA_5_112 SN: 1000000000000 2023-09-06 08:03									
0	0	1	2	3	4	5	6	7	8	9
0		.00	.5	.35	.4	1.0	2.0	0	.10	1.35
10	1	.85	100	160	—	—	—	—	—	260
20	290	260	2.40	2.70	2.40	5	—	—	.01	1
30	.5	1	1.0	1.0	1.3	.5	1.0	.1	1.0	1.0
40	1.5	—	.5	1.0	1.0	1.0	70	6	8	0
50	0	0	—	—	—	0	.5	1.0	—	—
60	—	—	—	—	1	0	1	0	0	0
70	—	—	—	8.0	.24	—	—	—	—	—
80	—	—	—	—	—	—	—	—	—	—
90	—	—	—	—	—	—	—	—	—	—

Advance Settings

Access to Infeed, Film, Sealing and System.

Screens 1 through 6

Advanced Settings

Advanced Settings Menu

Infeed Film Seal 1

Seal 2 System

Reset Language? Exit

Infeed

Film

← ADVANCED SETTINGS 1 →

1. Infeed Size Squeeze Time	2. Infeed Conveyor Stop Delay	3. Infeed Top Roller Down Delay
- .00 +	- .5 +	- .35 +
4. Infeed Gate Up Delay	5. Infeed Air Jet On Delay	6. Infeed Air Jet On Time
- .4 +	- 1.0 +	- 2.0 +
7. Infeed Conveyor Timeout	8. Infeed Size Release Time	9. Outfeed Top Roller Down Delay
- 0 +	- .10 +	- 1.35 +

Reset Find? Exit Home

← ADVANCED SETTINGS 2 →

10. Film Feed Enable	11. Film Feed Start Delay	12. Top Film Slack Calibration
- 1 +	- .85 +	- 100 +
13. Bottom Film Slack Calibration		
- 160 +		

Reset Find? Exit Home

Operation

Advanced Settings Continued

Seal 1

← **ADVANCED SETTINGS 3** →

19. Left Seal Target Temperature	20. Cross Seal Target Temperature	21. Right Seal Target Temperature
- 260 +	- 290 +	- 260 +
22. Left Seal Dwell Time	23. Cross Seal Dwell Time	24. Right Seal Dwell Time
- 2.40 +	- 2.70 +	- 2.40 +
25. Temperature Max. Deviation		
- 5 +		

Reset Find? Exit Home

Seal 2

← **ADVANCED SETTINGS 4** →

28. Cross Seal Clear Time	29. Cross Seal Eyes Enable	30. Cross Seal Cool Time
- .01 +	- 1 +	- .5 +
36. Side Seal Down Delay		
- 1.0 +		

Reset Find? Exit Home

System





← **ADVANCED SETTINGS 6** →

46. Main Air Pressure Target	47. Outfeed Full Eye Time Out	48. Left Outfeed Size Offset
- 70 +	- 6 +	- 8 +
49. External Count Reset Security	50. Infeed External Run Mode	51. Outfeed External Input Mode
- 0 +	- 0 +	- 0 +

Reset Find? Exit Home

Advanced Setup

Access to Seal, Conveyor Setup, History, Cycles, Calibration, VFD Drives



Operation

VFD Drives

Provides access to drives that controls Infeed and Outfeed Conveyor, as well as Top and Bottom Film Feed

VFD Setup

Infeed Conveyor Top Film Feed Bottom Film Feed

Outfeed Conveyor

Save All Accel/Decel Changes

Reset Language? Exit Home

Infeed Conveyor

Infeed Conveyor VFD Setup

120. Infeed Speed1	121. Infeed Speed2	122. Infeed Speed3
- 25.0 +	- 20.0 +	- 40.0 +
123. Infeed Speed4	124. Infeed Reverse	125. Infeed Accel
- 54.0 +	- -25.0 +	- .8 +
126. Infeed Decel		
- .8 +		

Reset Language? Exit Home

Infeed Conveyor Running Test

VFD Enable	Live VFD Error Code	Load %
	0	0
Modbus Retries	First VFD Error Code	Fast Forward
71	0	
	Clear Error	Fast Reverse

Reset Language? Exit Home

Infeed Conveyor / VFD Pairing

Motor Nameplate Volts	Motor Nameplate Amps	Motor Nameplate KWatts
- 100 +	- 1.50 +	- .30 +
Motor Nameplate Power Factor	Motor Nameplate RPM	
- .60 +	- 1600 +	
Default Motor Ratings		Pair Infeed Conveyor Motor/VFD

Reset Language? Exit Home

Outfeed Conveyor

Outfeed Conveyor VFD Setup

150. Outfeed Speed1	151. Outfeed Speed2	152. Outfeed Speed3
- 25.0 +	- 20.0 +	- 40.0 +
153. Outfeed Speed4	154. Outfeed Reverse	155. Outfeed Accel
- 54.0 +	- -25.0 +	- .8 +
156. Outfeed Decel		
- .8 +		

Reset Find? Exit Home

Outfeed Conveyor Running Test


VFD Enable	Live VFD Error Code	Load %
	0	0
Modbus Retries	First VFD Error Code	Fast Forward
42	0	
	Clear Error	Fast Reverse

Reset Language? Exit Home

Outfeed Conveyor / VFD Pairing

Motor Nameplate Volts	Motor Nameplate Amps	Motor Nameplate KWatts
- 100 +	- 1.50 +	- .30 +
Motor Nameplate Power Factor	Motor Nameplate RPM	
- .60 +	- 1600 +	
Default Motor Ratings		Pair Outfeed Conveyor Motor/VFD

Reset Language? Exit Home



Top Film Feed

Top Film Feed VFD Setup

130. Top Film Speed1 - 20.0 +	131. Top Film Speed2 - 40.0 +	132. Top Film Speed3 - 50.0 +
133. Top Film Speed4 - 60.0 +	134. Top Film Reverse - -20.0 +	135. Top Film Accel - .4 +
136. Top Film Decel - 5 +		

Reset Find? Exit Home

Top Film Feed Running Test

VFD Enable	Live VFD Error Code 0	Load % 0
Modbus Retries 93	First VFD Error Code 0	Fast Forward
	Clear Error	Fast Reverse

Reset Language? Exit Home

Top Film Feed / VFD Pairing

Motor Nameplate Volts - 100 +	Motor Nameplate Amps - 1.50 +	Motor Nameplate Kwatts - .30 +
Motor Nameplate Power Factor - .60 +	Motor Nameplate RPM - 1600 +	
Default Motor Ratings		Pair Top Film Feed Motor/VFD

Reset Language? Exit Home

Bottom Film Feed

Bottom Film Feed VFD Setup

140. Bottom Film Speed1 - 20.0 +	141. Bottom Film Speed2 - 46.9 +	142. Bottom Film Speed3 - 56.0 +
143. Bottom Film Speed4 - 60.0 +	144. Bottom Film Reverse - -20.0 +	145. Bottom Film Accel - .4 +
146. Bottom Film Decel - 5 +		

Reset Find? Exit Home

Bottom Film Feed Running Test

VFD Enable	Live VFD Error Code 0	Load % 0
Modbus Retries 5	First VFD Error Code 0	Fast Forward
	Clear Error	Fast Reverse

Reset Language? Exit Home

Bottom Film Feed / VFD Pairing


Motor Nameplate Volts - 100 +	Motor Nameplate Amps - 1.50 +	Motor Nameplate Kwatts - .30 +
Motor Nameplate Power Factor - .60 +	Motor Nameplate RPM - 1600 +	
Default Motor Ratings		Pair Bottom Film Feed Motor/VFD

Reset Language? Exit Home

Operation

Advanced Manual Menu


Provides access to current status of Conveyors, Drives, Sealing, System, I/O and Safety Sensors.



← ADVANCED MANUAL 1 INFEED CONVEYOR →		
Error code 0	Load % 0	Modbus Retries 50
Clear Drive Error	Reverse -25.0 Hz	
Speed 1 Forward 25.0 Hz	Speed 2 Forward 20.0 Hz	
Speed 3 Forward 40.0 Hz	Speed 4 Forward 54.0 Hz	Gate Up
Reset	Language?	Exit

← ADVANCED MANUAL 2 INFEED →		
Left Matt Ready Eye	Center Matt Ready Eye	Right Matt Ready Eye
Left Size Position 1		
Size Adjust Out	Size Adjust In	Top Roller Down
Left Pause	Air Jets	Gate Up
Reset	Language?	Exit

← ADVANCED MANUAL 3 TOP FILM →		
Error code 0	Load % 0	Modbus Retries 240
Clear Drive Error	Reverse -20.0 Hz	Film Out
Speed 1 Forward 20.0 Hz	Speed 2 Forward 40.0 Hz	Slack Sensor 5
Speed 3 Forward 50.0 Hz	Speed 4 Forward 60.0 Hz	Film Low
Reset	Language?	Exit




← ADVANCED MANUAL 4 BOTTOM FILM →		
Error code 0	Load % 0	Modbus Retries 78
Clear Drive Error	Reverse -20.0 Hz	Film Out
Speed 1 Forward 20.0 Hz	Speed 2 Forward 46.9 Hz	Slack Sensor 1
Speed 3 Forward 56.0 Hz	Speed 4 Forward 60.0 Hz	Film Low
Reset	Language?	Exit

← ADVANCED MANUAL 5 CROSS SEAL →		
Cross Seal Left Clear	Cross Seal Temp 80.6	Cross Seal Right Clear
Cross Seal Heat		
Cross Seal Down Sensor		
Cross Seal Down		
Reset	Language?	Exit

← ADVANCED MANUAL 8 OUTFEED CONVEYOR →		
Error code 0	Load % 0	Modbus Retries 63
Clear Drive Error	Reverse -25.0 Hz	Outfeed Center Slow Eye
Speed 1 Forward 25.0 Hz	Speed 2 Forward 20.0 Hz	Outfeed Center Stop Eye
Speed 3 Forward 40.0 Hz	Speed 4 Forward 54.0 Hz	Outfeed Top Roller Down
Reset	Language?	Exit




Advanced Manual continued



Outfeed Sizing



Side Seals

System



External In / Out

Safety Sensors




Operation


Other Operator Controls

1. Emergency Stop & Power On -

allows the machine to be turned on and stopped.



2. **Stop Pull Cable** - stretched above the INPUT conveyor in the loading area, allows the operator to quickly stop the machine in case of any problems.



3. **Output Emergency Stops** - located on the output end of the machine. One e-stop is mounted on each end post for the operator convenience.



4. **Side Doors** - located on each side of the machine, allow the mechanic easy access to the SEALING AREA to correct any problems.

Note: Side Doors can be used to stop the machine if necessary.



Operation

Light Tower Indicator

The LIGHT TOWER is designed to help the operator/mechanic in machine operation and troubleshooting.

- **YELLOW LIGHT ON** means that the machine is out of the Top or the Bottom film. (Heaters On)
- **RED LIGHT ON** means that one or both side doors are open, or the Pull (red) Cable switch is activated. (Heaters On)
- **RED LIGHT FLASHING** means the seal bars are too hot.
- **GREEN LIGHT ON** means that the machine is ready to run. It comes on as soon as the POWER ON button is pressed, and there are no faults to prevent the machine from running.
- **GREEN LIGHT FLASHING** means the seal bars are heating up and have not yet reached operating temperature.



Note: To start the machine, the MACHINE START button on the touch screen may need to be pressed.

- **ALL LIGHTS OFF** means that one or more of the E-STOP buttons are pressed, or the Main Power is turned OFF, or otherwise disabled.

Note: If the above indications do not solve the problem, please refer to “Troubleshooting” section of this manual for additional help or call Atlanta Attachment Company’s service department at 770-963-7369.

3. SERVICE

Motor Drives and Settings

The 1390BA machine has four motor drives. The following images below show the physical drive locations. The table in the bottom right corner shows the drive machine parameters and their settings. These parameters may vary slightly based on the final installation requirements. To edit these drive parameters, refer to “Editing Motor Drive Parameters” on page 27. If the parameters have to be modified, record the new settings, and keep them with this manual for future reference.

Note: Do not change any of the other drive parameters, leave them as defaults.



Input Conveyor Drive




Output Conveyor Drive



Top Film Drive



Bottom Film Drive



Drive Controllers

Motor Drive Parameters

These are defaults according to the latest software version

When commissioning a machine, replacing a drive, or replacing a motor (with a different model), the user initiates the ‘pairing’ processes (via the Setup -> Advanced Setup -> VFD Setup menu). The user will be warned that this needs to be done when commissioning a machine or replacing a drive – but not when replacing a motor... As part of this processes, the user temporarily sets some settings to match the nameplate of the motor (volts, amps, rpm, etc). This data is used in the pairing process, but it is saved in the drive and is not a numbered/saved software setting

Setting name	Setting number	Default value
Infeed Speed 1	120	25.0 (Hz)
Infeed Speed 2	121	20.0 (Hz)
Infeed Speed 3	122	40.0 (Hz)
Infeed Speed 4	123	54.0 (Hz)
Infeed Reverse	124	(-) 25.0 (Hz)
Infeed Acceleration	125	0.8 (seconds)
Infeed Deceleration	126	0.8 (seconds)

Setting name	Setting number	Default value
Top Film Speed 1	130	20.0 (Hz)
Top Film Speed 2	131	40.0 (Hz)
Top Film Speed 3	132	50.0 (Hz)
Top Film Speed 4	133	60.0 (Hz)
Top Film Reverse	134	(-) 20.0 (Hz)
Top Film Acceleration	135	0.4 (seconds)
Top Film Deceleration	136	0.5 (seconds)


Setting name	Setting number	Default value
Bottom Film Speed 1	140	20.0 (Hz)
Bottom Film Speed 2	141	46.9 (Hz)
Bottom Film Speed 3	142	56.0 (Hz)
Bottom Film Speed 4	143	60.0 (Hz)
Bottom Film Reverse	144	(-) 20.0 (Hz)
Bottom Film Acceleration	145	0.4 (seconds)
Bottom Film Deceleration	146	0.5 (seconds)

Setting name	Setting number	Default value
Outfeed Speed 1	150	25.0 (Hz)
Outfeed Speed 2	151	20.0 (Hz)
Outfeed Speed 3	152	40.0 (Hz)
Outfeed Speed 4	153	54.0 (Hz)
Outfeed Reverse	154	(-) 25.0 (Hz)
Outfeed Acceleration	155	0.8 (seconds)
Outfeed Deceleration	156	0.8 (seconds)

Seal Bar Maintenance and Replacement

WARNING: Wait until the heat-sealing bar has cooled enough (approx. 3 hours) before servicing seal bars or the areas near the bars. If maintenance on the machine is absolutely necessary before sealing bars have had a chance to cool down, the person performing the maintenance must use safety equipment approved by OSHA or local law to protect against burns.

The unit has three (3) heat sealing bars. (a-cross seal), (b-right seal), and (c-left seal). The optimum temperature and the dwell settings depend on the type of plastic film being used, the thickness of the film, and the bag construction. For instance, if the requirement is for boot plastic only at one end of the bed, this means there are four plies of plastic on one side, but only two plies on the other side. Furthermore, the Cross Seal has to seal four plies on one end, and only two on the other. Due to the variations such as that, the dwell times and/or the temperature are fine-tuned during the machine installation. After Installation if the packaging variables ever change, the dwell time in most cases is the only correction needed for a proper weld.



Temperature Settings

Standard temperature settings of the heat-sealing bars are as follows:

Sealing Bar	Temperature ° F / ° C	Closing Time
Cross Seal No Boot	325 ° F / 162 ° C	170 a 200
Cross Seal W/Boot	345 ° F / 173 ° C	170 a 200
Right edge No Boot	325 ° F / 162 ° C	170 a 200
Right edge W/Boot	345 ° F / 173 ° C	170 a 200
Left edge No Boot	325 ° F / 162 ° C	170 a 200
Left edge W/Boot	345 ° F / 173 ° C	170 a 200

The left seal thermocouple is monitored by the # 59 module, the right seal is module # 5 and the cross seal is module # 52.

Seal power left, right, cross seal are controlled by module # 34.

There are four major variables for obtaining a good weld.

- 1. Temperature:** The value is set via the control panel. The degrees are expressed in Fahrenheit. Try not to alter the temperature settings as much as possible. A variation of 5 degrees in Fahrenheit temperature will change the clarity of welded materials. Always adjust the dwell time first.
- 2. Time:** The value is set via the control panel. Sealing time is expressed in 0.01 seconds, or 100 equals one second.
- 3. Pressure:** A value that is set by the stroke of the air cylinders from the factory. Unless you are changing the seal rail system height, leave settings as they are.
- 4. Condition of seal bars:** upper seal bars black coating is smooth with no cut or scraps and a dull finish. Lower seal bed smooth with not cuts and a shiny finish on tape.

Note: The Machine is configured to operate with two sheets of 3 mill plastic from the factory. If the thickness changes, you should only have to adjust the dwell. More Heat and pressure can create expensive problems later.

Explanation of chart written out below: 

(a) Temperature and Time Correct. The plastic appears melted with small bubbles and a connecting line between the bubbles. The solder is constant throughout.


(b) Excessive time or temperature. The melted plastic bubble appears irregularly, several of which are joined together and, in some cases, bundling between these portions.
The weld is not constant throughout.

(c) Lack of time or temperature. The plastic melted with small bubbles appear regularly without union between these parts.
The weld looks constant without proper seal.

Cleaning seal bars: for best performance, seal bars should be kept clean, clean whenever necessary with a soft cloth dampened with WD-40. Be very careful not to scratch or disturb the coating on the upper heat seal bar as this will cause sticking and film buildup and poor seal quality.

Very Important Note: *If you are having issues with a complete seal, (for example the rear), check for air movement around the machine. A large fan overhead near the 1390 can cool the seal bar enough to make you think you need to add heat or pressure to correct the problem. This is not always the best solution.*

Always be aware of your surroundings before changing any settings.



Side Sealing Bars

WARNING: Wait until the heat-sealing bar has cooled enough (approx. 3 hours) before servicing seal bars or the areas near the bars. If maintenance on the machine is absolutely necessary before sealing bars have had a chance to cool down, the person performing the maintenance must use safety equipment approved by OSHA or local law to protect against burns.

Refer to table on page **Error! Bookmark not defined.** for details

(A). - Welding is even and the depth of a weld's right.

The melted plastic appears with small bubbles and a connecting line between these bubbles. The weld is constant throughout.

(B). - Sealing bars are too deep


To set the depth of the shaft, loosen the nuts (a), (b) and rotate the cylinder shaft clockwise from top view on both cylinders which support the seal bars. Rotate the shaft ¼ turn at a time and test the quality of the seal between each setting.

(C). - Heat sealing bars Lack depth.

Adjust the height of the shaft, loosen the nuts (a), (b) and rotate cylinder shaft counterclockwise from top view on both cylinders which support the seal bars. Rotate the shaft ¼ turn at a time and test the quality of the seal between each setting.


(D). - Heat sealing bar is not parallel with the non-stick tape lengthwise.

Adjust the parallelism between the heat seal bar and nonstick ribbon by loosening the nut (a) or (b) and rotate the corresponding cylinder rod. Rotate the shaft ¼ turn at a time and test the quality of the seal between each setting.




(E). - Irregularity along the sealing

1. Make sure the sheet metal clamping the plastic film is at the correct height. The bar should be protruding to 0.050 inch (1.3mm) below the seal bars. To do this, loosen the screws (a) and (b) holding the pressure plate and lower it until the measurement is correct. Atlanta Attachment has a tool to facilitate this adjustment Part # 1390965 included in the kit of replacement parts.




2. Verify that the sealing bar is parallel with reference to the non-stick tape. Rest the cooled seal bar on the non-stick tape and place a square on the tabletop next to seal bar and check the distance between the top of the heat baffle (a) and the bottom (b). You should have equal reference to the square. Make sure that the sheet metal is on the rubber and not the metal lip of the bottom tray. You should have equal reference to the square. If not, go to alignment on page 31.



Note: Upper bar should always come into contact with tape and silicone cushion. At no time should any part of the upper seal bar contact the metal of the lower bar assembly.

Alignment (continued)

Loosen the four screws (a) and (b) securing the two bearings and slide up or down to meet the proper angle. Check after each adjustment. It is very likely need to adjust the height of the bar.




(F). - Random irregularities in the seals.

1. Check the non-stick tape on all three seal bars, tape should be smooth, clean, no air pockets and or crevices. Tape must be cleaned periodically and replaced as needed.
2. Inspect the silicone rubber backing under tape for cuts. If cut or damaged, replace silicone rubber cushion in that area as they are all glued together. After replacement follow the procedure for system realignment on page 34.
3. Check the upper sealing bars for damage, they should look black with a dull finish all along the bar. If any shinny areas are seen along the bar, it is damaged and needs replacement.

(G). - Irregularities constant seal.

1. Check the non-stick tape on all three seal bars, tape should be smooth, clean, no air pockets or crevices. Tape must be cleaned periodically and replaced as needed.
2. Inspect the silicone rubber backing under tape for cuts. If cut or damaged, replace silicone rubber cushion in that area as they are all glued together. After replacement follow the procedure for system realignment on page 34.
3. Check and see if shims under the support tray of non-stick tape are in place. Otherwise move them or insert new shims in that area.
4. Check the upper sealing bars for damage, they should look black with a dull finish all along the bar. If any shiny areas are seen along the bar, it is damaged and needs replacement.




Note: Upper bar should always come into contact with tape and silicone cushion. At no time should any part of the upper seal bar contact the metal of the lower bar assembly.

Symptoms and adjustments of the cross-seal Bar

(a) through (g) in the previous graph are types of heat-sealing problems that also apply to the cross-seal bar with the following additions:

(D). Bar-Gradient

Position cross seal bar to the height as pictured until you see the four bolts (C) & (D) in the chain guard opening. Loosen these bolts with a 7/16 wrench as well as the 30mm nut above the clevis on the cylinder where pressure needs to be added. Rotate the cylinder shaft counterclockwise from top view ¼ turn only, then tap the cylinder cycle button (1/10 sec) to jog cylinders. Tighten the four chain bolts with a 7/16 wrench and test seal. Repeat if needed, otherwise tighten nut above clevis to complete adjustment.




(E). - Stamped Irregularities in crossbar seal

1 Check the non-stick tape on all three seal bars, tape should be smooth, clean, no air pockets and or crevices. Tape must be cleaned periodically and replaced as needed.

2. Inspect the silicone rubber backing under tape for cuts. If cut or damaged, replace silicone rubber cushion in that area as they are all glued together. After replacement follow the procedure for system realignment on page 34.

3. Check and see if shims under the support tray of non-stick tape are in place. Otherwise move them or insert new shims in that area.

4. Check the upper sealing bars for damage, they should look black with a thin layer of carbon deposit along the bar. If any shiny areas are seen along the bar, it is damaged and needs replacement.



Replacement of Nonstick Tape

1. Make sure heat seal bars are in the up position.


2. Open the clamping system (a) peel back non-stick tape

3. Inspect the silicone rubber backing under tape for cuts. If cut or damaged, replace silicone rubber cushion in that area as they are all glued together. After replacement follow the procedure for system realignment on page 34.

4. Pull out enough new tape from the roll located in front of raised rail to cover silicone padding.

5. Align the tape and adhere to the silicone rubber and metal flanges of support tray.

6. Cut the excess tape and mount into the front clamping system. (A)



Replacement Tape here.

Cross Bar chain tension

Chains are responsible for parallel movement of the cross-seal bar.

To check tension and adjust if needed:




The chain (a) displacement is approximately 0.5 inches (12 mm) on center pressure is applied to the chain.

The adjusting tensioners (c) are located at the upper ends of the chain. Use a 9/16 wrench to loosen the two mounting bolts and adjust the tension. Retighten the mounting bolts.

Note: Tension should be checked every three months.



if light system. bolt.



Replacing silicone rubber padding:

WARNING: Wait until the heat-sealing bar has cooled enough (approx. 3 hours) before servicing seal bars or the areas near the bars. If maintenance on the machine is absolutely necessary before sealing bars have had a chance to cool down, the person performing the maintenance must use safety equipment approved by OSHA or local law to protect against burns.

With seal bar in the up position remove non-stick tape. Next remove the damaged silicone padding completely. Clean glue off with mineral spirit. **(DO NOT LOOSEN ANY OF THE SCREWS BENEATH THE SILICONE PADDING AS THIS WILL DISRUPT THE SEAL BAR LOWER RAIL ALIGNMENT!)**

Glue new padding to the rail. Secure PTFE tape and see shimming the seal bar on page **Error! Bookmark not defined.** after lower rubber replacement.




Side Seal and Cross Seal Bladder Adjustments

Reference parts 1406995 and 13901145

1406995 Cross Seal

Note: 10 – 15 psi is average setting



13901145 Side Seals

Note: 10 – 15 psi is average setting





Service

Adjusting the Seal bar Pressure

Note: For cross seal bar see symptoms and adjustment of cross seal bar.

WARNING: Wait until the heat-sealing bar has cooled enough (approx. 3 hours) before servicing seal bars or the areas near the bars. If maintenance on the machine is absolutely necessary before sealing bars have had a chance to cool down, the person performing the maintenance must use safety equipment approved by OSHA or local law to protect against burns.



Loosen nut above clevis on each cylinder rod and rotate rod cylinder counterclockwise $\frac{3}{4}$ turn. Take a sample set of plastic layers used in production and perform a seal. What we are trying to determine is a sealing pressure point. The object is to get the heated seal bar sealing the plastic evenly with as little force as possible.

Note: We are only adjusting the cylinder rods, not shimming.


Once you have example A, try to decrease pressure by a $\frac{1}{2}$ turn on both cylinders and see if you get example B.

If not, keep decreasing until you see example B. If so, then increase pressure $\frac{1}{2}$ turn and tighten the cylinder rod nuts and you are finished.

Example A



Example B




Upper Seal Bar Element Replacement


WARNING: Wait until the heat-sealing bar has cooled enough (approx. 3 hours) before servicing seal bars or the areas near the bars. If maintenance on the machine is absolutely necessary before sealing bars have had a chance to cool down, the person performing the maintenance must use safety equipment approved by OSHA or local law to protect against burns.

1) Turn Power supply off

2) Remove thermocouple wire.




3) Remove protective end plates from seal bar



4) Disconnect wire from both ends of heating element.



- 5) On the three tallest studs remove the top nut and back out the bottom nut to the end of stud without removing.




- 6) Remove all of the remaining nuts from shorter studs. This will allow the seal bar assembly to slide out pass stainless steel guards far enough for servicing.




Warning: It is imperative to lay out a large pad to protect parts being removed from this point on.

- 7) Using two closed end wrenches remove the nuts while leaving the bolts in place. **Be careful not to scratch any part of the coating on the seal bar assembly.** Note the order in which you remove the nuts because it is important that they are installed exactly in the same order.




- 8) Remove the Spacer bar (and Knife if applicable)

- 9) Remove damaged heating element.



10) On one end of the new heating element make a mark 3 ½” in from the tip with a sharpie. Starting with your mark begin inserting the heating element into the open slot of seal bar. Once in place, you should have 3 ½ “of extra heating element protruding from both ends of the seal bar.




Reverse steps 1 thru 10 to complete replacement with special attention to steps 7, 6, 5, & 4.

On step (7) torque each bolt to 7 in. lb. torque only!


On step (6) & (5) Push seal bar assembly up with one hand as you tighten the first set of nuts with the other hand. After all of the nuts are finger tight; use a wrench to turn each nut ¼ to a ½ turn to finish compression of nylon gasket. (**WARNING DO NOT TIGHTEN PAST ½ TURN!**)



Install the second nut on each shaft and lock it to the bottom nut using two wrenches. Use caution in this procedure making sure the bottom nut does not move from its set point.



(4) Bend heat element up approximately 30 degrees.



After replacement is complete refer to Adjusting the Seal bar Pressure on previous pages for final adjustments.

Shimming the Seal Bar

Note: For cross seal bar see symptoms and adjustment of cross seal bar; once adjustment is complete, move to #3 on this page 32.

Follow procedures for replacing Left and Right seal edge or heating element page.37.

After replacement, some very important steps are needed for the system to perform properly.

If you are inexperienced, It is always advisable to contact Atlanta Attachment service techs for detail procedures on setting up seal bar alignment, the next couple of steps are crucial to the machine's performance.

- 1) Setup test plastic as seen on right






- 2) Adjusting the Seal bar Pressure

Somewhere between Example A and B on page 29 is a good starting point for a new setup before moving on to shimming. Always make this adjustment **before** shimming.

- 3) Shimming rail system.


After test seal, shim the low points and record the value.



Keep repeating until you have a smooth seal. Then go back to Adjusting the Seal bar Pressure on page 35 and repeat this final adjustment to complete alignment of weld.

Mattress Size Adjustments

The 1390B machine is designed to automatically detect and adjust itself for one of the three basic bed lengths: 75", 80" and 84". To detect the bed length, the machine uses two arrays of three proximity sensors which are mounted on rectangular guide rails. One array is mounted on the left side of the Input frame, under the table, near the front of the machine (right illustration). The sensors detect the position of the (left) movable Input frame during the bed alignment and locating cycle. Depending on how many sensors are covered in this array, the machine controller determines how long the bed is and how far to move the adjustable Output Seal Bar frame assembly. This assembly uses the second array to get it positioned for the subsequent sealing process. The Output array is located near the left access door under the movable Seal bar frame (left illustration). It is adjusted to ensure that the opening between the two Side Seal bars is about 1" greater than the length of the bed detected in the Input end of the machine, to prevent bed jamming during the transfer from Input to the Output side of the machine.



Before this machine is shipped, it is adjusted and tested according to the customer bed specifications and should not need to be readjusted. If the parameters of the bed change after installation and it is necessary to readjust these arrays, it is very easy to do so. Simply loosen the screw that clamps the proximity sensor mounting block and move in the desired direction. If you want to be able to detect a smaller bed in the Input, move the sensor toward the center of the machine and vice versa. It works the same way if you want to stop the adjustable Output Seal bar frame.

Maintenance

Under normal operating circumstances, the 1390B machine does not require much maintenance. The following list outlines the normal machine maintenance that should be performed on periodic bases to keep the machine in a good working order:

Daily

Clean the three Seal bars at least once a day, preferably at the beginning of the first shift, before the seal bars begin to heat up. To clean the Seal bars, use a soft cloth and WD-40 as the solvent. Use extra caution and make sure Seal bars are not hot or heating up before cleaning. Also, use extra care not to scratch the Seal bar's anti-stick coating. If the coating surface is scratched to the bare metal, the plastic film may stick to it, which in turn may result in poor seal quality and /or machine down time.

Visually inspect PTFE tape (covering the lower seal bars) for any cuts and delaminating from the lower seal bar. If necessary, replace the tape.

During machine operation, listen for any unusual noises and watch for any uncommon machine behavior For example: jerky cross seal bar up/down movement, squeaky belt drive, etc.

Service

Clean the machine and remove any plastic film scraps or other debris. They may cause mechanism to jam and potentially fail.

Weekly

Check the main air supply filter for any accumulation of oil or debris. Empty the filter bowl before it is filled to the maximum level indicated on the side of the bowl.

Check the smoothness of the up/down movement of the Cross Seal Bar. If the bar chatters at all or does not move smooth, wipe the rods clean and apply a coat of sewing head oil to keep the rods lightly lubricated. This will improve the performance and extend the life of the bearing and keep the shafts from rusting. If the condition persists after application of the lubricant, check the tension and alignment of the two synchronizing chains. Also check the condition of the Cross Seal Guide rods for any unusual wear.

Monthly

Check the chain tension on all four motor drives. Adjust as needed.

Check the tension of the input and output belts. Adjust as needed.

Quarterly

Check the conveyor bearings and other pivot bearings and lubricate using PTFE based grease.

Check the condition of the Seal bar tape and the silicone rubber cushion below it for any through cuts particularly in the area where the hot knife cuts through the plastic. If the PTFE tape or cushion or both is cut or damaged, the whole setup must be replaced.

Bi-Annually







Replace the air supply filter element.


Operator Shift Maintenance Charts







Two(2) Printable Sheets





Technician Maintenance Charts







Four(4) Printable Sheets



<p>Frequency</p> <p>START MID END</p>	 <p>START</p>	<p>2. Check to see if the light tower indicator is working properly.</p>	 <p>START MID</p>	<p>5. Inspect seal bars for any damage, cracks and wear. See note at end on seal bars</p>
<p>1390B Auto Pack</p>	 <p>START</p>	<p>1. A Check the alignment of the belts. Make sure they are tracking properly.</p>	 <p>START MID</p>	<p>4. Check PTFE tape on lower three seal bars. Tape should be smooth no tears or cracking.</p>
<p>Preventative Maintenance (Shift Schedule)</p>	 <p>START</p>	<p>1. Check all conveyor belts for cracks, tears, rips, check seams and tension.</p>	 <p>START</p>	<p>3. Check for unusual noises and or air leaks. Alert a technician if any.</p>

<div style="display: flex; justify-content: space-between; align-items: center;"> Frequency <div style="display: flex; align-items: center;"> START MID END </div> </div>				
<p>1390B Auto Pack</p>	<p>Upper seal bars have a coating and the Lower Seal bars are made of PTFE which is a non-stick material. Use extreme caution when inspecting seal bars . If everything looks perfect DO NOTHING. If this material is scratched or torn in any way it could cause buildup on the seal bar. If this happens, a clean thick rag with WD-40 sprayed on it needs to be wipe on the seal bar to keep it clean. By doing this it will prevent buildup and burn through.</p>			
<p>Preventative Maintenance (Shift Schedule)</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;"> <p style="color: red; font-weight: bold; margin-top: 0;">START</p> <p>6. Check air system for moisture</p> </div> </div>			

<p>Frequency</p> <p>DAY WEEK MONTH</p>	 <p>WEEK</p>	<p>3. Check to see that Light tower functions properly.</p>
<p>1390B Auto Pack</p>	 <p>WEEK</p>	<p>2. General cleaning of the machine.</p>
<p>Preventative Maintenance (Mechanic schedule)</p>	 <p>WEEK</p>	<p>1. Check for unusual noises and or air leaks.</p>
 <p>WEEK</p>	<p>6. Check and clean photo eyes and reflective tape in infed area. Replace tape if damaged.</p>	
 <p>WEEK</p>	<p>5. Check air filter and replace as needed.</p>	
 <p>WEEK</p>	<p>4. Check screen operation, Recalibrate only if having issues. Procedure in owners manual.</p>	

Frequency	DAY	WEEK	MONTH
<p>Preventative Maintenance (Mechanic schedule)</p>		<p>WEEK</p>	<p>6.a. Check photo eye and reflective tape under infeed. Replace tape if damaged.</p>
<p>1390B Auto Pack</p>		<p>WEEK</p>	<p>6.b. Clean photo eye and reflective tape (outfeed) . Replace tape if damaged.</p>
<p>VERY Important Message: Upper seal bars have a coating and the Lower Seal bars are made of PTFE which is a non-stick material. Use extreme caution when inspecting seal bars . If everything looks perfect DO NOTHING. If this material is scratched or torn in any way it could cause buildup on the seal bar. If this happens, a clean thick rag with WD-40 sprayed on it needs to be wipe on the seal bar to keep it clean. By doing this it will prevent buildup and burn through.</p>	<p>caution</p>	<p>Never reuse cleaning rags in this procedure. Always discard after cleaning!</p>	<p>8. Clean cross seal bar cylinders and lubricate. Do not touch cylinders with bare hands.</p>
<p>Frequency</p>		<p>WEEK</p>	<p>7. Check PTFE tape on lower seal bars. Tape should be smooth w/ o tears or cracks.</p>
<p>Most importantly is where the seal bar knife presses down on the PTFE tape. If the tape is cut , check the silicone rubber cushion underneath the tape for cuts or damage. If damaged it is possible to flip over the cushion and use the bottom side. If damage is too severe , switch the top cushion with the bottom one.</p>	<p>caution</p>		<p>WEEK</p>

<p>Frequency</p> <p>DAY WEEK MONTH</p>	 <p>MONTH</p>	<p>10. a. Check the alignment of the belts. Make sure they are tracking properly.</p>	 <p>WEEK</p>	<p>12. Check all bearings and lubricate.</p>
<p>1390B Auto Pack</p>	 <p>MONTH</p>	<p>10. Check all conveyor belts for cracks, tears, rips, check seams and tension.</p>	 <p>WEEK</p>	<p>11. Check conveyor belt bearings and lubricate w/ PTFE based grease.</p>
<p>Preventative Maintenance (Mechanic schedule)</p>	 <p>WEEK</p>	<p>9. Clean seal bar guides and lubricate. Do not touch with bare hands.</p>	 <p>MONTH</p>	<p>10. b. Check tension on both the infeed and outfeed belts. Adjust as needed.</p>

<p>Frequency</p>				
<p>1390B Auto Pack</p>				
<p>Preventative Maintenance (Mechanic schedule)</p>		<p>13. Check chain tension on drive motors. 3 in infeed section and 1 under outfeed.</p>		

Lockout Procedure

Make sure all seal bar cylinders are in the desired position (up or down). It is necessary to observe the position of these cylinders. When the main air is turned off to the machine, the cylinders are pneumatically locked in the position they are at that moment.

Turn off the main air lockout valve and let the airlines and the air tank bleed-off completely.

Install a lockout padlock in the air lockout valve.

Turn off the main electrical switch and lock it out.

Wait until all seal bars cool off sufficiently before attempting to work near any of the seal bars.

Note: Do not lock seal bars in the down position if they are hot.

See page 15 for printable sheet on procedure.

Troubleshooting

Machine does not power up when the Power ON button is pressed.

1. Check to make sure all four Emergency Stops are pulled out and operational.
2. Check for a short circuit. Turn off all breakers and turn the machine back ON. If it comes ON, switch ON one breaker at a time.

The Input Conveyor belts turn in reverse upon machine startup before the bed is loaded on the input conveyor.

1. All three eyes bed Alignment Eyes are covered (dark) upon machine startup. Check, and if necessary, adjust the sensitivity screw. The Red led should blink 3 times /sec.
2. If sensitivity is ok but the problem persists, check the dark/light operate mode (white) screw, all three eyes should be set to light operate (turned clockwise).
3. If the eyes appear to be set correctly but the problem still exists, replace one eye at a time. Make sure to adjust as the new eye as described above.

The Input Conveyor belts turn in reverse once the bed is loaded and aligned.

1. None of the three size detecting proximity sensors were covered during the alignment phase. Adjust the left most proximity sensor in the input array and reload the bed. Repeat this procedure until the problem is solved.

The Input aligns and positions the bed properly and does not continue. The left output frame does not adjust for size.

1. The Customer conveyor eye is blocked (dark). The Red LED is not on. Adjust the eye sensitivity and make sure the Eye mode is set to Dark Operate (Counter-clockwise)
2. If problem persists, replace the eye (adjust as described)

The bed transfers to the Output area for sealing; the Cross Seal begins to go down but goes back up before cross sealing.

1. The cross-seal eye is too sensitive or adjusted too far toward the Input end of the machine. Adjust the pot on the amplifier to reduce the sensitivity some, but no less than 5 on the scale. If problem persists, realign the cross-seal sensor.

The bed climbs or hits the bottom left seal bar.

1. Adjust the location of the corresponding bed size proximity sensor on the output array.

The Side or Cross Seal is spotty in appearance.

1. Check the quality of the Teflon tape on the lower seal bar. Check the silicone rubber tape backing for cuts.
2. Adjust the Air Cylinder rod ends, out ¼ turn at a time, to lower the seal bar. Test the seal quality between every adjustment.

The seal is good in appearance but weak.

1. Adjust the seal bar Temperature, and/or dwell time (do not exceed 30).

Input aligns and positions the bed, and the left sizing plate retracts, but the bed does not move.

1. Check to make sure that a bed or another object is not covering the Customer Conveyor Eye.
2. If the eye is unobstructed, check the eye to make sure it is set and working properly. Note: this is the only eye on the machine that must be set to the Dark Operate mode of operation; all other eyes are set to Light Operate mode.


Machine continues to run even after the film (top or bottom) has run out.

1. Check to make sure that the Film run-out Eye for the corresponding film is set and working properly.

Sensor Adjustments

Proximity Switch

All proximity switches used on the 1390B machine have 8mm sensing range. The distance between the end of the sensor and the target flag should be set at about 5/32" for best performance.



Cross Seal Photo Detector

The amplifier sensitivity for the Cross Seal bar is located in the bottom-right corner of the main control box. It is factory set to the maximum setting of 10 (on the adjustment knob). It can be adjusted down if a false detection of the trailing edge of the mattress occurs often. The false detection usually results in an incomplete downward movement of the Cross Seal bar.

in the





Photo Eye

All retro-reflective photo eyes on the 1390B machine are set to Light operated mode (except the "Custom Conveyor Full Eye" which is set to the dark operated mode).

operated mode (except the



Conveyor Connection for the 1390BA

Customer's infeed conveyor

There are 2 types of connections to connect a conveyor to the infeed.

- Module 17, channel 1 is for connecting a relay for an external infeed conveyor to the 1390BA.
- Module 19, channel 1 is for connecting a PLC for an external infeed conveyor to the 1390BA.

Using one of the two options will synchronize the external conveyor with the infeed-belt of the 1390BA.

Customer's outfeed conveyor

There are 2 options to connect an external outfeed conveyor to the 1390BA.

- Module 16, channel 2 is for connecting a 24-volt eye/sensor. This eye/sensor can be placed anywhere in the customer's conveyor. As long as this eye/sensor is blocked the 1390BA will not unload a mattress. (**Setting #8 in "Advanced Settings" need to be set**)
- Module 18, channel 2 is for a signal from the customer's PLC to stop unloading the 1390BA. (**Setting #12 in "Advanced Settings" need to be set**)

Installation

To make a connection to one of the modules use 22-gauge wire.

The part numbers for the plugs used for the modules/wire connection are:

- 2 pin connector FF100F2202
- 2 pin cover FFSC10002
- 3 pin connector FF100F2203
- 3 pin cover FFSC10003

A special crimping tool is recommended for the connectors. (AAC part #: MMIT-100F)

****** Always use a current wire diagram for wire connection information ******

Mattress Speed Cycle

	Machine in pause mode	Machine waiting for mattress	Infeed middle eye covered/ Mattress positioning	Mattress sizing	Mattress feed through cross-seal	Infeed center eye uncovered/ Mattress positioning	Cross sealing	Mattress moves to 1st wobble switch	Mattress covers 1st wobble switch	Mattress covers 2nd wobble switch	Side sealing	Unloading mattress
Speed 4												
Speed 3												
Speed 2												
Speed 1												
Speed 0												

Speed Cycle

	Infeed	Top Film	Bottom Film	Outfeed
Speed 1	Only used in manual	Depends on position of dancer-bar speed 1, 2, 3 or 4	Depends on position of dancer-bar speed 1, 2, 3 or 4	Only used in manual
Speed 2	Position speed			Position speed
Speed 3	Mattress through cross seal speed			Mattress through cross seal speed
Speed 4	Ready for receiving mattress			Outfeed Mattress (full speed)

4. ASSEMBLY DRAWINGS AND PARTS LISTS

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.







One-Stop Shopping
For Expendable Replacement Parts for AAC & Other Bedding Equipment Suppliers
Toll Free: **1-866-885-5100**
www.atlantapartsdepot.com • sales@atlantapartsdepot.com

Parts

11390BA Auto Pack 24-8

AAC Drawing Number 9009108 Rev 1






11390BA parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	*1	1390-LAB1	LABEL,DANGER,VOLTAGE,	24	*1	13901307	ELECTRICAL KIT, CABLES
2	*2	1390-LAB2	LABEL, DANGER, HOT SURFACE 1390A	25	1	13901331	PC HMI MOUNT ASSEMBLY KIT
3	*8	1390-LAB3	LABEL, WARNING, START AUTO KEEP AWAY,	26	1	13901390	EXIT ASSEMBLY, AUTO-PAK
4	*2	1390-LAB4	LABEL, IMPORTANT, YELLOW 1390A	27	1	EEJBC375CG	GATEWAY PC, W-PWR CBL, SERIAL
5	*1	1390-LAB5	LABEL, FILM ROUTING	28	*1	LIGHT TOWER	LABEL, LIGHT TOWER
6	*4	1390-LAB7	LABEL, CAUTION, YELLOW	29	3	MMSG1305	TAPE, TEX PTFE, 3.4W X 54"L, 6 MIL
7	*4	1390-LAB8	LABEL, PRECAUTION, SPANISH YELLOW, 1390A	30	4	NNH7/8-9	7/8-9 HEX NUT
8	*4	1390-LAB13	LABELS, CAUTION, NVR CLIMB LAS	31	27	SSBC98048	10-32 X 3/4 BUTION CAP SC
9	*2	1390-LAB14	LABELS, CAUTION, LONG LASER EN	32	1	SSFC90064	10-32 x 2 FLAT ALLEN
10	*4	1390-LAB16	LABELS, CAUTION, BIG, BLK/YL L	33	4	SSHC10064	5/16-18 X 1 HHCS
11	1	1390KIT06	GUARD AND STIFFENER KIT	34	8	SSHC25064	3/8-16 X 1,HEX CAP
12	1 AR	1390170	HANDLE ASBLY, TAPE ROLLER	35	4	SSHC25080	3/8-16X1-1/4 HHCS
13	1 AR	1390449	TOP BOOT ROLL HLDR ASY	36	8	SSHC45112	1/2-13 X 1-3/4 HHCS, G8
14	1	1390457	MOUNT,LOWER CASTER	37	4	SSHC49192	7/8-9 X 3 HEX CAP
15	1 AR	1390475	BOTTOM BOOT ROLL HLDR ASY	38	8	WWF10	WASHER, FLAT, #10, COM
16	1	1390500	ROLL HOLDER FRAME, LOWER	39	8	WWFS1/2	WASHER,FLAT,1/2, SAE
17	1 AR	1390788	GUARD, EXIT END	40	13	WWFS3/8	WASHER,FLAT,SAE,3/8
18	2	1391923	ANGLE,SHIPPING	41	4	WWFS5/16	WASHER,FLAT,SAE,5/16
19	2	1394000	SHIPPING BRACKET 1	42	21	WWFS10	WASHER, FLAT, #10, SAE
20	4	1394284	SHIPPING BRACKET 2	43	8	WWL1/2	1/2 LOCK WASHER
21	4	1394285	SHIPPING BRACKET 3	44	12	WWL3/8	WASHER,LOCK, 3/8
22	1	13901279	INPUT CONVEYOR	45	4	WWL5/16	WASHER,LOCK, 5/16
23	1	13901289	LEXAN GUARDS	46	28	WWL10	WASHER,LOCK,#10

Parts

1390170 Tape Roller Handle Assembly

AAC Drawing Number 1390170 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	1	1390520	ROLLER,TAPE REMOVING
2	1	MM78005T44	Telescoping Pole-6'-18'

Parts

1390449 Top Boot Roll Holder Assembly

AAC Drawing Number 1390449 Rev 4




NO	QTY	PART #	DESCRIPTION
1	1	1390014	WELDMENT,ROLLER BAR
2	1	1390444	PIVOT BAR ASSY, UPPER
3	2	1390448	SADDLE ASSY
4	2	1390502	CLAMP,SPRING, 5/8B
5	1	1390506	WLDMNT, ROLLERBAR
6	2	1390509	SLOT COVER
7	2	1390510	DOWEL PIN, 1/2 X 2 15/16
8	1	1390892	RATCHET DOG, LEFT
9	1	1390893	RATCHET DOG, RIGHT
10	2	CCCL10F	CLAMP COLLAR- 5/8 ID
11	4	CCSC2-9-16	SHAFT COLLAR, SET 2-9/16"
12	1	RRLT085N4L	SPRING,TORSION,.085 WIRE, LEFT
13	1	RRLT085N4R	SPRING,TORSION, MOD
14	4	SSAS020016	SHOULDER BOLT 1/4 X 1/4L
15	4	SSBC98032	10-32 X 1/2 BUTTON CAP SC
16	4	SSHHC25080	3/8-16 X 1-1/4 HHCS
17	2	SSSC90032	#8-32 X 1/2 SOC CAP SC
18	4	TTH6271K450	ADJUSTABLE HANDLE 1/2-13x

Parts

1390457 Lower Caster Mount

AAC Drawing Number 1390457 Rev 1




NO.	QTY	PART #	DESCRIPTION
1	1	1390658	REAR CASTER MTG FRAME
2	2	1390692	LOCATING PIN ASSY,
3	1	1390736	MTG ARM, CASTER FRAME-LH
4	1	1390738	MTG ARM, CASTER FRAME- RH
5	1	1390819	GLIDE PIVOT WELDMENT
6	1	CCCL12F	CLAMP COLLAR- 3/4
7	1	MM2419T31	WHEEL, 4"OD X 2"W X 3/4 B
8	2	SSHC10064	5/16-18 X 1 HHCS
9	4	SSHC45064	1/2-13X1 HEX CAP
10	2	SSHC98032	10-32X1/2 HEX HD
11	4	WWFS1/2	WASHER,FLAT,SAE,1/2
12	2	WWFS10	WASHER, FLAT, #10, SAE
13	2	WWFS5/16	WASHER,FLAT,SAE,5/16
14	4	WWL1/2	1/2 LOCK WASHER
15	2	WWL10	WASHER,LOCK,#10
16	2	WWL5/16	WASHER, LOCK, 5/16

Parts

1390475 Bottom Boot Roll Holder Assembly

AAC Drawing Number 1390475 Rev 4




ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	1390448	SADDLE ASSY
2	2	1390502	CLAMP,SPRING, 5/8B
3	2	1390509	SLOT COVER
4	2	1390510	DOWEL PIN, 1/2 X 2 15/16
5	1	1390528	BOTTOM BOOT HLDR SUB-ASBY
6	1	1390892	RATCHET DOG, LEFT
7	1	1390893	RATCHET DOG, RIGHT
8	2	CCCL10F	CLAMP COLLAR- 5/8 ID
9	4	CCSC2-9-16	SHAFT COLLAR, SET 2-9/16"
10	1	RRLT085N4L	SPRING,TORSION,.085 WIRE, LEFT
11	1	RRLT085N4R	SPRING,TORSION, MOD
12	4	SSAS020016	SHOULDER BOLT 1/4 X 1/4L
13	4	SSBC98032	10-32 X 1/2 BUTTON CAP SC
14	4	SSHHC25080	3/8-16X1-1/4 HHCS
15	2	SSSC90032	#8-32 X 1/2 SOC CAP SC
16	4	TTH6271K450	ADJUSTABLE HANDLE 1/2-13x

Parts

1390500 Lower Roll Holder Frame

AAC Drawing Number 1390500 Rev 5




NO	QTY	PART #	DESCRIPTION	NO	QTY	PART #	DESCRIPTION
1	4	1390198	ROLL RELEASE DISK	14	2	NNH1/2-13	NUT,HEX,1/2-13
2	2	1390458	ROD, ROLL STOP	15	16	NNK5/16-18	KEP NUT, 5/16-18
3	4	1390459	NUT PLATE-SIDE ROLLER ADJ	16	4	SSAS024024	SHOULDER BOLT 3/8 X 3/8L
4	4	1390463	ROLL STOP, WELD'T	17	2	SSAS048160	SHOULDER BOLT 3/8 X 2.5L
5	1	1390508	FRAME WELDT- BOTTOM ROLLS	18	4	SSFC01040	1/4-20 X 5/8 FLAT ALN CAP
6	1	1390559	HANDLE ASSEMBLY	19	16	SSHHC10064	5/16-18 X 1 HHCS
7	1	1390565	RIGHT IDLER ROLLER, ROLL	20	2	SSHHC45112	1/2-13 X 1-3/4 HHCS, G8
8	1	1390566	LEFT IDLER ROLLER, ROLL	21	8	SSSC05080	SREW, SOCKET CAP 1/4-28X1-1/4
9	4	BB1L038	BEARING,BALL, .375B	22	4	TH32430	HANDLE, THRD, 3/8-16X1-1/4
10	4	BBTRA613	WASHER, THRUST, STL, .375B	23	4	WWFS1/2	WASHER, FLAT, SAE, 1/2
11	2	CCCL10F	CLAMP COLLAR- 5/8 ID	24	32	WWFS5/16	WASHER, FLAT, SAE, 5/16
12	2	MM082008	CASTER, PPP, 1200LBS/WHEEL	25	2	WWL1/2	1/2 LOCK WASHER
13	4	MM16CA03201-S	CASTER, SWIVEL, 3.25" STEEL				

Parts

13901331 PC HMI Assembly

AAC Drawing Number 13901331 Rev 0




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	0411-3708	NUT PLATE, BOX MOUNT
2	1	13901328	MOUNT, HMI, PC DISPLAY
3	1	13901329	MOUNT, TOUCH SCREEN
4	1	4082105	TOUCHSCREEN. 10", SUB ASSEMBLY
5	1	4082105B	HMI BACKING PLATE, EEE10TSM
6	1	NNE1/4-20	NUT, ELASTIC LOCK, 1/4-20
7	2	SSHCO1040	1/4-20 X 5/8 HHCS
8	1	SSSC01064	1/4-20 X 1 SOC CAP
9	4	SSSCM3X16	M3-0.5X16 ,SOCKET CAP
10	1	TH32425	HANDLE, THRD, 5/16-18X3/4
11	4	WWFM3	FLAT WASHER, M3
12	4	WWFS1/4	WASHER, FLAT, SAE, 1/4
13	1	WWFS5/16	WASHER, FLAT, SAE, 5/16
14	2	WWL1/4	WASHER, LOCK, 1/4
15	4	WWLM3	WASHER, LOCK, M3

Parts

13901390 Exit Assembly

AAC Drawing Number 13901390 Rev 0




13901390 parts list

ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13901391	SIDE SEALER, LEFT	12	2	NNH5/8-11	NUT,HEX,5/8-11
2	1	13901392	SIDE SEALER, RIGHT	13	2	NNK10-32	KEP NUT, 10-32
3	2	1390160	KEY, 1/4 X 1.25L	14	2	SSF98032	10-32 X 1/2 FLAT ALLEN CAP
4	1	1390225	GUARD, COUPLING	15	12	SSH10048	5/16-18 X 3/4 HHCS
5	2	1390382	TUBE,F,4X4X.25WX23.50L,D	16	1	SSH10080	HEX HEAD, 5/16-18 X 1-1/4
6	2	1390384	PLATE, MOUNTING	17	2	SSH41160	5/8-11 X 2-1/2 HEX CAP
7	2	1390789	SUPPORT, FRAME JOINER	18	4	WWF5/8	WASHER,FLAT,5/8
8	6	MM2421K31	GREASE FITTING, FLUSH-STYLE	19	2	WWF10	WASHER, FLAT, #10, SAE
9	2	MM6407K43	SPROCKET, 5/8P, 16T	20	12	WWF5/16	WASHER,FLAT,SAE,5/16
10	1	MM6407K53	CHAIN, #50-2, 16LINKS	21	12	WWL5/16	WASHER,LOCK, 5/16
11	*2	MMT9945	TAPE,REFLECTIVE,2" WIDE	22	2	WWL5/8	WASHER,LOCK 5/8

Parts

13901391 Left Side Exit Sealer

AAC Drawing Number 13901391 Rev 0




13901391 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	1349293	PLATE,NUT 1/4-20,2.50 CTC	26	1	EESP150-3	LINEAR, XDUCER (STRING POT) 50" RNGE
2	2	1390162	GUARD,BRACKET	27	1	MM1897A24	HANDLE,DOOR,PULL,OVAL,5/8
3	1	1390229	DRIVE-ROLLER REAR CONV.	28	3	MM9307K63	GROMMET,1/2ID,13/16 HOLE
4	1	1390255	BELT, OUTPUT CONV, 18" W	29	2	MMGRPA207-20	1-.25" BEARING, GRIP-IT
5	1	1390256	DOOR FRAME, LEFT	30	2	MMUCPA207-20	1-.25" BEARING
6	2	1390277	ASSY, ROLLER, SUPPORT	31	1	NNH1/2-13	NUT,HEX,1/2-13
7	2	1390278	SHAFT, BELT-SUPPORT, LONG	32	2	NNH3/4-10	NUT,HEX,3/4-10
8	4	1390427	WASHER, S/S, .755ID X 1-1/2OD	33	4	SSBC01032	1/4-20 X 1/2 BUT CAP SC
9	2	1390607	GUARD,BRACKET	34	4	SSFC01048	1/4-20 X 3/4 FLAT CAP
10	2	1390694	GUARD, REAR ROLLER	35	18	SSHC01048	1/4-20 X 3/4 HEX CAP
11	1	1390696	TOP PLATE, AIR TANK	36	10	SSHC01064	1/4-20 X 1 HHCS
12	1	1391021	EXIT FRAME ASSY, LEFTSIDE	37	2	SSHC34192	3/4-10 X 3 HEX CAP
13	1	1391025	ASSY, SEALBAR, LEFT	38	8	SSHC45080	1/2-13X1-1/4 HEX CAP
14	1	1391034	E-STOP GUARD-LH	39	4	SSHC98048	SCREW, HEX CAP #10-32X.75
15	1	1391043	RAISED SEAL BAR OPTION	40	2	SPPS98040	10-32X5/8 PAN HD SLOT
16	1	1391061	IDLER ROLLER ASSY	41	2	SSZS93032	SCREW, SHT,METAL 10 ZIP
17	1	1391157	DOOR SENSOR MTG BRKT.	42	2	WWF3/4	WASHER,FLAT,3/4
18	1	1391176	MTG BRKT, SIX MODULE STAT	43	2	WWFE016	WASHER,FENDER,LARGE,1/4
19	1	1391902	BED-PLATE ASSY	44	8	WWFS1/2	WASHER,FLAT,1/2, SAE
20	1	1394521	AIR TANK ASSY.	45	28	WWFS1/4	WASHER,FLAT,SAE,1/4
21	1	1396746	MOUNT, LINEAR TRANSDUCER	46	6	WWFS10	WASHER, FLAT, #10, SAE
22	1	AAQUT-4-4	QUICK UNION T 1/4X1/4	47	8	WWL1/2	1/2 LOCK WASHER
23	1	AAQUY-5-4	Y UNION, 5/32X1/4	48	28	WWL1/4	WASHER,LOCK, 1/4
24	8	CCCL16F	COLLAR,1" CLAMP TYPE	49	6	WWL10	WASHER,LOCK,#10
25	1	EEPTS25302G	ENCLOSURE W/ BUTTON, E-STOP	50	2	WWL3/4	3/4 LOCK WASHER

Parts

1391021 Exit Frame Assembly

AAC Drawing Number 1391021 Rev 8




1391021 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	13901406	COVER, CASTER MOUNT, SIDE SEAL	14	1	NNH3/4-10	NUT,HEX,3/4-10
2	2	1390237	ANGLE, KEEPER	15	4	NNJ3/4-10	3/4-10 JAM NUT
3	4	1390251	SPACER, PUSHER-CARRIAGE	16	8	SSHC01048	1/4-20 X 3/4 HEX CAP
4	1	1391020	WLDMNT, LEFT SIDE SEAL	17	1	SSHC33176	3/4-16 X 2-3/4 HEX CAP
5	1	1391022	WELDMNT,EXIT SUBFRAME,LT	18	2	SSHC34384	3/4-10 X 6 HEX CAP
6	1	1391036	CYLINDER ASSY, LH FRAME S	19	2	SSHC98096	#10-32 X 1-1/2 HEX CAP
7	1	1391038	VALVE ASSY, L SIDE SEAL	20	7	WWFE3/4	WASHER,3/4 FENDER
8	1	1391039	VALVE ASSY, CARRIAGE	21	8	WWFS1/4	WASHER,FLAT,SAE,1/4
9	1	1391040	MANIFOLD ASSY, TABLE ADJ	22	2	WWFS10	WASHER, FLAT, #10, SAE
10	1	1391771	ROLLER CARRIAGE ASBLY	23	8	WWL1/4	WASHER,LOCK, 1/4
11	5	1391907	SKID PLATE,UHMW	24	2	WWL10	WASHER,LOCK,#10
12	15	MM5X521	RIVET,POP,1/8D,,.313-.375	25	1	WWL3/4	3/4 LOCK WASHER
13	2	MMVG04201-12	V-GROVE CASTER .75 X 4				

Parts

1391036 Cylinder Assembly, LH frame

AAC Drawing Number 1391036 Rev 0




ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	AACDNCB100320PP	CYLINDER,100MMB X 320MMS
2	1	AAFSNC100	REAR PIVOT BRKT, 100MM
3	1	AAFSGSM20x15	ROD END, FEM-20MM X 1.5MM
4	2	AA1984201FU0411	FLOW CONTROL, 1/2 UNIFIT

Parts

1391038 Valve Assembly, Left Side

AAC Drawing Number 1391038 Rev




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	1390351	VALVE MTG PLATE
2	1	AAE4V21008	VALVE, 1/4" PORTED, 24VDC
3	2	AAFP18	MUFFLER, 1/8 NPT, BRONZ
4	1	AAQME-4-3S	FITTING, ELBOW, 1/4NPT, 3/8
5	2	AAQMT-4-3S	TEE, 1/4NPT-3/8 TUBE
6	2	NNH8-32	NUT, HEX, 8-32 REG.
7	2	SSSC90080	#8-32 X 1-1/4 SOC CAP SC
8	4	WWF8	WASHER, FLAT, #8
9	2	WWL8	WASHER, LOCK, #8

Parts

1391039 Valve Assembly, Carriage


AAC Drawing Number 1391036 Rev



ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	1390351	VALVE MTG PLATE
2	1	AAE4V230C08	VALVE, 1/4",24VDC,CNTR BK
3	2	AAFP18	MUFFLER,1/8 NPT, BRONZ
4	3	AAQME-4-3S	FITTING,ELBOW,1/4NPT,3/8
5	2	NNH8-32	NUT,HEX, 8-32 REG.
6	2	SSSC90080	#8-32 X 1-1/4 SOC CAP SC
7	4	WWF8	WASHER, FLAT, #8
8	2	WWL8	WASHER,LOCK,#8

Parts


1391040 Manifold Assembly, Table
AAC Drawing Number 1391040 Rev



ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	AAF4549K532	NIPPLE,1/4NPT X 1.5L
2	1	AAMSR20008	REGULATOR, 0-140 PSI RELIEVING, W/BRKT
3	1	AAQMC-3-3S	FITTING,STRT,3/8NPT,3/8
4	1	AAQME-3-2S	FITTING,ELBOW ,3/8NPT,1/2
5	2	AAQME-4-3S	FITTING,ELBOW ,1/4NPT,3/8
6	1	AAVM4A	MANIFOLD, 3/8(2) X 1/4(4)
7	2	EE6X750	TIE WRAP - Small.
8	2	MM4554K12	PLUG, 1/4" PIPE
9	2	SSSC98112	SCR, SOC CAP 10-32 X 1-3/4
10	2	WWFS10	WASHER, FLAT, #10, SAE
11	2	WWL10	WASHER,LOCK,#10

Parts

1391771 Roller carriage Assembly
 AAC Drawing Number 1391771 Rev 0




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	4	1391765	SPACER, ROLLER, 3/8
2	1	1391766	ROLLER CARRIAGE WELDMENT
3	2	MMVG04201-12	V-GROVE CASTER .75 X 4
4	6	NNJ3/4-10	3/4-10 JAM NUT
5	2	SSHC34352	3/4-10 X 5.5 HEX CAP
6	1	SSHC34384	3/4-10 X 6 HEX CAP
7	4	SSHC45064	1/2-13X1 HEX CAP
8	6	WWFE3/4	WASHER,3/4 FENDER
9	4	WWFS1/2	WASHER,FLAT,1/2, SAE
10	4	WWL1/2	1/2 LOCK WASHER

Parts

1391025 Left Seal Bar Assembly

AAC Drawing Number 1391025 Rev 4




DETAIL A
SCALE 1 : 6

NO	QTY	PART #	DESCRIPTION	NO	QTY	PART #	DESCRIPTION
1	1	1390130	END PLATE,RIGHT	13	1	K-234	COVER,4IN SQUARE
2	1	1390131	END PLATE,LEFT	14	2	K-235	CONNECTOR,ROMEX,1/2"
3	1	1390212	TUBE, SIDE SEAL	15	7	SSBC10064	5/16-18 X 5/8 L
4	1	1390336	SIDE SEAL CLAMP GUARD	16	7	SSHHC10048	5/16-18 X 3/4 HHCS
5	1	1390853	SIDE SEAL CLAMP GUARD	17	8	SSHHC25064	3/8-16 X 1,HEX CAP
6	1	1390855	SIDE SEAL CLAMP GUARD	18	4	SSHHC95032	10-24 X .5, HEX CAP
7	1	1390960	SIDE SEAL CLAMP GUARD	19	14	WWF5/16	WASHER,FLAT,5/16
8	1	1391024	PIVOT ARM, HEAT BAR, LH	20	8	WWFS3/8	WASHER,FLAT,SAE,3/8
9	1	1406516	SEAL BAR ASSY, 100"	21	4	WWFS10	WASHER, FLAT, #10, SAE
10	1	FF3234	STRAIN RELIEF,3/4NPT	22	8	WWL3/8	WASHER,LOCK, 3/8
11	1	FF8465	NUT,LOCK,3/4NPT,NYLON,BLK	23	4	WWL10	WASHER,LOCK,#10
12	1	K-233	BOX,ELECTRICAL,SQUARE				

Parts

1406516 Seal Bar Assembly, 100"

AAC Drawing Number 1406516 Rev 1




NO	QTY	PART #	DESCRIPTION
1	3	1390385	THREADED ROD, 7.5"
2	4	1390386	THREADED ROD, 6.25"
3	1	1390438	CUT BLADE 100"
4	1	1396590	SPACER, PTFE
5	1	1406517	SEAL BAR ASSY, 100"
6	1	EERBN105A10A-2	HEAT ELEMENT,105L,.315D
7	14	NNH3/8-16	NUT,HEX,3/8-16
8	7	WWFS3/8	WASHER,FLAT,SAE,3/8

Parts

1394521 Air Tank Assembly

AAC Drawing Number 1394521 Rev 0




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	261007	AIR TANK ASSEMBLY
2	1	1394520	TOP PLATE, AIR TANK
3	1	AAQBT-2-2	QUICK BRANCH "T"
4	1	MM44605K24	HEX BUSHING, 3/4 X 1/2
5	2	NNK1/4-20	KEP NUT, 1/4-20
6	2	SSHC01048	1/4-20 X 3/4 HEX CAP
7	4	WWFS1/4	WASHER,FLAT,SAE,1/4

Parts

13901392 Right Side Exit Sealer

AAC Drawing Number 1391392 Rev 0




13901392 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	1349293	PLATE,NUT 1/4-20,2.50 CTC	31	1	MM11/4SH	HUB, TAPERLOCK
2	2	13901319	BRACKET, SENSOR	32	1	MM1897A24	HANDLE,DOOR,PULL,OVAL,5/8
3	1	1390153	BRACKET, GUARD	33	1	MM40SH21H	SPROCKET, 1/2 P, 21T
4	1	1390160	KEY, 1/4 X 1.25L	34	6	MM5X521	RIVET,POP,1/8D.,313-.375
5	2	1390162	GUARD,BRACKET	35	3	MM9307K63	GROMMET,1/2ID,13/16 HOLE
6	1	1390229	DRIVE-ROLLER REAR CONV.	36	2	MMGRPA207-20	1.25" BEARING, GRIP-IT
7	1	1390255	BELT, OUTPUT CONV, 18"W	37	2	MMUCPA207-20	1.25" BEARING
8	1	1390273	DOOR FRAME, RIGHT	38	2	NNH3/4-10	NUT,HEX,3/4-10
9	2	1390277	ASSY, ROLLER, SUPPORT	39	4	SSBC01032	1/4-20 X 1/2 BUT CAP SC
10	2	1390279	SHAFT, BELT-SUPPORT, LONG	40	4	SSFC01048	1/4-20 X 3/4 FLAT CAP
11	4	1390427	WASHER, S/S, .755ID X 1-1/2OD	41	19	SSHC01048	1/4-20 X 3/4 HEX CAP
12	1	1390468	BRACKET, EYE MOUNT,LH	42	4	SSHC25096	3/8-16 X 1 1/2 HHCS
13	1	1390473	MOTOR/REDUCER ASSY	43	2	SSHC34176	3/4-10 X 2-3/4 HEX CAP
14	2	1390607	GUARD,BRACKET	44	8	SSHC45080	1/2-13X1-1/4 HEX CAP
15	2	1390694	GUARD, REAR ROLLER	45	1	SSHC45256F	1/2-13X4 FULL THD HEX CAP
16	1	1391038	VALVE ASSY, L SIDE SEAL	46	6	SSPS70048	4-40 X 3/4 PAN HD SLOTTED
17	1	1391043	RAISED SEAL BAR OPTION	47	1	SSPS70064	4-40 X 1 PAN HD SLOTTED
18	1	1391046	E-STOP GUARD-RH	48	2	SSPS98040	10-32X5/8 PAN HD SLOT
19	1	1391047	WELDMENT,EXIT SUBFRAME,RT	49	6	SSSC98048	10-32 X 3/4 SOC CAP
20	1	1391052	ASSY, SEALBAR, RIGHT	50	4	WWF3/8	WASHER,FLAT,3/8 OR 10MM
21	1	1391061	IDLER ROLLER ASSY	51	2	WWF4	WASHER, FLAT, #4
22	2	1391176	MTG BRKT, SIX MODULE STAT	52	8	WWFS1/2	WASHER,FLAT,1/2, SAE
23	2	1391177	NUT PLATE, GEAR MOTOR MTG	53	18	WWFS1/4	WASHER,FLAT,SAE,1/4
24	1	1391183	PANEL, TOP RH STATIC UHMW	54	8	WWFS10	WASHER, FLAT, #10, SAE
25	1	1975-412A	PLATE,NUT,4-40,.95CTC	55	2	WWFS3/4	WASHER,.797ID X 1-1/2OD
26	1	AAQUY-5-4	Y UNION, 5/32X1/4	56	8	WWL1/2	1/2 LOCK WASHER
27	8	CCCL16F	COLLAR,1" CLAMP TYPE	57	18	WWL1/4	WASHER,LOCK, 1/4
28	1	EEPTS25302G	ENCLOSURE W/ BUTTON, E-STOP	58	8	WWL10	WASHER,LOCK,#10
29	2	FFQS18VN6AFF	SENSOR,PROXIMITY	59	2	WWL3/4	3/4 LOCK WASHER
30	1	FFSM312LVQ	EYE,ELECTRIC,10-30VDC	60	4	WWL3/8	WASHER,LOCK, 3/8

Parts

1390473 Motor Reducer Assembly

AAC Drawing Number 1390473 Rev 3




NO.	QTY	PART #	DESCRIPTION
1	AR	51494	LUBRICANT, MOBIL SHC634
2	1	FF3460	STRAIN RELIEF, LIQ TIGHT
3	1	MM3/4SH	HUB, TAPERLOCK
4	1	MM40SH28H	SPROCKET, 1/2 P, 28T
5	1	MM56438	HORIZONTAL BASE, CI U
6	1	MMF71520B5J	SPEED REDUCER, WORM,
7	1	MMVM3542	3/4 1800 TEFC 208/460

Parts

1391038 Left Side Valve Assembly

AAC Drawing Number 1391038 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	1	1390351	VALVE MTG PLATE
2	1	AAE4V21008	VALVE, 1/4" PORTED, 24VDC
3	2	AAFP18	MUFFLER, 1/8 NPT, BRONZ
4	1	AAQME-4-3S	FITTING, ELBOW, 1/4NPT, 3/8
5	2	AAQMT-4-3S	TEE, 1/4NPT-3/8 TUBE
6	2	NNH8-32	HEX-NUT 8-32 REG.
7	2	SSSC90096	#8-32 X 1-1/2 SOC CAP SC
8	4	WWF8	WASHER, FLAT, #8
9	2	WWL8	WASHER, LOCK, #8

Parts

1391043 Raised Seal Bar Option

AAC Drawing Number 1391043 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	1	1390514	TAPE DISPENSER
2	1	1390530	TEMP HEAT PAD RISER
3	1	1391033	CYLINDER ASSY-SEAL BAR
4	1	1391037	CYLINDER ASSY-SEAL BAR
5	1	MM1268T63	SPRING CLIP, STEEL, 3"
6	4	SSBC01032	1/4-20 X 1/2 BUT CAP SC
7	2	SSH90032	#8-32 X 1/2 HEX CAP
8	6	SSPS01256	1/4-20 X 2-1/4 PAN HD SLOT

Parts

1391033 Seal Bar Cylinder Assembly

AAC Drawing Number 1391033 Rev 2




NO.	QTY	PART#	DESCRIPTION
1	2	AA1983201FU0311	FLOW CONTL 3/8UNIFIT X3/8
2	1	AACDNCB80250PPV	CYLINDER, 80MM X 250MM
3	1	AAFSGSM20x15	ROD END, FEM-20MM X 1.5MM
4	1	AAFSNC80	REAR PIVOT
5	1	AAV78861717	VALVE, BLOCKING, R3/8
6	1	AAQME-5-8U	QUICK MALE ELBOW- UNIFIT

Parts

1391037 Seal Bar Cylinder Assembly


AAC Drawing Number 1391037 Rev 0



NO.	QTY	PART #	DESCRIPTION
1	1	AACDNCB80250PPV	CYLINDER, 80MM X 250MM
2	1	AAFSGSM20x15	ROD END, FEM-20MM X 1.5MM
3	1	AAFSNC80	REAR PIVOT
4	2	AA1983201FU0311	FLOW CONTL 3/8UNIFIT X3/8

Parts

1391052 Right Seal Bar Assembly
AAC Drawing Number 1391052 Rev 5




1391052 parts list

NO	QTY	PART #	DESCRIPTION
1	1	1390130	END PLATE,RIGHT
2	1	1390131	END PLATE,LEFT
3	1	1390212	TUBE, SIDE SEAL
4	1	1390336	SIDE SEAL CLAMP GUARD
5	1	1390853	SIDE SEAL CLAMP GUARD
6	1	1390855	SIDE SEAL CLAMP GUARD
7	1	1390960	SIDE SEAL CLAMP GUARD
8	1	1391051	SIDE SEAL ASSM
9	1	1406516	SEAL BAR ASSY, 100"
10	1	FF3234	STRAIN RELIEF,3/4NPT
11	1	FF8465	NUT,LOCK,3/4NPT,NYLON,BLK
12	1	K-233	BOX,ELECTRICAL,SQUARE
13	1	K-234	COVER,4IN SQUARE
14	2	K-235	CONNECTOR,ROMEX,1/2"
15	7	SSBC10064	5/16-18 X 5/8 L
16	7	SSHC10048	5/16-18 X 3/4 HHCS
17	8	SSHC25064	3/8-16 X 1,HEX CAP
18	4	SSSC95032	10-24 X1/2, SOC CAP
19	14	WWF5/16	WASHER,FLAT,5/16
20	8	WWFS3/8	WASHER,FLAT,SAE,3/8
21	4	WWFS10	WASHER, FLAT, #10, SAE
22	8	WWL3/8	WASHER,LOCK, 3/8
23	4	WWL10	WASHER,LOCK,#10

Parts

1391061 Idler Roller Assembly


AAC Drawing Number 1391061 Rev 2



NO	QTY	PART #	DESCRIPTION
1	2	1390247	WELDMENT, BELT-TENSIONER
2	1	1390258	IDLER-ROLLER, REAR CONV.
3	2	MMGRPA207-20	1.25" BEARING, GRIP-IT
4	2	NNH1/2-13	NUT,HEX,1/2-13
5	4	SSHHC45096	1/2-13X1-1/2 HEX CAP
6	2	SSHHC45256F	1/2-13X4 FULL THD HEX CAP
7	4	WWFS1/2	WASHER,FLAT,SAE,1/2
8	4	WWL1/2	1/2 LOCK WASHER

13901279 Input Conveyor

AAC Drawing Number 13901279 Rev 1




13901279 parts list

ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13061105	VALVE ASSY, DUAL 4-WAY MANUAL	22	4	1394286	NUT PLATE
2	2	1390067	GUARD, CHAIN, SEAL-BAR, R	23	4	MM1676A12	MAGNETIC CATCH
3	1	13901280	INPUT CONVEYOR ASSY. #4	24	4	NNH1/2-13	NUT, HEX, 1/2-13
4	4	1390159	SPACER, LATCH, LEFT	25	8	SSHC01048	1/4-20 X 3/4 HEX CAP
5	2	1390286	BELT, CONVEYOR	26	8	SSHC25080	3/8-16X1-1/4 HHCS
6	2	1390394	GUARD, CHAIN, SEAL-BAR, R	27	2	SSHC45064	1/2-13X1 HEX CAP
7	4	1390617	TOP RACK SPACER	28	4	SSHC45192	1/2-13X3 HEX CAP
8	1	1390623	GUARD, CHAIN, UPR ROLLER	29	2	SSSC01032	1/4-20X1/2 SOC CAP
9	4	1390969	PLATE, SPACER, DOOR LATCH	30	8	SSSC80032	6-32 X 1/2 SOC CAP SC
10	1	1390B-PD3	DIAGRAM, PNEUMATIC,	31	48	SSSC98040	10-32 X 5/8 SOC CAP
11	1	1391054	ROLL HOLDER FRAME	32	1	WWF10	WASHER, FLAT, #10, COM
12	1	1391056	LOWER ROLL FEED	33	8	WWF8	WASHER, FLAT, #8
13	1	1391057	ROLLER TAKEUP ASSY	34	10	WWFS1/2	WASHER, FLAT, 1/2, SAE
14	1	1391057	ROLLER TAKEUP ASSY	35	8	WWFS1/4	WASHER, FLAT, SAE, 1/4
15	2	1391091	GUARD, CYLINDER	36	46	WWFS10	WASHER, FLAT, #10, SAE
16	1	1391178	GUARD, CHAIN, LWR ROLLER	37	8	WWFS3/8	WASHER, FLAT, SAE, 3/8
17	1	1391179	GUARD, LOWER FILM GEAR BO	38	6	WWL1/2	1/2 LOCK WASHER
18	2	1391180	MTG BRKT, LOWER FILM MOTO	39	10	WWL1/4	WASHER, LOCK, 1/4
19	1	1391269	OUTFEED PRESSURE ROLLER	40	48	WWL10	WASHER, LOCK, #10
20	1	1391435	GUARD, CHAIN, UPR ROLLER	41	8	WWL3/8	WASHER, LOCK, 3/8
21	2	1391873	GUARD, ROLLER BEARINGS	42	8	WWL8	WASHER, LOCK, #8

Parts

13061105 Valve Assembly

AAC Drawing Number 13061105 Rev 1




ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	*1	1390HCD-LAB1	LABEL, VALVE ASSY, DUAL 4-WAY
2	1	13061106	MOUNT, DUAL MAN. TOGGL VALVE
3	6	AAQME 4 8	QUICK MALE ELBOW, 1/4T
4	2	AAVMJTV-4	VALVE TOGGLE 4W, 1/8NPT

Parts

1391054 Roll Holder Frame

AAC Drawing Number 1391054 Rev 3




1391054 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	4	1390198	ROLL RELEASE DISK	23	2	CCCL10F	CLAMP COLLAR- 5/8 ID
2	1	1390233	ROLL STOP TUBE	24	1	FFSM312LVQ	EYE,ELECTRIC,10-30VDC
3	1	1390276	NUT PLATE-ROLL BRAKE MTG	25	3	MM132-1496	PLUG 1 X 2
4	2	1390405	SUPPORT ROLLER WELDT	26	2	MM9307K63	GROMMET,1/2ID,13/16 HOLE
5	1	1390412	SIDE ROLLER, ROLL HOLDER	27	8	SSSC05080	1/4-28X1-1/4 SOC CAP
6	2	1390458	ROD, ROLL STOP	28	4	NNH1/2-13	NUT,HEX,1/2-13
7	4	1390459	NUT PLATE-SIDE ROLLER ADJ	29	4	SSAS024024	SHOULDER BOLT 3/8 X 3/8L,
8	4	1390463	ROLL STOP, WELDT	30	5	SSFC01040	1/4-20 X 5/8 FLAT ALN CAP
9	1	1390468	BRACKET, EYE MOUNT,LH	31	2	SSHC25064	3/8-16 X 1,HEX CAP
10	1	1390470	FRAME WELDT- TOP ROLL	32	8	SSHC45096	1/2-13X1-1/2 HEX CAP
11	1	1390759	SIDE ROLLER, LONG	33	4	SSHC45256	1/2-13X4 HEX CAP
12	1	1391096	BRAKE BLOCK ASSY, 1390B	34	2	SSSC98040	10-32 X 5/8 SOC CAP
13	1	1391098	MTG. BRKT. ROLL BRAKE	35	2	SSSC70064	4-40 X 1 SOCKET CAP
14	1	1975-412A	PLATE,NUT,4-40,.95CTC	36	4	MMGRPA207-20	1.25" BEARING, GRIP-IT
15	1	AAC171D	CYLINDER,AIR,DA,1-1/2 B,1 ST	37	4	TTH32430	HANDLE,THRD,3/8-16X1-1/4
16	1	AAF122A-A	1/8" NPT HEX CLOSE	38	2	WWF4	WASHER, FLAT, #4
17	1	AAFCT-15	CLEVIS,AIR CYL,7/16-20	39	16	WWFS1/2	WASHER,FLAT,1/2. SAE
18	1	AAFP18	MUFFLER,1/8 NPT, BRONZ	40	2	WWFS10	WASHER, FLAT, #10, SAE
19	1	AAQME-5-8	QUICK MALE ELBOW	41	2	WWFS3/8	WASHER,FLAT,SAE,3/8
20	1	AAVMJTV-3	V ALVE,TOGGLE	42	12	WWL1/2	1/2 LOCK WASHER
21	4	BB1L038	BEARING,BALL,.,375B	43	2	WWL10	WASHER,LOCK,#10
22	4	BBTRA613	WASHER,THRUST,STL, .375B	44	2	WWL3/8	WASHER,LOCK, 3/8

Parts

1391056 Lower Roll Feed

AAC Drawing Number 1391056 Rev 2




NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	2	1390405	SUPPORT ROLLER WELDT	17	4	MMGRPA207-20	1.25" BEARING, GRIP-IT
2	1	1390804	BOTTOM ROLLER MTG BRKT FO	18	8	NNE10-32	NUT,ELASTIC LOCK
3	2	1390810	GUIDE PLATE ASSY, LOWER R	19	2	NNH5/8-11	NUT,HEX,5/8-11
4	1	1390811	LOWER ROLLER WELDMNT	20	8	SSFC98048	#10-32 X .75 SHCSF
5	1	1390812	AXEL, GLIDE WHEEL	21	2	SSHC01064	1/4-20 X 1 HHCS
6	2	1390882	SIDE PLATE- BOTTOM ROLL	22	2	SSHC25080	3/8-16 X 1-1/4 HEX CAP
7	1	1391095	MTG. BRKT. BRAKE	23	2	SSHC41192F	5/8-11X4 HEX CAP FULL THD
8	1	1391096	BRAKE BLOCK ASSY, 1390B	24	1	SSHC45064	1/2-13X1 HEX CAP
9	1	AAC171D	CYLINDER,AIR,DA,1-1/2 B,1 ST	25	8	SSHC45080	1/2-13X1-1/4 HEX CAP
10	1	AAF122A-A	1/8" NPT HEX CLOSE	26	8	WWF10	WASHER, FLAT, #10, COM
11	1	AAFCT-15	CLEVIS,AIR CYL,7/16-20	27	1	WWFS1/2	WASHER,FLAT,SAE,1/2
12	1	AAFP18	MUFFLER,1/8 NPT, BRONZ	28	2	WWFS1/4	WASHER,FLAT,SAE,1/4
13	1	AAQME-5-8	QUICK MALE ELBOW	29	2	WWFS3/8	WASHER,FLAT,SAE,3/8
14	1	AAVMJTV-3	VALVE,TOGGLE	30	9	WWL1/2	1/2 LOCK WASHER
15	1	CCCL12F	CLAMP COLLAR- 3/4	31	2	WWL1/4	WASHER,LOCK,1/4
16	1	MM2419T31	WHEEL, 4"OD X 2"W X 3/4 B	32	2	WWL3/8	WASHER, LOCK, 3/8

Parts

1391057 Roller Take-up Assembly


AAC Drawing Number 1391057 Rev 0



NO.	QTY	PART #	DESCRIPTION
1	1	1390248	IDLER-ROLLER, INFEEED CONV
2	2	1390282	WELDMENT, BELT-TENSIONER
3	2	1390681	GUARD, ROLLER
4	2	1390859	COVER, PILLOWBLOCK
5	2	MMGRPA207-20	1.25" BEARING, GRIP-IT
6	4	SSH45096	1/2-13 X 1-1/2 HEX HEAD
7	4	WWFS1/2	WASHER, FLAT, 1/2
8	4	WWL1/2	1/2 LW

Parts

1391269 Outfeed Pressure Roller
AAC Drawing Number 1391269 Rev 2




ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	1390755	CYL. MTG. BRTK.	10	2	MMVPLS-116	BEARING,PILLOW BLOCK 1.0B
2	2	1390766	PIVOT HANGER-TOP ROLLER O	11	2	NNJ3/8-16	3/8-16 JAM NUT
3	1	1390856	SPACER - CYL. MTG. BRTK.	12	4	SSHC01064	1/4-20 X 1 HHCS
4	1	1391185	ROLLER ASSY -OUTFEED	13	4	SSHC25080	3/8-16X1-1/4 HHCS
5	1	1391270	FRAME - TOP ROLLER. OUTFE	14	2	SSHC25096	3/8-16 X 1 1/2 HHCS
6	2	AA198RA404U	FLOW CONTROL,1/4PTX1/4	15	4	WWFS1/4	WASHER,FLAT,SAE,1/4
7	1	AACM3110DXP	CYLINDER,AIR,DA W/MAGNET	16	4	WWFS3/8	WASHER,FLAT,SAE,3/8
8	1	AAFD2313	CLEVIS, AIR CYL 1/2-20	17	4	WWL1/4	WASHER,LOCK, 1/4
9	1	AAFD620	REAR PIVOT BRKT	18	4	WWL3/8	WASHER,LOCK, 3/8

Parts

13901280 Input Conveyor Assembly # 4

AAC Drawing Number 13901280 Rev 0




13901280 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	1390324	TOP BRACKET LINEAR SHAFT	26	4	SSBC01040	1/4-20 X 3/4 BUT CAP SC
2	1	1390337	INPUT GUARD CROSS SEAL RT	27	12	SSBC10064	5/16-18 X 5/8 L
3	2	1390342	TOP CHAIN TENSIONER	28	2	SSBC98048	10-32 X 3/4 BUTTON CAP SC
4	2	1390343	LOWER LINEAR BRKT CROSS	29	16	SSHC10064	5/16-18 X 1 HHCS
5	2	1390346	SHAFT,ROLLER	30	2	SSHC25080	3/8-16X1-1/4 HHCS
6	1	1390484	SHAFT ASSY,IDLER SPKTS	31	18	SSHC25096	3/8-16 X 1 1/2 HHCS
7	2	1390485	END PLATE, CROSS SEAL	32	4	SSHC25112	3/8-16 X 1-3/4 HEX HEAD
8	1	1390504	STOP PLATE ASSEMBLY	33	4	SSHC25128	3/8-16 X 2 HEX CAP
9	1	1390507	PLATE ASSY, PUSHER	34	2	SSHC25224	3/8-16 X 3.5 HEX CAP
10	1	1390609	MOUNT, CROSS SEAL BAR	35	2	SSHC45112	1/2-13 X 1-3/4 HHCS, G8
11	2	1390858	INPUT GUARD CROSS SEAL	36	6	SSPS98032	10-32X1/2 PAN HD SLOT
12	1	1390967	INPUT GUARD CROSS SEAL LT	37	8	SSSC05096F	1/4-28X1-1/2 SOC CAP FUL
13	1	13901281	INPUT CONVEYOR ASSY. #3	38	4	SSSC25064	3/8-16X1 SOC CAP
14	1	1406519	SEAL BAR 120" ASSEMBLY	39	6	SSSC98040	10-32 X 5/8 SOC CAP
15	1	1406823	SUPPORT, CENTER CROSSBAR	40	28	WWF5/16	WASHER,FLAT,5/16
16	1	1406995	BLADDER SEAL KIT, 120"	41	2	WWFE016	WASHER,FENDER,LARGE,1/4
17	1	1490345	IDLER ROLLER ASSY. FILM	42	12	WWFS1/4	WASHER,FLAT,SAE,1/4
18	2	CCCL20F	COLLAR, 1 1/4" CLAMP TYPE	43	36	WWFS3/8	WASHER,FLAT,SAE,3/8
19	2	MM41E15	SPROCKET, 1/2 P, 15T	44	6	WWFS10	WASHER, FLAT, #10, SAE
20	1	MM9307K63	GROMMET,1/2ID,13/16 HOLE	45	2	WWL1/2	1/2 LOCK WASHER
21	2	MM94807A029	PUSHNUT,ROUND,1/4 DIA	46	4	WWL1/4	WASHER,LOCK, 1/4
22	2	MMPB20M	LIN. PILLOW-BLOCK,MOD.	47	26	WWL3/8	WASHER,LOCK, 3/8
23	16	NNH1/4-28	NUT,HEX,1/4-28	48	4	WWL5/16	WASHER,LOCK, 5/16
24	8	NNH3/8-16	NUT,HEX,3/8-16	49	6	WWL10	WASHER,LOCK,#10
25	2	NNJ3/8-16	3/8-16 JAM NUT	50	8	WWS307-1	WASHER,SPRING,BELVEL

Parts

1390484 Drive Shaft Assembly

AAC Drawing Number 1390484 Rev 3




NO	QTY.	PART #	DESCRIPTION
1	2	1386645	MODIFIED SPROCKET
2	1	1390355	JACK SHAFT CROSS SEAL
3	2	1390997	KEY, 1/4 X 1.25L, W/STEP
4	2	IIS016X112	ROLL PIN 1/8 DIA X 1 1/2 SS
5	3	MMUCP205-16	BEARING,PILLOW BLOCK,1"

Parts

1390504 Stop late Assembly

AAC Drawing Number 1390504 Rev 1




NO.	QTY	PART #	DESCRIPTION
1	1	1390194	BRACKET, SENSOR
2	1	1390304	GUIDE, RIGHT POSITION
3	1	1390308	GUIDE, LEFT, WELDMENT
4	1	1975-412A	PLATE, NUT, 4-40, .95CTC
5	1	FFSM312LVQ	EYE, ELECTRIC, 10-30VDC
6	6	NNK10-32	KEP NUT, 10-32
7	6	SSFC98128	#10-32 X 2 FLAT CAP
8	2	SSHC01032	1/4-20 X 1/2 HHCS
9	2	SSPS70064	4-40 X 1 PAN HD SLOTTED
10	2	WWF4	WASHER, FLAT, #4
11	2	WWFS1/4	WASHER, FLAT, SAE, 1/4
12	6	WWFS10	WASHER, FLAT, #10, SAE
13	2	WWL1/4	WASHER, LOCK, 1/4
14	2	WWL4	WASHER, LOCK, #4

Parts

1390507 Pusher Plate Assembly

AAC Drawing Number 1390507 Rev 4




NO.	QTY	PART #	DESCRIPTION	NO.	QTY	PART #	DESCRIPTION
1	1	1390194	BRACKET, SENSOR	14	6	NNK10-32	KEP NUT, 10-32
2	1	1390305	GUIDE, RIGHT POSITION	15	6	SSFC98128	#10-32 X 2 FLAT CAP
3	1	1390309	GUIDE, RIGHT, ASSEM	16	2	SSHC01032	1/4-20 X 1/2 HHCS
4	1	1390350	PLUG,1/4" PIPE, MOD	17	2	SSHC98096	#10-32 X 1-1/2 HEX CAP
5	1	1390674	BRACKET, MANFOLD	18	2	SSPS70064	4-40 X 1 PAN HD SLOTTED
6	1	1975-412A	PLATE,NUT,4-40,.95CTC	19	2	SSSC01048	1/4-20 X 3/4" SOC CAP SC
7	1	AAF1/4-BFF	90 DEG ECONO ELBOW, NPTF, 1/4"	20	2	WWF4	WASHER, FLAT, #4
8	1	AAQME-3-3S	FITTING,ELBOW,3/8NPT,3/8	21	4	WWFS1/4	WASHER,FLAT,SAE,1/4
9	1	AAVM4A	MANIFOLD, 3/8 X 1/4	22	8	WWFS10	WASHER, FLAT, #10, SAE
10	1	FFSM312LVQ	EYE,ELECTRIC,10-30VDC	23	4	WWL1/4	WASHER,LOCK,1/4
11	3	MM4554K12	PLUG, 1/4" PIPE	24	2	WWL10	WASHER,LOCK,#10
12	1	MM4638K513	PLUG,3/8",HEX SOCKET	25	2	WWL4	WASHER,LOCK,#4
13	1	MM4830K137	NIPPLE,1/4NPT X 5.0L				

Parts

1406519 Seal Bar Assembly, 120"

AAC Drawing Number 1406519 Rev 1




NO	QT	PART #	DESCRIPTION
1	1	1390333	CUT BLADE 120"
2	3	1390385	THREADED ROD, 7.5"
3	6	1390386	THREADED ROD, 6.25"
4	7	1391898	SHIM, .018, CROSS SEAL
5	2	1391899	SHIM, .018, CROSS SEAL
6	1	1406518	SEAL BAR 120" ASSEMBLY
7	1	1490508	STRIP, INSULATING
8	1	EERBN125A10A-4	HEAT ELEMENT, 125L, .315D
9	18	NNH3/8-16	NUT, HEX, 3/8-16
10	9	WWFS3/8	WASHER, FLAT, SAE, 3/8

Parts

1406995 Bladder Seal, 120"

AAC Drawing number 1406995 Rev 10




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	3	1406938	QUICK PLUG 1/4, MODIFIED
2	1	1406942	REGULATOR ASSY, MODIFIED
3	2	13901203	TROUGH, SEAL BAR 120"
4	1	14061357	BLADDER ASSY, 120"
5	2	AAQMF-4	MANIFOLD, 3, 1/4-1/4-1/4
6	1	AAQPR-2-3	QUICK PLUG REDUCER
7	1	AAQPR-3-4	QUICK REDUCER 3/8-1/4
8	1	AAQUY-2-2	QUICK UNION Y, 1/2X1/2
9	10'	AATP4-1	1/4" OD POLYURETHANE
10	1 KIT ONLY	DDB#29	#29 DRILL BIT
11	1	MMRF118914	SILICONE, STRIP, 2.25X.25TK
12	1	MMSG1305	TAPE, TEX PTFE, 3.4W X 54'L, 6 MIL
13	4	SSFC70064	SCREW, FLAT ALLEN CAP 4-40 X 1
14	2	SSSC90032	SCREW, SOCKET CAP
15	2	SSSC90080	SCREW, SOCKET CAP
16	1 KIT ONLY	TTA8-32	8-32 TAP

Parts

1490345 Film Idler Roller Assembly

AAC Drawing Number 1490345 Rev 0





ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	1390446	TURN-AROUND ROD
2	1	1390464	TUBE, IDLER ROLLER
3	2	1490346	SPACER, PILLOW BLOCK
4	2	BBF-1000-4	BEARING, BALL, 1 1/4 B, UNGRD
5	2	CCCL16F	COLLAR, 1" CLAMP TYPE
6	2	MMVPLS-116	BEARING, PILLOW BLOCK 1.0B
7	4	SSHHC25080	3/8-16X1-1/4 HHCS
8	4	SSSC25064	3/8-16X1 SOC CAP
9	4	WWFS3/8	WASHER, FLAT, SAE, 3/8
10	4	WWL3/8	WASHER, LOCK, 3/8

Parts

13901281 Input Conveyor Assembly # 3

AAC Drawing Number 13901281 3






13901281 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	13901053	BUTTON BOX, E-STOP/START	33	*36"	MMT9945	TAPE, REFLECTIVE, 2" WIDE
2	5	1975-412A	PLATE, NUT, 4-40, .95CTC	34	6	NNH3/8-16	NUT, HEX, 3/8-16
3	1	1390443	SENSOR ASSEMBLY, FILM OUT	35	4	NNJ1/2-20	NUT, JAM, 1/2-20
4	1	1390468	BRACKET, EYE MOUNT, LH	36	8	NNJ3/8-16	3/8-16 JAM NUT
5	2	1390478	SPACER, BUMPER	37	1	NNK1/4-20	KEP NUT, 1/4-20
6	2	1390703	BRACKET, DAMPENING MOUNT	38	*468"	PPP40	CHAIN, #40 RIVET
7	4	1390846	BRACKET, EYE MOUNT, LH	39	*10	PPP40CL	LINK, CONNECTING, #40
8	3	1391176	MTG BRKT, SIX MODULE STAT	40	4	SSHCO1032	1/4-20 X 1/2 HHCS
9	1	13901032	TOP MTG BRKT, MAIN BOX	41	4	SSHC01048	1/4-20 X 3/4 HEX CAP
10	1	13901041	CABLE TRACK, 1390 CABINET	42	2	SSHC01064	1/4-20 X 1 HHCS
11	2	13901055	BUTTON BOX, RESET, BLUE	43	2	SSHC01096	1/4-20 X 1-1/2 HHCS
12	2	13901091	SAFETY INTERLOCK SWITCH ASSY	44	2	SSHC01144	HEX HEAD, 1/4-20 X 2-1/4
13	1	13901207	ENCLOSURE, SBUS, EXTERNAL	45	2	SSHC25048	3/8-16X3/4, HEX CAP
14	1	13901282	INPUT CONVEYOR ASSY. #2	46	2	SSHC25064	3/8-16 X 1, HEX CAP
15	1	13901292	CABINET, ELECT CNTRL 1390BA	47	6	SSHC25096	3/8-16 X 1 1/2 HHCS
16	1	13901326	TOP MTG BRKT, MAIN BOX, PC MOUNT	48	8	SSHC25096F	3/8-16 X 1 1/2 HEX HEAD
17	2	13901557	PLATE, NUT, 3/8-16@2.00 CTC	49	8	SSHC98032	10-32X1/2 HEX HD
18	1	13901558	TUBE, F.4X4X.25WX135.25L	50	8	SSPS70064	4-40 X 1 PAN HD SLOTTED
19	*50	AAF3/16	CLAMP, BLACK PLASTIC, 3/16 DIA	51	2	SSSC70048	4-40 X 3/4 SOCKET CAP
20	2	AAPR025IF2B	SHOCK 5/8 STK, 1/2-20 THD	52	2	SSSC98048	10-32 X 3/4 SOC CAP
21	*100'	AATP1/2	1/2" OD POLYURETHANE	53	2	SSSC98080	10-32 X 1-1/4 SOC CAP
22	*300'	AATP3/8	3/8" OD POLYURETHANE	54	2	WWF1/4	WASHER, FLAT, 1/4", COM
23	*150'	AATP4-1	1/4" OD POLYURETHANE	55	4	WWF3/8	WASHER, FLAT, 3/8 OR 10MM
24	*75'	AATP5/32	5/32" OD POLYURETHANE	56	10	WWF4	WASHER, FLAT, #4
25	1	EELES302RAG	TOWER, SIGNAL, LED, RAG	57	6	WWFS1/4	WASHER, FLAT, SAE, 1/4
26	1	EESP150-3	LINEAR, XDUCER (STRING POT) 50" RNGE	58	14	WWFS3/8	WASHER, FLAT, SAE, 3/8
27	2	FFQS18VN6RQ8	SENSOR, LASER RECEIVER, NPN	59	10	WWFS10	WASHER, FLAT, #10, SAE
28	2	FFQS186LEQ8	SENSOR, LASER EMITTER	60	8	WWL1/4	WASHER, LOCK, 1/4
29	1	FFSM312LVQ	EYE, ELECTRIC, 10-30VDC	61	10	WWL3/8	WASHER, LOCK, 3/8
30	*50	MM5X521	RIVET, POP, 1/8D., 313-.375	62	8	WWL4	WASHER, LOCK, #4
31	*6'	MM8507K22	EDGE TRIM	63	12	WWL10	WASHER, LOCK, #10
32	2	MM9540K28	BUMPER, 1-1/2 DIA, 70A				

Parts

13901053 E-Stop / Start Button Assembly


AAC Drawing Number 13901053 Rev 0



ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	1391142	MTG BRKT REMOTE CONTROL
2	2	EE3Q01	CNTK BLOCK, N.C. (RED) SPNG TERM
3	1	EE3Q10	CNTK BLOCK, N.O. (GRN) SPNG TERM
4	2	EEA3L	LATCH,PUSH BUTTON
5	1	EEPCB65GM8	ENCLOSURE,80X110X65
6	1	EEPF3	BUTTON, PUSH 22MM, GREEN MO
7	1	EEPMTS44	E-STOP BUTTON, TWIST REL.
8	1	FFM3234GBR-SM1	STRAIN RELIEF, 3/4NPT, 5 HOLE, BLK
9	1	MM800E15YE112	E-STOP LEGEND PLATE
10	4	SSPS90040	8-32 X 5/8 PAN HD

Parts

1390443 Sensor Assembly, Film Out
AAC Drawing Number 1390443 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	1	1335-316	ROD, SS, "L", 3/8, 4.0 X
2	1	23080	BLOCK, CLAMP, EYE
3	1	23132A	HOLDER, EYE
4	1	FFSM312LVQ	EYE, ELECTRIC, 10-30VDC
5	2	SSSC70040	4-40 X 5/8, SCREW, SOCKET CAP
6	2	SSSC98040	10-32 X 5/8 SOC CAP
7	2	WWF4	WASHER, FLAT, #4

Parts

13901055 Reset Button Assembly

AAC Drawing Number 13901055 Rev 0




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	13901071	PLATE,MOUNTING,80X80 J-BOX
2	1	EE3Q10	CNTK BLOCK, N.O. (GRN) SPNG TERM
3	1	EEA3L	LATCH,PUSH BUTTON
4	1	EEPF6	PUSH BUTTON,22MM,BLUE,MO
5	1	EEPTS25302M1	BOX, 80X80X60MM, ONE BUTTON 7/8,
6	1	FFM3200GAH-SM	STRAIN RELIEF, 1/2NPT, 3 HOLE, BLK
7	4	SSSC90024	8-32 X 3/8 SOC CAP SC

Parts

13901091 Safety Interlock Switch Assembly

AAC Drawing Number 13901091 Rev 2




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	1060008	PLATE,NUT,8-32X.50
2	1	1307374	PLATE, NUT, 8-32 X 22MM CTC X 10 GA
3	1	1318377	SAFETY SWITCH MOUNT
4	1	13901092	SAFETY SW MNT FOR EEIDIS190051
5	1	EE140103	KEY,SAFETY SW,IDIS,90 DEG
6	1	EEIDIS190051	SWITCH, SAFETY, DOOR.
7	1	FFM3200GAH-SM	STRAIN RELIEF, 1/2NPT, 3 HOLE, BLK
8	2	SSBC90032	8-32X1/2 BUTTON CAP
9	4	SSBC98016	10-32 X 1/4 BUTTON CAP SC
10	2	SSSC90080	#8-32 X 1-1/4 SOC CAP SC
11	2	WWL6	WASHER,LOCK,#6


13901207 parts list

ITEM	QTY.	PARTNUMBER	DESCRIPTION	ITEM	QTY.	PARTNUMBER	DESCRIPTION
1	1	13901027	PLATE,SBUS HOLDDOWN, EXT	14	1	FF248-502	TERMBLK,WAGO,TP,MARK (1-10)
2	1	13901028	CABLE,SBUS, EXTERNAL CONNECT	15	1	FF248-503	TERMBLK,WAGO,TP,MARK (11-20)
3	1	13901029	COVER,SBUS MODULE GUARD	16	1	FF248-504	TERMBLK,WAGO,TP,MARK (21-30)
4	1	13901042	BRACKET, EXT CONNECTION PANEL	17	1	FF248-505	TERMBLK,WAGO,TP,MARK (31-40)
5	1	13901207-CAB	CABLE KIT - 1390 GENERIC	18	4	FF264-311	TERMBLK,WAGO,TP,SINGLE,GRY
6	1	13901207-LAB	LABEL - 1390 EXT CONNECTION BOX	19	36	FF264-321	TERMBLK,WAGO,TP,SNGL,GRY, NO FT
7	1	13901207-WD	DIAGRAM, WIRING - EXT CONNECTION	20	1	FF264-371	TERMBLK,WAGO,TP,END
8	1	4080-110	MODULE,QUAD INPUT	21	2	FF8465	NIJT,LOCK, 3/4NPT,NYLON,BLK
9	1	4080-120	MODULE,SBUS, DUAL OPTO-ISO, INPT	22	2	FFM3234GBR-SM	STRAIN RELIEF, 3/4NPT, 5 HOLE, BLK
10	1	4080-130	MODULE,QUAD OPTO-ISO	23	2	FFR10K	RESISTOR,10K, 1/4W, 5%
11	1	4080-140	MODULE,QUAD OUTPUT	24	4	SSPP90024	8-32X3/8 PAN PHILPS
12	2	4080-960	CONNECTOR, BULKHEAD, SBUS	25	4	SSPP98024	10-32 X 3/8 PAN HD PHILIP
13	1	EEPCM200100G	ENCLOSURE, PLASTIC, 255 X180X100				

Parts

13901292 Electrical Control Cabinet
AAC Drawing Number 13901292 Rev 0







ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13061116	CABINET, 1306D GENERIC,	12	3	4080-140	MODULE,QUAD OUTPUT
2	2	13901004	PLATE, INSERT, BACK 1390	13	5	4080-270	MODULE,MODBUS
3	1	13901017	SBUS ASSEMBLY, 1390 HCB GENERIC	14	1	4080-950	MODULE,POWER
4	1	13901208	PANEL, CABLE ENTRY, BOTTOM RIGHT	15	2	EE64151B	FERRITE CORE,SPLIT,CABLE
5	1	13901209	PANEL, CABLE ENTRY, BOTTOM LEFT	16	1	EEHR65	DISCONNECT HANDLE,PISTOL
6	1	13901293	PANEL ELECTRICAL CNTRL 1390BA	17	1	FFRTV1035	SILICONE, RTV, CLEAR, NON-COROS
7	1	1390BA-WD1	WIRING DIAG, CONTROL BOX, POWER	18	1	MM4952-1/4	TAPE,DOUBLE SIDED,1/4"W X .035 T
8	1	1390BA-WD2	WIRING DIAG, SBUS	19	1	RBM4524	STRAIN RELIEF,1-1/4 NPT, .87-.1.26, BLK
9	1	1390BA-WD3	WIRING DIAGRAM, SAFE, PAUSE,	20	1	RBM9144	LOCKNUT,NYLON,1-1/4"NPT
10	1	1390BA-WD4	WIRING, DIAG, SAFETY CIRCUIT	21	25	SSPP98024	10-32 X 3/8 PAN HD PHILIP
11	1	4080-110	MODULE,QUAD INPUT				

Parts

13901293 Panel, Electrical Control Cabinet, 1390BA


AAC Drawing Number 13901293 Rev 0






ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	EEB077MD27LR		13	AR	EE6X752	CABLE TIE, 5.51, 40 LB BLACK
2	4	SSPS90096	#8-32 X 1-1/2 PAN HD	14	AR	EE6X753	CABLE TIE, 7.40, 50 LB
3	12	SSTP98024	10-32 X 3/8, TRUSS HD SCR	15	1	4080-4255	CABLE, SBUS, PAUSE/WARN, 2 COND, 3"
4	4	SSSC80032	6-32 X 1/2 SOC CAP SC	16	1	FF881812	CABLE, 12 COND, 18 AWG, 300V, THICK
5	15	EECLIPFIX	ANCHOR, DIN RAIL	17	1	4080-4254	CABLE, SBUS, 3 CHAN HYD CONTROL
6	1	FFFAZD22NA	BREAKER, 2P, 2A, UL489, 240VT-MAG	18	1	4080-4252	CABLE, SBUS, 3 CHAN SEAL BAR HEAT
7	7	FFFAZD215NA	BREAKER, 2P, 15, UL489, 240VT-MAG	19	1	4080-4253	CABLE, SBUS, 3 CHAN SEAL BAR SOLIN
8	1	FFFAZD52NA	BREAKER, 2P, 5A, UL489,	20	5	4080-4251-12	CABLE, SBUS, MODBUS I510 DRIVE, 12"
9	1	FFM9XUTC15	BREAKER, ACC, UL489, COMB, 18MM, 3-COVER	21	1	4080-4250-24	CABLE, SBUS, POWER, PS - PWR MOD, 24"
10	2	FFM9XUP312	BREAKER, ACC, UL489, COMB, 18MM, 3P12	22	1	AAF3/8	CLAMP, BLACK PLASTIC
11	3	FFM9XUPC04	BREAKER, ACC, UL489, COMB, 18MM, TOP	23	2	EECGC85A220	CONTACTOR, 65A, 220VAC
12	AR	EE6X750	CABLE TIE, 4-0, BLACK, 18#	24	12	FF209-120	DIN MOUNTING FOOT, SHORT


13901293 parts list



DETAIL C
SCALE 1:2



DETAIL B
SCALE 1:2



DETAIL A
SCALE 1:2


13901293 parts list continued

ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
25	70"	EETS35X7.5A	DIN RAIL-AMERICAN	43	1	EEQS5DNET	POWER SUP,SW,24V 3.8A,85-264V,
26	1	EESPA210-6.90	DISCONNECT SHAFT,MOD	44	1	EEMDR2024	POWER SUP,SWITCHER,24V,1.0A,DIN
27	1	EEM60U3M	DISCONNECT, 3PH, 60A, UL98	45	1	EERC601BUZ4M1	PROTECTOR, SURGE, W/RING TERMINALS
28	4	MM510155B1M1	DRIVE, VFD ,1510,,75HP, 240V , 1PH, NET,	46	2	EELG5925-24	RELAY,SAFETY, 2 CHAN, 24V
29	1	FF109R0824SM1	FAN ASSY, 24V , 80MM	47	1	EELG5929-61	RELAY,SAFETY,24V,EXTENSION,5 NO,1 NC
30	2	FF08172	FAN GUARD, 80MM, METAL	48	1	EELG5928-3	RELAY,SAFETY,24V,EXTENSION,DLAY
31	4	EE64151B	FERRITE CORE,SPLIT,CABLE	49	2	FF84140210M1	RELAY,SSR,24VAC,25A
32	12	NNK10-32	KEP NUT, 10-32	50	1	SSPP90032	SCREW, #8-32 X 1/2, PAN HD, PHIL
33	1	FF793-5501	MARKER (BLANK)TERMBLK,WAGO,10X CRD	51	3	TTDBNYDS218	TERM, FLAT BLADE,INS, 14 AWG,BLUE
34	5	FF209-502	MARKER, WAGO, TOP, #1-10	52	3	TF52514	TERM, RING, 1/4", 14-16GA, INS BLU
35	1	FF209-503	MARKER,WAGO, TOP, 11-20	53	8	TT0190670071	TERM, RING, 1/4", 6 AWG, INS BLU
36	1	13901078	MOUNT, FAN	54	5	TT192130011	TERM, WIRE PIN, 14-16AWG, CRIMP, BLU
37	10	NNH8-32	NUT,HEX, 8-32 REG.	55	5	TTBB5263	TERM, .25 FULLY INSUL QUICK D,
38	6	NNH1/4-20	NUT,HEX, 1/4-20	56	2	TT191930152	TERM,RING,1/4",8AWG,NON INS
39	6	NNK8-32	NUT,KEP,8-32	57	3	FF280-308	TERMBLK ENDPLATE,WAGO,280
40	1	13901011	PANEL, SUB, 1390 BASIC	58	2	FF264-341	TERMBLK,WAGO, TOP, DUAL, GRY
41	1	13901384	PC POWER BLOCK BRACKET	59	1	FF264-371	TERMBLK,WAGO, TOP, END
42	1	13901012	PLATE, HEAT SPREADER, SINK	60	21	FF280-901	TERMBLK,WAGO, TOP, \$NGL, GRY

Parts

13901282 Input conveyor Assembly # 2

AAC Drawing Number 13901282 Rev 0




13901282 parts list

ITEM	QTY	PART NUMBER	DESCRIPTION	ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	13901283	INPUT CONVEYOR ASSY #1	19	3	MM11/4SH	HUB, TAPERLOCK
2	4	1390160	KEY, 1/4 X 1.25L	20	3	MM40SH21H	SPROCKET, 1/2 P, 21T
3	1	1390297	PVC ROLLER ASM	21	8	NNH3/8-16	NUT,HEX,3/8-16
4	2	1390473	MOTOR/REDUCER ASSY	22	2	SSHC01032	1/4-20 X 1/2 HHCS
5	1	1390498	BLOWER/MANIFOLD ASSY	23	2	SSHC01064	1/4-20 X 1 HHCS
6	1	1390979	MOTOR ASSEMBLY	24	1	SSHC25064	3/8-16 X 1,HEX CAP
7	1	1390991	GUARD,PNEUMATICS	25	4	SSHC25080	3/8-16X1-1/4 HHCS
8	1	1391032	CYLINDER ASSY-INFEED SIDE	26	8	SSHC25112	3/8-16 X 1-3/4 HEX HEAD
9	1	1391035	VALVE ASSY, CROSS SEAL	27	8	SSHC25128	3/8-16 X 2 HEX CAP
10	1	1391062	CYL ASSY, LRG INFEED ROLL	28	2	SSSC98112	SCR, SOC CAP 10-32 X 1-3/4
11	1	1391063	CYL ASSY, LRG INFEED ROLL	29	4	WWF3/8	WASHER,FLAT,3/8 OR 10MM
12	2	1391068	ARM, PVC ROLLER	30	4	WWFS1/4	WASHER,FLAT,SAE,1/4
13	1	1391071	CYLINDER ASSY. CROSS SEAL	31	2	WWFS10	WASHER, FLAT, #10, SAE
14	1	13911013	VALVE BANK ASSEMBLY	32	17	WWFS3/8	WASHER,FLAT,SAE,3/8
15	1	1391145	CYLINDER ASSY. CROSS SEAL	33	4	WWL1/4	WASHER,LOCK, 1/4
16	4	1391177	NUT PLATE, GEAR MOTOR MTG	34	2	WWL10	WASHER,LOCK,#10
17	1	1396850	MOTOR MOUNTING ANGLE	35	21	WWL3/8	WASHER,LOCK, 3/8
18	1	1396853	GUARD, CHAIN, INFEED MTR				

Parts

1390498 Blower / Manifold Assembly

AAC Drawing Number 1390498 Rev 1




NO.	QTY	PART #	DESCRIPTION
1	1	1390350	PLUG,1/4" PIPE, MOD
2	1	AAF1/4-BFF	90 DEG ECONO ELBOW, NPTF, 1/4"
3	1	AAQMC-3-3S	FITTING,STRT,3/8NPT,3/8
4	1	AAVM4A	MANIFOLD, 3/8 X 1/4
5	3	MM4554K12	PLUG, 1/4" PIPE
6	1	MM4638K513	PLUG,3/8",HEX SOCKET
7	1	AAF112A-B	NIPPLE,1/4 NPT

Parts

1390979 Motor Assembly

AAC Drawing Number 1390979 Rev 0




ITEM	QTY.	PART NUMBER	DESCRIPTION
1	1	51494	LUBRICANT,MOBIL SHC634
2	1	FF3460	STRAIN RELIEF,LIQ TIGHT, 3/4NP
3	1	FF8465	NUT,LOCK, 3/4NPT,NYLON,BLK
4	1	MM3/4SH	HUB, TAPERLOCK
5	1	MM40SH28H	SPROCKET, 1/2 P, 28T
6	1	MM56438	HORIZONTAL BASE,CI U
7	1	MMF71520B5J	SPEED REDUCER,WORM,
8	1	MMVM3542	MOTOR,3PH,3/4HP,230/460V

Parts

1391032 Cylinder Assembly, Infeed Side

AAC Drawing Number 1391032 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	2	AA1983201FU0311	FLOW CONTL 3/8UNIFIT X3/8
2	1	AACDNCB63380PPV	CYLINDER,AIR,ISO,63BX380S
3	1	AAFSGSM16x15	BEARING,ROD END, FOR DNCB50
4	1	AAFSNC63	REAR PIVOT BRKT, 63MM BORE FESTO

Parts

1391035 Cross Seal Valve Assembly

AAC Drawing Number 1391035 Rev 1




NO.	QTY	PART #	DESCRIPTION
1	1	1391086	MOUNT, VALVE, JUNCTION BOX
2	1	AAE4V41015	VALVE, 1/2" PORTED, 24VDC
3	2	AAFAN400N04	MUFFLER, 1/2NPT, PLASTIC
4	1	AAQME-2-2S	FITTING, ELBOW, 1/2NPT, 1/2
5	2	AAQMT-2-2S	TEE, 1/2NPT-1/2 TUBE
6	1	FF3234	STRAIN RELIEF, LIQ TIGHT
7	1	FF8465	NUT, LOCK, 3/4NPT, NYLON, BLK
8	2	NNK10-32	KEP NUT, 10-32
9	2	SSSC98112	SCR, SOC CAP 10-32 X 1-3/4
10	2	WWFS10	WASHER, FLAT, #10, SAE

Parts

1391062 Cylinder Assembly, Large Infeed Roll

AAC Drawing Number 1391062 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	1	AA1983201FU0311	FLOW CONTRL 3/8UNIFIT X3/8
2	1	AACDNCB63380PPV	CYLINDER,AIR,ISO,63BX380S
3	1	AAFASV510F3R	QUICK EXHAUST,3/8R,3/8T
4	1	AAFSGSM16x15	BEARING,ROD END, FOR DNCB50
5	1	AAFSSNC63	REAR PIVOT BRKT, 63MM BORE FESTO

Parts

1391063 Cylinder Assembly, Large Infeed Roll

AAC Drawing Number 1391063 Rev 1




NO.	QTY	PART #	DESCRIPTION
1	1	AA1983201FU0311	FLOW CONTL 3/8UNIFIT X3/8
2	1	AACDNB63380PPV	CYLINDER,AIR,ISO,63BX380S
3	1	AAFASV510F3R	QUICK EXHAUST,3/8R,3/8T
4	1	AAFSGSM16x15	BEARING,ROD END, FOR DNCB50
5	1	AAFSNC63	REAR PIVOT BRKT, 63MM BORE FESTO

Parts

1391071 Cross Seal Cylinder Assembly

AAC Drawing Number 1391071 Rev 2




ITEM #	QTY.	PART #	DESCRIPTION
1	1	1391072	CYLINDER MOUNT PLATE-END
2	1	1391073	CROSS SEAL CYL. MNT
3	1	1391075	SPACER, MOUNTING PLT,- DNC
4	1	AACDNCB100600PP	CYLINDER, AIR, ISO, 100BX600 METRIC ISO
5	AR*	AAESME8MDS24	SENSOR FOR FESTO ISO CYL
6	1	AAFNC100	FLANGE, MOUNTING PLT,- DNCB100610
7	1	AAFSGM20X15	CLEVIS, ROD, M20 X 1.5
8	2	AAQME-2-2U	FITTING, 1/2T-1/2 UNIFIT
9	1	AAQME-5-8U	QUICK MALE ELBOW- UNIFIT
10	1	AAV78862121	VALVE, BLOCKING, R1/2
11	4	NNH1/2-13	NUT, HEX, 1/2-13
12	4	SSHHC45176	1/2-13X2-3/4 HEX CAP
13	4	SSSCM10X20	CAP SCREW 10MM X 20MM
14	8	WWFS1/2	WASHER, FLAT, 1/2, SAE
15	4	WWL1/2	1/2 LOCK WASHER

Parts

13911013 Valve Bank Assembly

AAC Drawing Number 13911013 Rev 0



13911013 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	8	WWFS10	WASHER, FLAT, #10, SAE	11	1	1391105	PLATE, MOUNTING
2	4	WWL10	WASHER, LOCK, #10	12	1	13911014	VALVE STACK ASSY
3	4	SSSC98040	10-32 X 5/8 SOC CAP	13	1	1391116	MAIN REGULATOR ASSEMBLY
4	4	NNK10-32	KEP NUT, 10-32	14	2	AAMSR20008	REGULATOR, 0-140 PSI RELIEVING, W/BRKT,
5	2	NNK1/4-20	KEP NUT, 1/4-20	15	1	AAQUY-5-4	Y UNION, 5/32X1/4
6	4	NNK8-32	KEP NUT, 8-32	16	6	AAQUT-4-4	QUICK UNION T 1/4X1/4
7	4	WWFS1/4	WASHER, FLAT, SAE, 1/4	17	2	AAQME-4-4	ELBOW, MALE, Q, 1/4 TUBE, 1/4 NPT
8	2	SSHC01048	1/4-20 X 3/4 HEX CAP	18	2	AAQME-5-4	ELBOW, QUICK MALE, 5/32 X 1/4 NPT
9	4	SSSC90096	#8-32 X 1-1/2 SOC CAP SC	19	8	EEPBM5H25C	MOUNT, CABLE TIE, NYLON
10	4	WWF8	WASHER, FLAT, #8	20	2	4130-002	BRACKET, REGULATOR


13911014 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	2156	FTG,GALV,NPPL,CLOSE,1/4	13	2	AAFP18	MUFFLER,1/8 NPT, BRONZ
2	1	2289	FTG,GALV,TEE,1/4	14	4	AAFP28	MUFFLER,1/4 NPT
3	1	273-4-504	CLOSE NIPPLE	15	1	AAMSR20008	REGULATOR, 0-140 PSI RELIEVING, W/BRKT,
4	2	AA3001F-11	FLOW CONT,INLINE,3/8 LINE	16	1	AAQMC-4-4	Male Connector
5	1	AAE4V200M6	MANIFOLD, 6 STATION	17	2	AAQME-4-2S	FITTING,ELBOW,1/4NPT,1/2
6	2	AAE4V200MB	MANIFOLD, BLANK PLATE	18	4	AAQME-4-3S	FITTING,ELBOW,1/4NPT,3/8
7	4	AAE4V21008	VALVE, 1/4" PORTED, 24VDC	19	2	AAQMT-4-3S	TEE,1/4NPT-3/8 TUBE
8	1	AAE4V230C08	VALVE, 1/4",24VDC,CNTR BK	20	1	AAQPR-3-4	QUICK REDUCER 3/8-1/4
9	1	AAF207P-2	COUPLING,1/8 NPT,FEMALE	21	1	AAQUY-3-3	QUICK UNION Y 3/8 X 3/8
10	2	AAF207P-4	COUPLING,1/4 NPT,FEMALE	22	6"	AAIP3/8	3/8" OD POLYURETHANE
11	1	AAF23400-2	"L",BRASS,1/8 FM - 1/8 M	23	3	MM4554K12	PLUG, 1/4" PIPE
12	3	AAF4549K532	NIPPLE,1/4NPT X 1.5L				

Parts

1391145 Cross Seal Cylinder Assembly

AAC Drawing Number 1391145 Rev 2




ITEM #	QTY.	PART #	DESCRIPTION
1	1	1391072	CYLINDER MOUNT PLATE-END
2	1	1391073	CROSS SEAL CYL. MNT
3	1	1391075	SPACER,MOUNTING PLT,- DNC
4	1	AACDNCB100600PP	CYLINDER, AIR, ISO, 100BX600 METRIC ISO
5	1	AAFNC100	FLANGE,MOUNTING PLT,- DNCB100610
6	1	AAFSGM20X15	CLEVIS,ROD,M20 X 1.5
7	2	AAQME-2-2U	FITTING, 1/2T-1/2 UNIFIT
8	1	AAQME-5-8U	QUICK MALE ELBOW- UNIFIT
9	1	AAV78862121	VALVE, BLOCKING, R1/2
10	4	NNH1/2-13	NUT,HEX,1/2-13
11	4	SSHC45176	1/2-13X2-3/4 HEX CAP
12	4	SSSCM10X20	CAP SCREW 10MM X 20MM
13	8	WWFS1/2	WASHER,FLAT,1/2, SAE
14	4	WWL1/2	1/2 LOCK WASHER

Parts

13901283 Input Conveyor # 1

AAC Drawing Number 13901283 Rev 0




13901283 parts list

ITEM	QTY.	PART NUMBER	DESCRIPTION	ITEM	QTY.	PART NUMBER	DESCRIPTION
1	2	1390026	ROD,THOMSON,1-1/4ODX61"L	28	4	MMUCPA207-20	1.25" BEARING
2	1	13901284	FRAME, INPUT, WELDMENT	29	4	NNH1/2-13	NUT,HEX,1/2-13
3	2	1390165	FOUNDATION PLATE	30	2	NNH5/16-18	NUT,HEX, 5/16-18
4	2	1390178	BELT SPACER-IN-FEED	31	30	NNK5/16-18	NUT,KEP,5/16-18
5	1	1390224	ROLLER, DRIVE ASSY	32	1	NNK8-32	NUT,KEP,8-32
6	1	1390310	PLATE, TOP	33	*18.5"	PPP40	CHAIN,#40 RIVET
7	2	1390360	ROLLER ASSY,4-1/4",DRIVE	34	1	PPP40CL	LINK, CONNECTING, #40
8	2	1390365	ROLLER ASSY,4-1/4",IDLER	35	4	SSFC98048	#10-32 X .75 SHCSF
9	4	1390378	PINCH ROLLER AIR CLAMP	36	28	SSHC10080	HEX HEAD, 5/16-18 X 1-1/4
10	7	1390491	SHAFT, STUD	37	2	SSHC10224F	5/16-18 X 3.5 HEX CAP
11	1	1390698	ROLLER, IDLER, FILM	38	8	SSHC45080	1/2-13X1-1/4 HEX CAP
12	2	1390699	WELDMENT, IDLER ROLLER	39	4	SSHC45128	1/2-13 X 2,HEX CAP
13	1	1391077	GATE PIVOT CYLINDER ASSY	40	6	SSPS90024	SCREW, #8-32 X 3/8 LG PAN HD
14	1	1391078	BAR, STOP,ASSM	41	8	SSPS98032	10-32X1/2 PAN HD SLOT
15	1	1391081	INPUT CARRIAGE ASSY	42	1	SSSC90048	#8-32 X 3/4 SOC CAP SC
16	2	1391132	BRACKET, POT MNT.	43	2	SSSC95048	10-24 X 3/4, SOC CAP
17	2	1391133	SHAFT, DANCER BAR	44	10	UUCFB205-16	BEARING, FLANGE, 3 BOLT
18	2	1391147	COVER-POT, DANCER ARM	45	2	UUCFL207-20	1.25" BEARING, FLANGE
19	2	1391151	BAR,DANCER ASBLY	46	8	UUCT207-20	PEER207-TAKEUP-BEARING
20	1	1391432	SHAFT, STUD, LONG	47	16	WWF1/2	WASHER,FLAT,1/2
21	4	CCCL20F	COLLAR,1 1/4" CLAMP TYPE	48	2	WWF10	WASHER, FLAT, #10, COM
22	2	CCCL6F	CLAMP COLLAR- 3/8	49	60	WWF5/16	WASHER,FLAT,5/16
23	AR	FF6657S1102	POTENTIOMETER,PREC,1K	50	6	WWF8	WASHER, FLAT, #8
24	1	MM11/4SH	HUB, TAPERLOCK	51	12	WWL1/2	1/2 LOCK WASHER
25	1	MM1JA	HUB, TAPERLOCK,1 B	52	2	WWL10	WASHER,LOCK,#10
26	1	MM40JA15H	SPROCKET, 1/2 P, 15T	53	6	WWL8	WASHER,LOCK,#8
27	1	MM40SH25H	SPROCKET, 1/2 P, 25T	54	*305"	ZZZSH-310	DOUBLE SIDED TAPE

Parts

1391077 Gate Pivot Cylinder Assembly

AAC Drawing Number 1391077 Rev 1




ITEM NO.	QTY	PART NUMBER	DESCRIPTION
1	1	AACDNCB80160PPV	CYLINDER,AIR,ISO,80X160
2	1	AAFSGSM20x15	ROD END, FEM-20MM X 1.5MM
3	1	AAFSNC80	REAR PIVOT
4	2	AAQME-3-3U	MALE ELBOW 3/8 OD TUBE,3/8UNIFIT
5	2	WWFS3/4	WASHER, .797ID X 1-1/2OD

Parts

1391081 Input Carriage Assembly

AAC Drawing Number 1391081 Rev 0




NO.	QTY	PART #	DESCRIPTION
1	2	1391082	BRACKET, CLEVIS
2	1	1391083	WELDMENT, SLIDE ASSY
3	4	MMP20	LIN.PILLOW-BLOCK,SEALIGN
4	4	NNK5/16-18	KEP NUT, 5/16-18
5	4	SSHC10176	SCREW,HEX CAP
6	16	SSSC98048	10-32 X 3/4 SOC CAP
7	16	WWFS10	WASHER, FLAT, #10, SAE
8	8	WWFS5/16	WASHER,FLAT,SAE,5/16
9	16	WWL10	WASHER,LOCK,#10

Parts

1390BA-PD Pneumatic Diagram

AAC Drawing Number 125951d Rev 0



QTY	ITEM NO.	DESCRIPTION	PART NO.	STOCK SIZE
ATLANTA ATTACHMENT COMPANY				
NAME: DIAGRAM, PNEUMATIC				
2nd DES: 11390BA				
MATERIAL: NEXT METAL FAB				
DES. BY: CHRIS MILLER				
PART NO. 1390BA-PD				
DRAWING NO. 125951D				
REV: DR. BY: CHRIS MILLER				
CK. BY: X XXX				

NO.	REVISION	DATE	DR.	CHK.
1	FINISH			
2	PLAIN ANGLE			
3	COUNTERSINKS			
4	BLIND HOLES			
5	HEAT TREAT			
6	SAND BLAST			
7	PAINT			
8	CLEAR CHROMATE			
9	TIME SAVE			




AIR LINE LEGEND

_____	1/2" AIR LINE
_____	3/8" AIR LINE
_____	1/4" AIR LINE
_____	5/32" AIR LINE


1390BA-WD1 Wiring Diagram, Power

AAC Drawing Number 125932D Rev 0



1390BA-WD4 Wiring Diagram, Safety

AAC Drawing Number 125937d rev 0



5. TRAINING

Check	Description	Time Hrs.
	Safety Instructions	0.5
	Installation <ul style="list-style-type: none"> • Set up • Power On cycle 	1.5
	Operation <ul style="list-style-type: none"> • Individual components • Serial Bus operator label • Operation Description • With / without dustcover • Maintenance Operator Label 	3
	Service <ul style="list-style-type: none"> • Lock out tag out • Operation sequence Mechanical level 	1
	Mechanical Adjustments <ul style="list-style-type: none"> • Table Adjustments • Tension wheel • Clamp fingers • Staplers 	3
	Pneumatic components <ul style="list-style-type: none"> • Plumbing diagram • FRL unit • Solenoid valve manifold • Pressure adjustments • Pressure switch 	1.5
	Electric component <ul style="list-style-type: none"> • Wiring diagram • Photoelectric Sensor 	1.5
	Serial Bus <ul style="list-style-type: none"> • Touch screen • Modules • Program update • Technical screens 	2
	Maintenance Technical Level	1
	Troubleshooting	0.5
	Evaluate any questions.	0.5

Participants: _____

Instructor: _____ Date: _____

Atlanta Attachment Company (AAC) Statement of Warranty

Manufactured Products

Atlanta Attachment Company warrants manufactured products to be free from defects in material and workmanship for a period of eight hundred (800) hours of operation or one hundred (100) days whichever comes first. Atlanta Attachment Company warrants all electrical components of the Serial Bus System to be free from defects in material or workmanship for a period of thirty-six (36) months.

Terms and Conditions:

- AAC Limited Warranty becomes effective on the date of shipment.
- AAC Warranty claims may be made by telephone, letter, fax, or e-mail. All verbal claims must be confirmed in writing.
- AAC reserves the right to require the return of all claimed defective parts with a completed warranty claim form.
- AAC will, at its option, repair or replace the defective machine and parts upon return to AAC.
- AAC reserves the right to make the final decision on all warranty coverage questions.
- AAC warranty periods as stated are for eight hundred (800) hours or one hundred (100) days whichever comes first.
- AAC guarantees satisfactory operation of the machines on the basis of generally accepted industry standards, contingent upon proper application, installation, and maintenance.
- AAC Limited Warranty may not be changed or modified and is not subject to any other warranty expressed or implied by any other agent, dealer, or distributor unless approved in writing by AAC in advance of any claim being filed.

What Is Covered

- Electrical components that are not included within the Serial Bus System that fail due to defects in material or workmanship, which are manufactured by AAC are covered for a period of eight hundred (800) hours.
- Mechanical parts or components that fail due to defects in material or workmanship, which are manufactured by AAC.
- Purchased items (sewing heads, motors, etc.) will be covered by the manufacturers (OEM) warranty.
- AAC will assist in the procurement and handling of the manufacturers (OEM) claim.

What Is Not Covered

- Parts that fail due to improper usage, lack of proper maintenance, lubrication and/or modification.
- Damages caused by; improper freight handling, accidents, fire, and issues resulting from unauthorized service and/or personnel, improper electrical, plumbing connections.
- Normal wear of machine and parts such as Conveyor belts, "O" rings, gauge parts, cutters, needles, etc.
- Machine adjustments related to sewing applications and/or general machine operation.
- Charges for field service.
- Loss of time, potential revenue, and/or profits.
- Personal injury and/or property damage resulting from the operation of this equipment.

Declaración de Garantía



Productos Manufacturados

Atlanta Attachment Company garantiza que los productos de fabricación son libres de defectos de material y de mano de obra durante un periodo de ochocientos (800) horas de operación o cien (100) días cual llegue primero. Atlanta Attachment Company garantiza que todos los componentes del Serial bus son libres de defectos de material y de mano de obra durante un periodo de treinta y seis (36) meses.

Términos y Condiciones:

- La Garantía Limitada de AAC entra en efecto el día de transporte.
- Reclamos de la Garantía de AAC pueden ser realizados por teléfono, carta, fax o correo electrónico. Todo reclamo verbal tiene que ser confirmado vía escrito.
- AAC reserva el derecho para exigir el retorno de cada pieza defectuosa con un formulario de reclamo de garantía.
- AAC va, según su criterio, reparar o reemplazar las máquinas o piezas defectuosas devueltas para AAC.
- AAC reserva el derecho para tomar la decisión final sobre toda cuestión de garantía.
- Las garantías de AAC tiene una validez de ochocientas (800) horas o cien (100) días cual llega primero.
- AAC garantiza la operación satisfactoria de sus máquinas en base de las normas aceptadas de la industria siempre y cuando se instale use y mantenga de forma apropiada.
- La garantía de AAC no puede ser cambiado o modificado y no está sujeto a cualquier otra garantía implicado por otro agente o distribuidor menos al menos que sea autorizado por AAC antes de cualquier reclamo.

Lo Que Está Garantizado

- Componentes eléctricos que no están incluidos dentro del sistema Serial Bus que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un periodo de ochocientas (800) horas.
- Componentes mecánicos que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un periodo de ochocientas (800) horas.
- Componentes comprados (Motores, Cabezales,) son protegidos debajo de la garantía del fabricante.
- AAC asistirá con el manejo de todo reclamo de garantía bajo la garantía del fabricante.

Lo Que No Está Garantizado

- Falla de repuestos a la raíz de uso incorrecto, falta de mantenimiento, lubricación o modificación.
- Daños ocurridos a raíz de mal transporte, accidentes, incendios o cualquier daño como resultado de servicio por personas no autorizados o instalaciones incorrectas de conexiones eléctricas o neumáticas.
- Desgaste normal de piezas como correas, anillos de goma, cuchillas, agujas, etc.
- Ajustes de la máquina en relación con las aplicaciones de costura y/o la operación en general de la máquina.
- Gastos de Reparaciones fuera de las instalaciones de AAC
- Pérdida de tiempo, ingresos potenciales, y/o ganancias.
- Daños personales y/o daños a la propiedad como resultado de la operación de este equipo.

Atlanta Attachment Company
362 Industrial Park Drive
Lawrenceville, GA 30046
770-963-7369
www.atlatt.com

Printed in the USA