Expendable Replacement Parts Catalog

One-Stop Shopping for Expendable Replacement Parts, for AAC & Other Bedding Equipment Suppliers

Log on to our website . . . . **www.atlantapartsdepot.com**

or call toll free. **866-885-5100**
for more information.

Atlanta Parts Depot™
362 Industrial Park Drive
Lawrenceville, GA 30046

Atlanta Parts Depot is a division of Atlanta Attachment Company®.
© 2011 Atlanta Attachment Company. All rights reserved. All materials contained herein are additionally protected by United States copyright laws and may not be used, disclosed, reproduced, distributed, published or sold without the express written consent of Atlanta Attachment Company, which consent may be withheld at Atlanta Attachment's sole discretion. You may not alter or remove any copyright, trademark or other notice from copies of these materials. Atlanta Attachment Company is a registered trademark of Atlanta Attachment Company. Atlanta Parts Depot is a trademark of Atlanta Attachment Company. 04070111411

One-Stop Shopping for Replacement Parts

Atlanta Parts Depot™

A Division of **Atlanta Attachment Company®**

Manufacturing expendable replacement parts for **Atlanta Attachment Company** as well as other sewing equipment companies.

- **Brother**
- **Cash**
- **Consew**
- **Durkopp Adler**
- **Efka**
- **Galkin**
- **Gribetz**
- **Groz-Beckert**
- **Illinois Tool Works**
- **Juki**
- **Meistergram**
- **Mitsubishi**
- **Organ**
- **Pegasus**
- **Pfaff**
- **Porter**
- **Schmetz**
- **Singer**
- **SunStar**
- **Tajima**
- **Union Special**
- **United**
- **Wilcox & Gibbs**
- **Yamato**

We also offer glue, oil, silicone and other accessories.

TO VIEW ONLINE

1) Download your QR Barcode Software from your App Store
2) Scan the code with your mobile device
3) Learn more about our parts replacement abilitiles online at http://www.atlantapartsdepot.com/

Call **1-866-885-5100**
today or email **sales@atlantapartsdepot.com**
to find out how we can help you get up and running.

APD can manage your parts as well with our Parts Management System

Our modular design, not only saves valuable shop space, it will help your staff organize inventory and reduce total maintenance cost.

Each drawer has a detailed drawing located on the inside of the lid with part numbers indicated and areas highlighted.

Partitioned areas with part numbers allow for easy location and to quickly see inventory.

www.atlantapartsdepot.com • sales@atlantapartsdepot.com

Atlanta Parts Depot is a division of Atlanta Attachment Company®

© 2011 Atlanta Attachment Company. All rights reserved.

11225101911

Atlanta Parts Depot ™
362 Industrial Park Drive
Lawrenceville, GA 30046
1-866-885-5100

This is a sampling of parts in our current catalog. We will be updating soon to include over 7,000 parts, middle of 2012.

ATLANTA ATTACHMENT COMPANY

1334

AUTOMATIC PRE-FLANGING GUSSET WORKSTATION

004312

SCREW, 1/8-44X7.9
YAMATO 1804P

004445-G

SCREW,11/64-40X11,1804P

0066601

LOOPER FOR 1804
YAMATO

4003-IS3WT2

SENSOR,THREAD BREAK

SN11316

NEEDLE,SIZE 16

SSM50014

SCREW,SLOTTED SET 9/64
-40X5/32

1335A

AUTOMATIC PILLOWTOP GUSSET RUFFLER WORKSTATION W/AUTOMATIC FLANGING MODULE

001186-G

SCREW,9/64-40X7.8,1804P

003404-G

SCREW,NEEDLE CHUCK

004134-G

SCREW,1/8-44X6.5,1804P

004312

SCREW, 1/8-44X7.9
YAMATO 1804P

© 2004 Atlanta Attachment Company

004445-G

SCREW,11/64-40X11,1804P

0066524

GUARD,NEEDLE 1804 YAMATO

0066599

LOOPER HOLDER, VM1804P YAMATO

0066601

LOOPER FOR 1804 YAMATO

0066621

RETAINER

009142

SCREW F/THROAT PLATE FOR YAMATO VC2700 MACHINES

110126-G

SCREW,M3-0.5X5,MG2002 YAM

120056-G

SCREW,M3-0.5X5,MG2002 YAM

1278-7055B

PROX SWITCH W/PLUG,12 IN .10-30VDC,APPR-ON, ROBOTIC

1325-3602A

BLADE,RUFFLER

1325-3602B

BLADE,RUFFLER,HEAVY DUTY INT RUFFLER

1325-3602C

BLADE,RUFFLER,INT RUFFLER

1325-3773A

BLADE,STRIPPER

1325-3773B

BLADE,STRIPPER,3" CAP

© 2004 Atlanta Attachment Company

1325-3773D

BLADE,STRIPPER,6"CAP.

1325-3773F

BLADE,STRIPPER,LONG

132556-278B

PLATE,PRESSURE

132556-280

SPRING

1335-201

FIXTURE,ALIGNMENT, YAMATO

1335-201A

FIXTURE,ALIGNMENT, SINGER

1825N14S01

NEEDLE CHUCK,1N 302W SINGER

229

SCREW,LOOPER DELFECTOR

23140A

EYE,ELECTRIC,72 INCH CORD

267665

LOOP DEFLECTOR

268602

LOOPER HOLDER

268614M

PLATE,THROAT,1N,300W SINGER

268638

SPREADER

281208

LOOPER,300U SINGER

© 2004 Atlanta Attachment Company

281975

SPREADER,300UX5 SINGER

374107-001

SCREW,THROAT PLATE BACK

39500KM

CUTTER FOR 39500K

40-630

GUIDE WHEEL ASSEMBLY

4003-IS3

SENSOR,THREAD BREAK

4003-IS3WT2

SENSOR,THREAD BREAK

4080-110

MODULE,QUAD INPUT SBUS

4080-120

MODULE,DUAL OPTO-ISO INPUT,SBUS

4080-130

MODULE,QUAD OPTO-ISO OUTPUT,SBUS

4080-140

MODULE,QUAD OUTPUT SBUS

414518

SCREW,THROAT PLATE FRONT

414519

SCREW,NEEDLE SET

414552

SCREW,SPRDR

414638

SCREW,FOOT,OUTER

© 2004 Atlanta Attachment Company

54205A9016

FEED DOG,9N,16 GA

54224A9016

PLATE,THROAT,9N,1/4 GA

54420X9016

FOOT,PRESSER,9N,1/4 GA 1335

547670

WASHER

559057

FOOT,VIBRATING PRESSER

559059

FOOT,LIFTING PRESSER

559060

PLATE,THROAT, STANDARD

559061

FEED DOG,SINGLE NEEDLE,300UX5 SINGER

AACSHH104

CYLINDER,AIR,5/16 FEMALE THREAD

AAEDY59A-10

SWITCH,SOLID STATE NPN SMC,MGP & CXS CYLINDERS

AAEHSKQ

SWITCH,HALL EFFECT BIMBA W/QUICK CONNECT OPTION

AAPR025IF2B

SHOCK ABSORBER

AT301-08A

CUTTER,LOWER

AT301-09

CUTTER,UPPER

© 2004 Atlanta Attachment Company

BBAW-3Z

BEARING,ROD END, FEMALE

BBAW-4

BEARING,ROD END, FEMALE

BBAW-5Z

BEARING,ROD END, FEMALE

BBNTA411

BEARING, THRUST,.250B,.687D,.078W

BBTRA411

WASHER,THRUST, STEEL,.25ID,.67OD,.03T

EEFE-RR2

1" WIDE REFLECTIVE TAPE

FF23SN6LVQ

EYE,SMALL,10-30VDC

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

GG100XL037

GEAR BELT 1/5P 3/8W 50 TEETH

GG150L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,40 TEETH

GG180XL037

BELT,GEAR,1/5 PITCH,3/8 WIDE,90 TEETH

GG187L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,50 TEETH

GG225L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,60 TEETH

GG540L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,144 TEETH

© 2004 Atlanta Attachment Company

GG6R195018

BELT,40 DP, POLYCORD,3/16 WIDE,195 TEETH

GGD540L050

BELT,GEAR,DOUBLE,3/8 PITCH,1/2 WIDE,144 TEETH,54.0 LONG

M1Y88-001

FOOT,SINGLE NEEDLE, MG2002P YAMATO

M1Y88-002

FOOT,SINGLE NEEDLE, MG2002P YAMATO

M2Y88-001

FEED DOG,1 NEEDLE, HEAVY DUTY

M2Y88-002

FEED DOG,1 NEEDLE, HEAVY DUTY

MM1676A12

CATCH,MAGNETIC DOOR

MM9540K22

BUMPER,RUB,.19 ID X .75 OD

MMJ510

EYELET,GREY CERAMIC

SN11316

NEEDLE,SIZE 16

SN62X5721

NEEDLE,SIZE 21,SCHMETZ

SN62X5924

NEEDLE,SIZE 180/24

SN62X8524

NEEDLE,SIZE 180/24



SSM1225

SCREW,PAN HEAD 3/32X56X3.2MM

© 2004 Atlanta Attachment Company

SSM1892

SCREW

SSM1900

SCREW,1/8-44X2.4

SSM22593

SCREW,FILLISTER HEAD .124-50X9/32

SSM50014

SCREW,SLOTTED SET 9/64 -40X5/32

1335M

PILLOW-TOP GUSSET RUFFLER WORKSTATION

001186-G

SCREW,9/64-40X7.8,1804P

003404-G

SCREW,NEEDLE CHUCK

004312

SCREW, 1/8-44X7.9 YAMATO 1804P

004445-G

SCREW,11/64-40X11,1804P

0066524

GUARD,NEEDLE 1804 YAMATO

0066601

LOOPER FOR 1804 YAMATO

0066621

RETAINER

009142

SCREW F/THROAT PLATE FOR YAMATO VC2700 MACHINES

© 2004 Atlanta Attachment Company

110126-G

SCREW,M3-0.5X5,MG2002 YAM

120056-G

SCREW,M3-0.5X5,MG2002 YAM

1278-7055B

PROX SWITCH W/PLUG,12 IN .10-30VDC,APPR-ON, ROBOTIC

1335M-2002C

RUFFLER BLADE 12 TPI 3.3" LONG

1335M-2002D

BLADE,RUFFLER,HD

1825N14S01

NEEDLE CHUCK,1N 302W SINGER

1862N14001

NEEDLE CHUCK,1N 1804A YAMATO

1862N94016

NEEDLE CHUCK,9N,1/4 GA 1804P YAMATO

1888N12S01

FEED DOG,1N

1888N13S01

PLATE,NEEDLE,SN, RUFFLER YAMATO 1804A

2109334

LOOPER,LOWER AZF8700 YAMATO

2109343

LOOPER,UPPER AZF8700 YAMATO

2121107

CUTTER,UPPER,TRIM AZF8600 YAMATO

2121111

CUTTER,LOWER,TRIM AZF8600 YAMATO

© 2004 Atlanta Attachment Company

268614M

PLATE,THROAT,1N,300W SINGER

268638

SPREADER

32006525

FOOT,MODIFIED 3200

4080-110

MODULE,QUAD INPUT SBUS

4080-120

MODULE,DUAL OPTO-ISO INPUT,SBUS

4080-130

MODULE,QUAD OPTO-ISO OUTPUT,SBUS

4080-140

MODULE,QUAD OUTPUT SBUS

4209201-G

NEEDLE GUARD,REAR, MG2002P

4209325

LOOPER,MG2004 YAMATO

54205A9016

FEED DOG,9N,16 GA

54224A9016

PLATE,THROAT,9N,1/4 GA

54420X9016

FOOT,PRESSER,9N,1/4 GA 1335

AA198-5106FC

ELEMENT,FILTER COALESCING FIL AA198 -5106

AA198-5106FR

ELEMENT,FILTER REG ON AA198-5106

© 2004 Atlanta Attachment Company

AAEHSKQ

SWITCH,HALL EFFECT BIMBA W/QUICK CONNECT OPTION

B1103481F00

PLATE,THROAT 481 JUKI

B1613481F00-G

FEED DOG,481 JUKI

B2030481000

LOOPER FOR 481 JUKI

B21264810A0

SPREADER 481 JUKI

EEFE-RR2

1" WIDE REFLECTIVE TAPE

EENC256

ENCODER,SBUS,256,1/4

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

GG100XL037

GEAR BELT 1/5P 3/8W 50 TEETH

GG110XL75U

GEAR BELT 3/8P 1/2W 50 TEETH CLEAR POLY STEEL

GG169L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,45 TEETH

GG187L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,50 TEETH

M1I91-019

FOOT,SN,NF,RUFFLER PLAIN SEWER,11335M

M1V67-014

FOOT,SN,RUFFLER EXTENDED SHOE,1804A YAMATO

© 2004 Atlanta Attachment Company

M1Y88-002A

FOOT,SN,MG2002P YAMATO

M2I91-008

FEED DOG,5 ROW,10 TPI F/REV FEED,281 SINGER

M2Y88-002

FEED DOG,1 NEEDLE, HEAVY DUTY

MF00A0834

CUTTER,MOVEABLE, 6Z1591

MF00A0838

CUTTER,FIXED, 6Z0958

SN62X5721

NEEDLE,SIZE 21,SCHMETZ

SN62X5924

NEEDLE,SIZE 180/24

SND0X521

NEEDLE,DOX5 130/21 BX/100

SNDBX1140

NEEDLE,SIZE 140

SNDLX1140

NEEDLE,SCHMETZ, SIZE140/22 BX/100

SNTVX7X110

NEEDLE,SZ 110/18, SCHMETZ ROUND POINT

SS-6121220-TP-G

SCREW,3/16-28X11.5,481 JU

SS-7111410-TP-G

SCREW,11/64-40X14,481 JUK

SS2110920TP

SCREW,THROAT PLATE

© 2004 Atlanta Attachment Company

SS7080510TP

SCREW,NEEDLE SET 481 JUKI

SS7090520TP

SCREW



SSM1225

SCREW,PAN HEAD 3/32X56X3.2MM

SSM1892

SCREW

ZZZSR-109

ACCRO LUBE GREASE 1.5 TUBES

1335SA

SEMI-AUTOMATIC PILLOWTOP GUSSET RUFFLER WORKSTATION WITH AUTO FLANGING MODULE

1325-3602A

BLADE,RUFFLER

1325-3602B

BLADE,RUFFLER,HEAVY DUTY INT RUFFLER

1325-3602C

BLADE,RUFFLER,INT RUFFLER

1325-3773A

BLADE,STRIPPER

1325-3773B

BLADE,STRIPPER,3" CAP

1325-3773D

BLADE,STRIPPER,6"CAP.

© 2004 Atlanta Attachment Company

132556-278B

PLATE,PRESSURE

211156

SPREADER LEFT

211161

LOOPER,LOWER E52L SERIES

211726

PLATE,THROAT,LH, REPLACMNT 11961W17

23140A

EYE,ELECTRIC,72 INCH CORD

277014A

SPREADER,2 THREAD SERGER EX5204

277034

LOPPER,LOWER HIGH LIFT,EX52 SERIES

277504R50M

PLATE,THROAT,FR, REPLACMNT 11961W17

39500KM

CUTTER FOR 39500K

AAEHSKQ

SWITCH,HALL EFFECT BIMBA W/QUICK CONNECT OPTION

AAPR025IF2B

SHOCK ABSORBER

EEFE-RR2

1" WIDE REFLECTIVE TAPE

FF23SN6LVQ

EYE,SMALL,10-30VDC

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

© 2004 Atlanta Attachment Company

FFT18FF100Q

EYE,FIXED FIELD W/PLUG,4 IN DIST

GG100XL037

GEAR BELT 1/5P 3/8W 50 TEETH

GG150L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,40 TEETH

GG180XL037

BELT,GEAR,1/5 PITCH,3/8 WIDE,90 TEETH

GGD540L050

BELT,GEAR,DOUBLE,3/8 PITCH,1/2 WIDE,144 TEETH,54.0 LONG

MM742-27BN

BULB,12V HALOGEN FTA MR11 W/GLASS LENS

MMJ510

EYELET,GREY CERAMIC

SN11316

NEEDLE,SIZE 16

SN62X5721

NEEDLE,SIZE 21,SCHMETZ

SN62X5924

NEEDLE,SIZE 180/24

SN62X8524

NEEDLE,SIZE 180/24

SNB27140

NEEDLE,SIZE 140 SPEC B27,BX/100

UM-68D10

STONE,SHARPENING SKS4,3/8" BORE

UM-68KH10

HOLDER,CUTTER

© 2004 Atlanta Attachment Company

UM-SKS10

SHARPENER,PORTABLE CUTTER REPLACES UM-SKS4

ZZZSR-202

STAPLES, B8,1/4" (STANLEY BOSTITCH

ZZZSR-20W

SCIZZORS,10"

ZZZSR-220

STAPLER,B-8 PLIER (STANLEY BOSTICH

1337

FLANGING WORKSTATION WITH PNEUMATIC FLOATATION TABLE

0066621

RETAINER

115-65900

UPPER CUTTER (CARBIDE) MOG-3716 JUKI

115-66502

LOWER CUTTER MOG -3716 JUKI

118-90001

NEEDLE GUARD,LOWER LOOPER MOG-3716 JUKI

120-15400

NEEDLE HOLDER GUARD MOG-3716 JUKI

123-83501

LOOPER, UPPER MOG -3716 JUKI

123-84202

LOOPER,LOWER MOG -3716 JUKI

123-84400

LOOPER,CHAIN MOG-3716

© 2004 Atlanta Attachment Company

1337001

GUARD,FRONT NEEDLE

1337002

GUARD, REAR NEEDLE

AAEVQZ2121

VALVE,BODY PORTED WITH FOOT MOUNTING

EEFE-RR2

1" WIDE REFLECTIVE TAPE

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

GG140XL037

BELT,GEAR,1/5P,3/8W,70 TEETH

GG140XL75U

BELT,GEAR,1/5 PITCH,3/4 WIDE,70 TEETH,CLEAR POLY,STEEL

GG356XL037U

BELT,GEAR,KEVLAR CORE,URE 1/5P,3/8,178T

M1J96-008

FOOT,TBF,7/8GA MOG3716 JUKI

M2J96-002

FEED DOG,MAIN MOG3716 JUKI

M2J96-003

FEED DOG,DIFFERENTIAL MOG3716 JUKI

M3J96-003

PLATE,THROAT,3/4GA MOG3716 JUKI

M4J96-002

NEEDLE CHUCK,3/4 GA MOG3716 JUKI

M5J96-001

LOOPER HOLDER MOG3716 JUKI

© 2004 Atlanta Attachment Company

M8J96-002

NEEDLE GUARD, FRONT,7/8 GA LEFT NEEDLE,AAP49J96

M8J96-003

NEEDLE GUARD,REAR,7/8 GA LEFT NEEDLE, AAP49J96

RRE29C

SPRING,EXT,.035D WIRE 3/8 OD X 1.5L

SN135X722

NEEDLE,SIZE 140/22 135X7,135X5,BX/100

SS8080310TP

SCREW,SET,SLOTTED,1/8 -44 2.8L,MOG-3716 JUKI

1338

CAP FLANGER

118-43208

FILTER,OIL

120-15301

NEEDLE HOLDER (GUARD)

123-83501

LOOPER, UPPER MOG -3716 JUKI

123-84202

LOOPER,LOWER MOG -3716 JUKI

123-84400

LOOPER,CHAIN MOG-3716

123-84509

GUARD,NEEDLE,FRONT

© 2004 Atlanta Attachment Company

40-630

GUIDE WHEEL ASSEMBLY

AAEVQZ2121

VALVE,BODY PORTED WITH FOOT MOUNTING

EEFE-RR2

1" WIDE REFLECTIVE TAPE

EEK10P11D1

RELAY,24VDC,15A AC, PLUG-IN

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

GG6R195018

BELT,40 DP, POLYCORD,3/16 WIDE,195 TEETH

M1J27-002A

FOOT,PRESSER

M2J27-001

FEED DOG,MAIN

M2J27-002A

FEED DOG,TOP

M3J27-001

PLATE,THROAT

MMAS568A202

O-RING,1/8 X 1/2 OD

SN135X722

NEEDLE,SIZE 140/22 135X7,135X5,BX/100

SS-6090620-TP-G

SCREW,MO3916J JUKI

SS-7110740-TP-G

SCREW,11/64-40X7, MO3916J

© 2004 Atlanta Attachment Company

SS-9090410-TP-G

SCREW,MO3916J JUKI

SS8080310TP

SCREW,SET,SLOTTED,1/8 -44 2.8L,MOG-3716 JUKI

SS9111050SP

SCREW

1339

SEMI-AUTOMATIC PANEL BINDER

120-15301

NEEDLE HOLDER (GUARD)

123-83501

LOOPER, UPPER MOG -3716 JUKI

123-84202

LOOPER,LOWER MOG -3716 JUKI

123-84400

LOOPER,CHAIN MOG-3716

BBB-66

BEARING,NEEDLE,.375B

GG140XL037

BELT,GEAR,1/5P,3/8W,70 TEETH

M1J27-002

FOOT,PRESSER FOR 11339HSJ27B,MOJ3916 JUKI

M2J27-002

FEED DOG,MAIN FOR 11339HSJ27B,MOJ3916 JUKI

© 2004 Atlanta Attachment Company

M2J27-004

FEED DOG,TOP FOR 11339HSJ27B,MOJ3916 JUKI

M3J27-002

PLATE, THROAT FOR 11339HSJ27B,MOJ3916 JUKI

SN135X722

NEEDLE,SIZE 140/22 135X7,135X5,BX/100

SS6090620TP

SCREW,BOBBIN CASE OPENING

SS7110740TP

SCREW,NIPPER LINK HOOK

SS8080310TP

SCREW,SET,SLOTTED,1/8 -44 2.8L,MOG-3716 JUKI

SS9090410TP

SCREW

SS9111050SP

SCREW

1345

TAPE EDGE WORKSTATION

10148

SPRING,LOOPER THREAD TENSION

13451021

GEAR RACK,CORNER

13453211

BELT,HEAD DRIVE,10MMx108"

13459007

CABLE, 5K POT, 5'

© 2004 Atlanta Attachment Company

13459008

CABLE, 5K POT, 6"

229

SCREW,LOOPER DELFECTOR

267665

LOOP DEFLECTOR

267718

RETAINER,PRESSER BAR

268032

SPRING,FACE PLATE LOCK

268052

ROD,LOOPER THREAD TAKE UP

268512

GUIDE,NEEDLE THREAD

276025

BALL,PRESSER BAR SPRING ARM

281208

LOOPER,300U SINGER

281912

NEEDLE BAR

281929

LEVER,FOOT LIFTER

281975

SPREADER,300UX5 SINGER

374107-001

SCREW,THROAT PLATE BACK

414518

SCREW,THROAT PLATE FRONT

© 2004 Atlanta Attachment Company

414519

SCREW,NEEDLE SET

414552

SCREW,SPRDR

414638

SCREW,FOOT,OUTER

415291

STUD,TENSION,LOOPER THREAD

415292

STUD,CLAMPING

50326

STUD,NEEDLE THREAD TENSION

541198

NUT,LOOPER CAR CRANK CLAMP

541452

NUT,THUMB,LOOPER THREAD TENSION

547670

WASHER

548459

WASHER,STUD

559057

FOOT,VIBRATING PRESSER

559059

FOOT,LIFTING PRESSER

559060

PLATE,THROAT, STANDARD

559061

FEED DOG,SINGLE NEEDLE,300UX5 SINGER

© 2004 Atlanta Attachment Company

AAOEM.5BSA

SHOCK ABSORBER

BB305702C

BEARING,CAM ROLLER

BB305705C

BEARING,CAM ROLLER

BB62032RS1

BEARING,BALL,DEEP GROOVE

BB6204-2Z

BEARING,BALL,DEEP GROOVE

BB62062RS1

BEARING,BALL,DEEP GROOVE

EE3X01

BLOCK,PUSH BUTTON CONTACT

EE3X10

BLOCK,PUSH BUTTON CONTACT

EE49111AS

PUSH BUTTON SWITCH ASSEMBLY

EECA491024

CONTACTOR,MINI,240V

EED5N157

LAMP,INC, BAYONET,24V,1.4W

EEK10P11D1

RELAY,24VDC,15A AC, PLUG-IN

EERHU02800

BRUSH HOLDER FOR SLIP RING ASSEMBLY

EERHU45066C

BRUSH FOR SLIP RING ASSEMBLY

© 2004 Atlanta Attachment Company

FF002304

TRANSDUCER,POT, SLIDE,80MM

FF002304A

LINEAR TRANSDUCER ASSEMBLY

FF2938947

POWER,SUP, SWITCHER,24V

FFL722C

CIRCUIT BREAKER, THERM-MAG

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

FFUZP101

PROX SENSOR,SUNX,10 -30VDC

FFUZP111

PROX SENSOR,SUNX,10 -30VDC

GG124L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,33 TEETH

IIS016X112

SPRING PIN,1/4X1-3/4

MM9540K53

BUMPER,RUBBER,3/8"

MM98335A064

PIN,COTTER

MMB6002

MOUNT,VIBRATION, MOTOR

MMNSS1040M1

GEAR,DRIVE,40 TEETH,10 PITCH W/KEY

MMVPS-112

BLOCK,PILLOW,3/4 BORE

© 2004 Atlanta Attachment Company

PPM644M

PULLEY,V-BELT,MOTOR

RRLC040C15

SPRING, COMP,.040X.24X1.38

RRLC063F6

SPRING, COMP,.063X42X1.25

RRLE055E10

SPRING, EXTENSION,.005X.5X4

SN62X5924

NEEDLE,SIZE 180/24

SSSCM5X16

SCREW,SOCKET CAP,M5 -0.80X16

ZX3825

V BELT,3/8 X 25"

ZX3827

V BELT,3/8 X 27"

1347D

FRENCH PILLOWTOP BORDER WORKSTATION

1347016

FOOT,PRESSER, MOD,11347D

1347072

PLATE,THROAT,SJUKI -481U

4003-IS3WT2

SENSOR,THREAD BREAK

B1613481F00

FEED DOG, JUKI 481U

© 2004 Atlanta Attachment Company

B2030481000

LOOPER FOR 481 JUKI

B21264810A0

SPREADER 481 JUKI

B2311481000A

NEEDLE GUARD,481 JUKI

EEFE-RR2

1" WIDE REFLECTIVE TAPE

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

FFT18FF100Q

EYE,FIXED FIELD W/PLUG,4 IN DIST

FFT18FF25Q

EYE,FIXED FIELD

M1I91-020

FOOT,SN,LEFT EXT PLAIN SEWER,11347D

SNTVX7X110

NEEDLE,SZ 110/18, SCHMETZ ROUND POINT

SS2110920TP

SCREW,THROAT PLATE

SS6121220TP

SCREW

SS7080510TP

SCREW,NEEDLE SET 481 JUKI

SS7090520TP

SCREW

SS7111410TP

SCREW

© 2004 Atlanta Attachment Company

ZZZSR-202

STAPLES, B8,1/4" (STANLEY BOSTITCH

ZZZSR-20W

SCIZZORS,10"

ZZZSR-220

STAPLER,B-8 PLIER (STANLEY BOSTICH

1959

AUTOMATIC HANDLE MAKING WORKSTATION FOR BORDERS

001186-G

SCREW,9/64-40X7.8,1804P

004312

SCREW, 1/8-44X7.9 YAMATO 1804P

004445-G

SCREW,11/64-40X11,1804P

0066524

GUARD,NEEDLE 1804 YAMATO

0066601

LOOPER FOR 1804 YAMATO

0066621

RETAINER

009142

SCREW F/THROAT PLATE FOR YAMATO VC2700 MACHINES

54205A9016

FEED DOG,9N,16 GA

© 2004 Atlanta Attachment Company

54224A9016

PLATE,THROAT,9N,1/4 GA

54420X9016

FOOT,PRESSER,9N,1/4 GA 1335

FF313500

FUSE,1/2 AMP,SLO BLOW,3AG

SN11316

NEEDLE,SIZE 16



SSM1225

SCREW,PAN HEAD 3/32X56X3.2MM

SSM50014

SCREW,SLOTTED SET 9/64 -40X5/32

ZX3825

V BELT,3/8 X 25"

ZX3836

V BELT,3/8 X 36"

ZX3837

V BELT,3/8 X 37"

1961

DUAL PURPOSE WORKSTATION FOR BORDERS AND GUSSETS

000541

GAUGE,TIMING,E52L HIGH LIFT PEGASUS

000593-91

GAUGE,TIMING,EX5203H HIGH LIFT PEGASUS

© 2004 Atlanta Attachment Company

1961-002

CUTTER,LOWER,LH,WIDE CUT 10MM,PEGASUS

1961-003

CUTTER,UPPER,LH,WIDE CUT 10MM,PEGASUS

201121A

CUTTER,UPPER E52 SERIES

201230CM

SHOE,RH,MOD,D1961

202295

CUTTER,LOWER 1907-02, E52

205607

CUTTER,UPPER E52L SERIES

205609

CUTTER,LOWER

210356

LOOPER,LOWER

210371

FINGER FOR 1510-728 FOOT

210512

SPREADER,UPPER

210801

PLATE,THROAT,5MM

211146

GUARD,FRONT NEEDLE E52L PEGASUS

211156

SPREADER LEFT

211161

LOOPER,LOWER E52L SERIES

© 2004 Atlanta Attachment Company

211621

NEEDLE GUARD,REAR E52L PEGASUS

211726

PLATE,THROAT,LH, REPLACMNT 11961W17

211726M

PLATE,THROAT,LH, REPLACEMENT

211726M1

PLATE,NEEDLE,HEAVY DUTY,LEFT HAND

211735

FEED DOG,MAIN

211738

FEED DOG,DIFFERENTIAL

211744M

SHOE,LH,MOD,1961

277000

CUTTER,UPPER, WIDE,10MM

277004

GUARD,NEEDLE

277005

GUARD,FRONT NEEDLE EX52 SERIES

277009

CUTTER,LOWER, WIDE,10MM

277014A

SPREADER,2 THREAD SERGER EX5204

277034

LOPPER,LOWER HIGH LIFT,EX52 SERIES

277303-16F

FEED DOG,MAIN EX5204 PFAFF

© 2004 Atlanta Attachment Company

277305-16F

DIFFERENTIAL FEED DOG FOR M2P86-001

277378A25-G

FEED DOG, MAIN,277511S70M

27738025-G

FEED DOG,DIFFERENTIAL

277504R50

PLATE,NEEDLE

277504R50M

PLATE,THROAT,FR, REPLACMNT 11961W17

277511S70M

PLATE,THROAT,6.4 GA

EJK1SC

Z-MAX WITH SCREW CONTROL

FFQM42VN6A

EYE,ELECTRIC,10-30VDC

FFT18FF100Q

EYE,FIXED FIELD W/PLUG,4 IN DIST

MM35

CHAIN,SINGLE STRAND

MM35CL

CONNECTING LINK

MM742-27BN

BULB,12V HALOGEN FTA MR11 W/GLASS LENS

SNB27140

NEEDLE,SIZE 140 SPEC B27,BX/100

UM-68D10

STONE,SHARPENING SKS4,3/8" BORE

© 2004 Atlanta Attachment Company

UM-68KH10

HOLDER,CUTTER

UM-68KH10M

JIG,CUTTER, LOWE4R,10MM WIDE

UM-SKS10

SHARPENER,PORTABLE CUTTER REPLACES UM-SKS4

ZZZSR-202

STAPLES, B8,1/4" (STANLEY BOSTITCH

ZZZSR-20W

SCIZZORS,10"

ZZZSR-220

STAPLER,B-8 PLIER (STANLEY BOSTICH

1962

DUAL PURPOSE WORKSTATION FOR BORDERS & GUSSETS, OVER/UNDER DESIGN

000593-91

GAUGE,TIMING,EX5203H HIGH LIFT PEGASUS

201230CM

SHOE,RH,MOD,D1961

210356

LOOPER,LOWER

210371

FINGER FOR 1510-728 FOOT

210512

SPREADER,UPPER

211146

GUARD,FRONT NEEDLE E52L PEGASUS

© 2004 Atlanta Attachment Company

211621

NEEDLE GUARD,REAR E52L PEGASUS

277000

CUTTER,UPPER, WIDE,10MM

277009

CUTTER,LOWER, WIDE,10MM

277014A

SPREADER,2 THREAD SERGER EX5204

277034

LOPPER,LOWER HIGH LIFT,EX52 SERIES

277378A25

FEED DOG, DIFFERENTIAL

27738025

FEED DOG, MAIN

277511S70M

PLATE,THROAT,6.4 GA

FFT18FF100Q

EYE,FIXED FIELD W/PLUG,4 IN DIST

MM742-27BN

BULB,12V HALOGEN FTA MR11 W/GLASS LENS

SNB27140

NEEDLE,SIZE 140 SPEC B27,BX/100

UM-68D10

STONE,SHARPENING SKS4,3/8" BORE

UM-68KH10M

JIG,CUTTER, LOWE4R,10MM WIDE

UM-SKS10

SHARPENER,PORTABLE CUTTER REPLACES UM-SKS4

© 2004 Atlanta Attachment Company

ZZZSR-202

STAPLES, B8,1/4" (STANLEY BOSTITCH

ZZZSR-20W

SCIZZORS,10"

ZZZSR-220

STAPLER,B-8 PLIER (STANLEY BOSTICH

300UX5

SINGLE NEEDLE, TWO-THREAD CHAINSTITCH SEWING MACHINE

10148

SPRING,LOOPER THREAD TENSION

229

SCREW,LOOPER DELFECTOR

267665

LOOP DEFLECTOR

267718

RETAINER,PRESSER BAR

268032

SPRING,FACE PLATE LOCK

268052

ROD,LOOPER THREAD TAKE UP

268512

GUIDE,NEEDLE THREAD

276025

BALL,PRESSER BAR SPRING ARM

© 2004 Atlanta Attachment Company

281208

LOOPER,300U SINGER

281912

NEEDLE BAR

281929

LEVER,FOOT LIFTER

281975

SPREADER,300UX5 SINGER

374107-001

SCREW,THROAT PLATE BACK

414518

SCREW,THROAT PLATE FRONT

414519

SCREW,NEEDLE SET

415291

STUD,TENSION,LOOPER THREAD

415292

STUD,CLAMPING

50326

STUD,NEEDLE THREAD TENSION

541198

NUT,LOOPER CAR CRANK CLAMP

541452

NUT,THUMB,LOOPER THREAD TENSION

548459

WASHER,STUD

559057

FOOT,VIBRATING PRESSER

© 2004 Atlanta Attachment Company

559059

FOOT,LIFTING PRESSER

559060

PLATE,THROAT, STANDARD

559061

FEED DOG,SINGLE NEEDLE,300UX5 SINGER

SN62X5924

NEEDLE,SIZE 180/24

SSSCM5X16

SCREW,SOCKET CAP,M5 -0.80X16

3200

AUTOMATIC CONTINENTAL OR PLAIN FOUNDATION AND MATTRESS BORDER WORKSTATION WITH DUAL OVERLOCK MODULE

003637

SCREW,NEEDLE,YAMATO

005345

SCREW,11/64-40-5.4 8600 YAMATO

007610

SCREW,M4-0.7X10, DOUBLE CHAINING LOOPER

007627

SCREW,M4-0.7X6,NEEDLE GUARD REAR

011-020

MOTOR,STEPPER WITH PLUG 450 OZ/IN

110002

SCREW,M3-0.5X5,NEEDLE GUARD FRONT

© 2004 Atlanta Attachment Company

110004

SCREW,TOP FEED DOG 8600 YAMATO

110026

SCREW VF2500 YAMATO

110027

SCREW VC2700 YAMATO

11003230

UPPER CUTTER ASSY W/SHAFT

110036

SCREW,M3-0.5X6.5, NEEDLE GUARD

1278-7055B

PROX SWITCH W/PLUG,12 IN .10-30VDC,APPR-ON, ROBOTIC

1434-02

PLATE,NEEDLE,5 ROW 241,251,281

160003

SCREW,LOWER LOOPER

2109081

FEED DOG,MAIN YAMATO 8600

2109082

FEED DOG,AUXILIARY YAMATO 8600

2109089

FEED DOG,DIFFERENTIAL YAMATO 8600

2109211

NEEDLE GUARD,FRONT DBL CHN STITCH, AZF8600YAM

2109212

NEEDLE GUARD,REAR AZF8600-G YAMATO

2109214

NEEDLE GUARD,AZF8700 YAM

© 2004 Atlanta Attachment Company

2109334

LOOPER,LOWER AZF8700 YAMATO

2109335

LOOPER,DOUBLE CHAINING AZF8700 YAMATO

2109343

LOOPER,UPPER AZF8700 YAMATO

2121107

CUTTER,UPPER,TRIM AZF8600 YAMATO

2121111

CUTTER,LOWER,TRIM AZF8600 YAMATO

2127550

FOOT,PRESSER, COMPLETE YAMATO 8600

2128604

PLATE,SWITCH YAMATO 8600

2129070

FEED DOG,TOP,AZF8600-G YAMATO

2129200

NEEDLE GUARD,FRONT, OVRLCK,AZF8600-G YAMATO

3200001

BLADE,TOP,18" CAPACITY

32004002

BLADE,BOTTOM,18" CAPACITY

32006525

FOOT,MODIFIED 3200

4080-110

MODULE,QUAD INPUT SBUS

4080-120

MODULE,DUAL OPTO-ISO INPUT,SBUS

© 2004 Atlanta Attachment Company

4080-130

MODULE,QUAD OPTO-ISO OUTPUT,SBUS

4080-140

MODULE,QUAD OUTPUT SBUS

A-2014-39

MICRO SWITCH

AA198-2201

FLOW CONTROL,1/8PTX5/32

AA198-2202

FLOW CONTROL, RC,1/8X1/4

AA198-3000

REGULATOR,INTERFACE

AA198-5106FC

ELEMENT,FILTER COALESCING FIL AA198 -5106

AA198-5106FR

ELEMENT,FILTER REG ON AA198-5106

AA198RA508

FLOW CONTROL,5/32 X 1/8

AA198RA510

FLOW CONTROL,5/32X10 -32

AA2000F-03

FLOW CONTROL,IN-LINE,5/32

AA2001F-03

FLOW CONTROL,IN-LINE,5/32

AA3000F-07

FLOW CONTROL,IN-LINE,1/4

AAEDY59A-10

SWITCH,SOLID STATE NPN SMC,MGP & CXS CYLINDERS

© 2004 Atlanta Attachment Company

AAEHSKQ

SWITCH,HALL EFFECT BIMBA W/QUICK CONNECT OPTION

AAQMC-5-8

QUICK MALE CONNECTOR,5/32X1/8

AAQME-4-8

ELBOW,QUICK MALE,1/4X1/8

AAQME-5-8

QUICK MALE ELBOW

AATP4-1

1/4" OD POLYURETHANE

AATP5/32

5/32" OD POLYURETHANE

AAVF51FM1B

AIR/ELECTRIC PRESSURE SWITCH,ADJUSTABLE,0 -100 PSI

ATC2-Y2303A

CUTTER,LOWER

EEFE-RR2

1" WIDE REFLECTIVE TAPE

EENC025

ENCODER,SERIAL BUS,025,1/8

EENC256

ENCODER,SBUS,256,1/4

EEVX80C1

SWITCH,HALL EFFECT

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

GG1252L100ST

BELT,GEAR,3/8 PITCH,1.0 WIDE,334 TEETH

© 2004 Atlanta Attachment Company

GG187L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,50 TEETH

GG210L050

BELT,GEAR,3/8 PITCH,1/2 WIDE,56 TEETH



GG450L100ST

BELT,GEAR,3/8 PITCH,1.0 WIDE,120 TEETH

M2I91-008

FEED DOG,5 ROW,10 TPI F/REV FEED,281 SINGER

M90806002

SCREW,1/8-44X6MM

M90815002

SCREW

M91106011

SCREW,SLOTTED,11/64-40, LS2-2210 MITSUBISHI

MF00A0120

BOBBIN,LS2-1380 MIT

MF00A0123

BOBBIN,LS2-1380 MIT

MF00A0834

CUTTER,MOVEABLE, 6Z1591

MF00A0838

CUTTER,FIXED, 6Z0958

MF10A0104

FEED DOG MITSUBISHI LS2-1380

MF40E0125

CASE,BOBBIN LS2-1380 MITSUBISHI

MF95A1101

CASE,BOBBIN LS2-1380 MITSUBISHI

© 2004 Atlanta Attachment Company

SND0X521

NEEDLE,DOX5 130/21 BX/100

SNDLX1140

NEEDLE,SCHMETZ, SIZE140/22 BX/100

ZX3829

V BELT,3/8 X 19"

ZX3848

V BELT,3/8 X 48"

ZZZSR-109

ACCRO LUBE GREASE 1.5 TUBES

3300

AUTOMATIC HANDLE TACKER, BORDER MEASURE AND CLOSE WORKSTATION

1278-7055B

PROX SWITCH W/PLUG,12 IN .10-30VDC,APPR-ON, ROBOTIC

33003101

CLAMP,TOE

33003121A

PLATE,HANDLE RETAINING

33003137

SPRING,CLAMP

33004001

BLADE,TOP,15" CAP

33004002

BLADE,BOTTOM,15" CAP

© 2004 Atlanta Attachment Company

33005324

CUTTER,UPPER

33005350

SHUTTLE ASSEMBLY, RIGHT HAND

33005353

CYLINDER,DUAL ROD

33505324

CUTTER,UPPER,LEFT HAND

33505350

SHUTTLE ASSEMBLY,LEFT HAND

4080-110

MODULE,QUAD INPUT SBUS

4080-120

MODULE,DUAL OPTO-ISO INPUT,SBUS

4080-130

MODULE,QUAD OPTO-ISO OUTPUT,SBUS

4080-140

MODULE,QUAD OUTPUT SBUS

70-102

CUTTER,BOTTOM

AA198-2201

FLOW CONTROL,1/8PTX5/32

AA198-5032

GAUGE,PRESSURE,0-60 PSI

AA198-5106FC

ELEMENT,FILTER COALESCING FIL AA198 -5106

AA198-5106FR

ELEMENT,FILTER REG ON AA198-5106

© 2004 Atlanta Attachment Company

AA198RA508

FLOW CONTROL,5/32 X 1/8

AA2000F-03

FLOW CONTROL,IN-LINE,5/32

AA3000F-07

FLOW CONTROL,IN-LINE,1/4

AAC00705DXP

CYLINDER,AIR

AACEV-16-4

CYLINDER,DIAPHRAGM 4MM STROKE

AACM043D

CYLINDER,3/4 BORE,3.0 STROKE

AAEDY59A-10

SWITCH,SOLID STATE NPN SMC,MGP & CXS CYLINDERS

AAEHSKQ

SWITCH,HALL EFFECT BIMBA W/QUICK CONNECT OPTION

AAESY3140

VALVE,REPLACEMENT

AAF10289

TEE,BRASS,1/8 NPT FEMALE

AAQMC-4-8

QUICK MALE CONNECTOR

AAQMC-5-8

QUICK MALE CONNECTOR,5/32X1/8

AAQME-4-8

ELBOW,QUICK MALE,1/4X1/8

AAQME-5-10

ELBOW,QUICK MALE 5/32X10-32

© 2004 Atlanta Attachment Company

AAQME-5-8

QUICK MALE ELBOW

AAQSU-4-4

UNION,QUICK STATION,1/4X1/4

AAQSU-5-5

UNION,QUICK STATION,5/32

AATP4-1

1/4" OD POLYURETHANE

AATP5/32

5/32" OD POLYURETHANE

EEFE-RR2

1" WIDE REFLECTIVE TAPE

EENC256

ENCODER,SBUS,256,1/4

FF270-1283

FUSE,1 AMP SLO BLOW

FFSE3WLC

EYE,SMARTEYE,MARK III

FFSM312LVQ

ELECTRIC EYE 10-30 VDC WITH 6" CORD AND PLUG

GG140XL037

BELT,GEAR,1/5P,3/8W,70 TEETH

M90513065

RING,SNAP,2.5

M90605010

SCREW,NEEDLE PLATE

M90906003

SCREW,9/64 (40) X 3.2

© 2004 Atlanta Attachment Company

M91129015

SCREW,11/64-40,PLKB -1006 MITSUBISHI

M96004052

WASHER,WAVE

MA10A0120

HOOK BASE, 6Z1260

MA10A0123

BOBBIN,LARGE CAPACITY



MA10B2476

SPACER

MA16E0210

THREAD TENSION ASSEMBLY

MB60A0470

PLATE,SLIDE

MM25CCF260

CHAIN,FLEX-E-PITCH,1/4 PITCH,65.0 LONG,KEVLAR CORE

MM4554K11

PLUG,1/8" PIPE

MM9753K35

CAP,VINYLTHREAD PROTECTION

MMGG41-15M

GEAR,SPUR,24 PITCH,15 TEETH

MS01A0329

THREAD GUIDE

MS01A0616

RETAINER,HOOK

MS01A1476

SPACER,NEEDLE PLATE

© 2004 Atlanta Attachment Company

MS03A1101

PLATE,NEEDLE, 6Z1740

MS03B0838

CUTTER,MOVABLE,6Z1590

MS14A0838

CUTTER,FIXED,6Z0960

MS17A0125

CASE,BOBBIN, 6Z0335

MV30A0256

FOOT,3MM DIA NEEDLE HOLE

SN135X1722

NEEDLE,SIZE 22

SSSCM3X10

SCREW,SOCKET CAP,M3 -0.5X10

ZX3848

V BELT,3/8 X 48"

ZZZSR-109

ACCRO LUBE GREASE 1.5 TUBES

CASH

CASH 300U103 SINGER

SINGER 300U103 FOR JAMES CASH TAPE EDGE MACHINES

20047C

FEED DOG

20119C

PLATE,NEEDLE

© 2004 Atlanta Attachment Company

267632C

FOOT,PRESSER,LIFTING

267659C

FOOT,PRESSER, VIBRATING

268638-C

SPREADER,J CASH

415045

FRAME,NEEDLE BAR ROCK

GALKIN

GAP 3301

FLANGE MACHINE

B364S

BELT,DRIVE,STEEL REINFRCD

C115-21507

HINGE,PRESSER FOOT

C115-28304

FEED DOG,MAIN (AUX ATTACHED)

C115-28502

FEED DOG,AUX

C115-65900

CUTTER,UPPER

C115-66502

CUTTER,LOWER

C118-90001

NEEDLE GUARD, TRAVELING

C118-90605

NEEDLE GUARD, OVEREDGE

© 2004 Atlanta Attachment Company

C120-14809

SPREADER

C121-21307

SPRING,THREAD GUIDE

C122-80608

NEELDE CLAMP (X2)

C123-77602

PLATE,LWR CUTTER PRESSER

C123-78808

NEEDLE HOLDER, OVEREDGE

C123-79004

NEEDLE HOLDER, CHAINSTITCH

C123-83501

LOOPER,UPPER

C123-84202

LOOPER,LOWER

C123-84400

410 LOOPER

C18040N

PLATE,NEEDLE

C18060

FEED DOG,DIFFERENTIAL

C3311

NEEDLE GUARD,FRONT

C3315

DEFLECTOR,SCRAP

C3335

FOOT,PRESSER,CHROME

© 2004 Atlanta Attachment Company

C3339

FEED DOG,CLAMP

CPT-251604

NEEDLE GUARD, CHAINSTITCH

GRIBETZ

QUILTING MACHINE

MULTI-NEEDLE CHAIN STITCH QUILTING MACHINE

P3-0146-N

LOOPER,NEW STYLE

P3-0146-O

LOOPER,OLD STYLE

P3-0178-1

LOOPER HOLDER

P3-0229DS

RETAINER,BLADE

P3-0229S

RETAINER,SPREADER

P3-0275

NEEDLE GUARD

P3-0462-7

BASE,AL SPLIT

P79037

BLADE,10" TEFLON SLITTER

Q-1720-29

BLADE,5-1/4" SLITTER

Q-1720-30

STONE,SHARPENING

© 2004 Atlanta Attachment Company

PORTER

BS401-300

MATTRESS & BOXSPRING MACHINE

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

610135

SCREW

610140

SCREW

610180

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

610420

SCREW

610520

SPRING

610560

SCREW,NEEDLE PLATE

© 2004 Atlanta Attachment Company

610600

WRENCH,ALLEN

610940

SCREW

610960

PIN,LINK

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

612240

COLLAR

612260

CONNECTION

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

© 2004 Atlanta Attachment Company

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

613200

REGULATOR

613340

GEAR,WORM

613360

WHEEL,WORM

613460

PIPE,OIL SPLASH, COMPLETE

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

613780

WASHER

613850

GUARD,FRONT NEEDLE, 6Z2154

© 2004 Atlanta Attachment Company

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

613920

BUSHING,NEEDLE BAR, 6Z1521

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

614300

WASHER

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

616220

GUIDE,LOOPER THREAD

616680

NUT

© 2004 Atlanta Attachment Company

616800

GASKET

617040

PIN,HINGE

617280

NEEDLE BAR, 6Z1673

617420

WICK,OIL

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618420

SCREW

618440

SCREW

618480

SCREW

© 2004 Atlanta Attachment Company

618520

SCREW

618540

SCREW

618640

SCREW

618660

SCREW,STOP

618720

SCREW

618740

SCREW,SPRING SEAT

618960

BOLT

618980

SCREW

619000

SCREW

619020

SCREW,HINGE PIN

619080

SCREW

619100

SCREW,PRESSER FOOT PIN

619120

SCREW

619140

SCREW,BUSHING

© 2004 Atlanta Attachment Company

619340

SCREW

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

619420

SCREW

619480

SCREW,PIN

619520

SCREW,LINK PIN

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

620047

GUARD,FRONT NEEDLE, 6Z1047

620144

CONNECTOR,AUX LIFTER ARM, 6Z0209

© 2004 Atlanta Attachment Company

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630113

NEEDLE HOLDER,RIGHT, 6Z2255

630117

HOLDER,TOP FEED, 6Z3534

630118

LINK,CONNECTOR, 6Z0660

630155

PIN,ECCENTRIC, 6Z0784

640002

SCREW

640012

CLAMP,NEEDLE BAR, 6Z1642

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

640053

NUT

© 2004 Atlanta Attachment Company

640068

STAND,FIVE SPOOL THREAD

650002

SPRING,PRESSURE, 6Z2109

650009

PRESSER BAR ROLLER ASSY, 6Z2028

650011

FOOT,TOP FEED, 6Z3194

650012

STRIP,TOP FEED WEAR, 6Z2997

650013

CUSHION,TOP FEED WEAR, 6Z3354

650014

HOLDER,TOP FEED, 6Z3202

650019

ROLLER,LIFT ARM, 6Z1354

650020

ARM,AUXILLARY LIFTER, 6Z0211

650042

PRESSER FOOT ASSY,6Z2038

650075

PLATE,THROAT,1313, 6Z3144

650076

FEED DOG, 6Z0900

650080

PRESSER FOOT ASSY

670700-1-1/4

1-1/4' BINDER,5/16'MOUTH, 6Z0299

© 2004 Atlanta Attachment Company

670700-7/8

7/8' BINDER,5/16' MOUTH

PSM-130

NEEDLE,SIZE 21, 6Z2718

BS401-500

MATTRESS & BOXSPRING MACHINE

208526

ARM,PRESSER

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

610135

SCREW

610140

SCREW

610180

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

© 2004 Atlanta Attachment Company

610420

SCREW

610520

SPRING

610560

SCREW,NEEDLE PLATE

610600

WRENCH,ALLEN

610960

PIN,LINK

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

612240

COLLAR

612260

CONNECTION

© 2004 Atlanta Attachment Company

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

613200

REGULATOR

613340

GEAR,WORM

613360

WHEEL,WORM

613460

PIPE,OIL SPLASH, COMPLETE

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

© 2004 Atlanta Attachment Company

613780

WASHER

613850

GUARD,FRONT NEEDLE, 6Z2154

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

613920

BUSHING,NEEDLE BAR, 6Z1521

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

614300

WASHER

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

© 2004 Atlanta Attachment Company

616220

GUIDE,LOOPER THREAD

616680

NUT

616800

GASKET

617040

PIN,HINGE

617280

NEEDLE BAR, 6Z1673

617420

WICK,OIL

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618420

SCREW

© 2004 Atlanta Attachment Company

618440

SCREW

618480

SCREW

618520

SCREW

618540

SCREW

618640

SCREW

618660

SCREW,STOP

618720

SCREW

618740

SCREW,SPRING SEAT

618960

BOLT

618980

SCREW

619000

SCREW

619020

SCREW,HINGE PIN

619080

SCREW

619100

SCREW,PRESSER FOOT PIN

© 2004 Atlanta Attachment Company

619120

SCREW

619140

SCREW,BUSHING

619340

SCREW

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

619420

SCREW

619480

SCREW,PIN

619520

SCREW,LINK PIN

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

© 2004 Atlanta Attachment Company

620047

GUARD,FRONT NEEDLE, 6Z1047

620126

BLOCK,FRONT GUIDE, 6Z1042

620134

STUD,ECCENTRIC, 6Z0788

620135

LINK,BEAM CONNECTOR, 6Z0656

620150

PIN,LONG PIVOT, 6Z1407

620175

PIN,PIVOT,6Z1946

620177

LINK,TOP FEED CONNECTOR, 6Z3190

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630113

NEEDLE HOLDER,RIGHT, 6Z2255

630118

LINK,CONNECTOR, 6Z0660

630134

PRESSER BAR, 6Z2034

© 2004 Atlanta Attachment Company

630140

BEAM,BYPASS, 6Z0490

630142

BLOCK,REAR RETAINING, 6Z2227

630144

ARM,PRESSER FOOT, 6Z2036

630145

TOP FEED MAIN SECTION, 6Z3207

630152

ARM,AUX LIFTER, 6Z0214

630153

HIGH LIFT LINKGE ASSY,517, 6Z1183

630304

SPRING,PRESSURE, 6Z3358

630305

HOUSING,PRESSURE, 6Z1256

630307

BASE,PRESSURE SPRING, 6Z2103

640002

SCREW

640012

CLAMP,NEEDLE BAR, 6Z1642

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

© 2004 Atlanta Attachment Company

640053

NUT

640068

STAND,FIVE SPOOL THREAD

650012

STRIP,TOP FEED WEAR, 6Z2997

650013

CUSHION,TOP FEED WEAR, 6Z3354

650042

PRESSER FOOT ASSY,6Z2038

650057

EXTENSION,HEAVY DUTY

650058

FOOT,T.F. WALKING, 6Z2998

650075

PLATE,THROAT,1313, 6Z3144

650078

FEED DOG, 6Z3549

670700-7/8

7/8' BINDER,5/16' MOUTH

PSM-130

NEEDLE,SIZE 21, 6Z2718

PSM-160

NEEDLE,#23, 6Z0122

© 2004 Atlanta Attachment Company

BS401-600

MATTRESS & BOXSPRING MACHINE

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

610135

SCREW

610140

SCREW

610180

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

610420

SCREW

610520

SPRING

610560

SCREW,NEEDLE PLATE

© 2004 Atlanta Attachment Company

610600

WRENCH,ALLEN

610960

PIN,LINK

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

612240

COLLAR

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

© 2004 Atlanta Attachment Company

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

613200

REGULATOR

613340

GEAR,WORM

613360

WHEEL,WORM

613460

PIPE,OIL SPLASH, COMPLETE

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

613780

WASHER

613850

GUARD,FRONT NEEDLE, 6Z2154

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

© 2004 Atlanta Attachment Company

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

614300

WASHER

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

616220

GUIDE,LOOPER THREAD

616680

NUT

616800

GASKET

617040

PIN,HINGE

617280

NEEDLE BAR, 6Z1673

© 2004 Atlanta Attachment Company

617300

NEEDLE HOLDER, 6Z1720

617420

WICK,OIL

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618420

SCREW

618480

SCREW

618520

SCREW

618540

SCREW

618640

SCREW

© 2004 Atlanta Attachment Company

618660

SCREW,STOP

618720

SCREW

618740

SCREW,SPRING SEAT

618960

BOLT

618980

SCREW

619000

SCREW

619020

SCREW,HINGE PIN

619080

SCREW

619100

SCREW,PRESSER FOOT PIN

619120

SCREW

619140

SCREW,BUSHING

619340

SCREW

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

© 2004 Atlanta Attachment Company

619420

SCREW

619480

SCREW,PIN

619520

SCREW,LINK PIN

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

620047

GUARD,FRONT NEEDLE, 6Z1047

620134

STUD,ECCENTRIC, 6Z0788

620175

PIN,PIVOT,6Z1946

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

© 2004 Atlanta Attachment Company

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630118

LINK,CONNECTOR, 6Z0660

640002

SCREW

640012

CLAMP,NEEDLE BAR, 6Z1642

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

640053

NUT

640068

STAND,FIVE SPOOL THREAD

650012

STRIP,TOP FEED WEAR, 6Z2997

650013

CUSHION,TOP FEED WEAR, 6Z3354

650042

PRESSER FOOT ASSY,6Z2038

650056

BASE,PRESSER FOOT, 6Z2044

© 2004 Atlanta Attachment Company

650075

PLATE,THROAT,1313, 6Z3144

650076

FEED DOG, 6Z0900

670700-7/8

7/8' BINDER,5/16' MOUTH

CB100

CONTINENTAL MATTRESS & BOXSPRING MACHINE

610100

SCREW,FEED DOG

610140

SCREW

610560

SCREW,NEEDLE PLATE

613850

GUARD,FRONT NEEDLE, 6Z2154

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

617280

NEEDLE BAR, 6Z1673

617420

WICK,OIL

© 2004 Atlanta Attachment Company

618340

SCREW

619120

SCREW

619400

SCREW,NEEDLE SET

620047

GUARD,FRONT NEEDLE, 6Z1047

620195

SHIELD,OIL, 6Z1855

620270

LOOPER,CHAINSTITCH, 6Z1484

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

650002

SPRING,PRESSURE, 6Z2109

650011

FOOT,TOP FEED, 6Z3194

650012

STRIP,TOP FEED WEAR, 6Z2997

650013

CUSHION,TOP FEED WEAR, 6Z3354

650014

HOLDER,TOP FEED, 6Z3202

650075

PLATE,THROAT,1313, 6Z3144

© 2004 Atlanta Attachment Company

650076

FEED DOG, 6Z0900

670700-1-1/4

1-1/4' BINDER,5/16'MOUTH, 6Z0299

PSM-130

NEEDLE,SIZE 21, 6Z2718

GM100

SEMI-AUTOMATIC MITERING MACHINE

16X257#20

NEEDLE, 6Z0113

MF00A0834

CUTTER,MOVEABLE, 6Z1591

MF00A0838

CUTTER,FIXED, 6Z0958

PALS3000

AUTOMATIC LABEL SEWER

135X17-23

NEEDLE

135X17#23

NEEDLE, 6Z3431

© 2004 Atlanta Attachment Company

610100

SCREW,FEED DOG

MA10A0120

HOOK BASE, 6Z1260

MS03A1101

PLATE,NEEDLE, 6Z1740

MS03B0838

CUTTER,MOVABLE,6Z1590

MS14A0838

CUTTER,FIXED,6Z0960

MS17A0123

BOBBIN

MS17A0125

CASE,BOBBIN, 6Z0335

PALS-205

PLATES,CORNER W/PINS, 6Z0673

PALS-220

FOOT,PRESSER, 6Z2037

PALS4000

AUTOMATIC LABEL SEWER

135X17-23

NEEDLE

135X17#23

NEEDLE, 6Z3431

© 2004 Atlanta Attachment Company

610100

SCREW,FEED DOG

MA10A0120

HOOK BASE, 6Z1260

MS03A1101

PLATE,NEEDLE, 6Z1740

MS03B0838

CUTTER,MOVABLE,6Z1590

MS14A0838

CUTTER,FIXED,6Z0960

MS17A0123

BOBBIN

MS17A0125

CASE,BOBBIN, 6Z0335

PALS-205

PLATES,CORNER W/PINS, 6Z0673

PALS-220

FOOT,PRESSER, 6Z2037

PE504-DO-2

DOUBLE BORDER SERGER MACHINE

211726

PLATE,THROAT,LH, REPLACMNT 11961W17

212215

LOOPER

© 2004 Atlanta Attachment Company

610080

SCREW

610120

SCREW,FEED DOG

610140

SCREW

610560

SCREW,NEEDLE PLATE

611240

CUTTER,UPPER, 6Z0507

612420

LOOPER,OVEREDGE, 6Z2146

613185

NEEDLE BAR

613720

CUTTER,LOWER, 6Z0506

614045

PLATE,NEEDLE

618325

NUT,NEEDLE CLAMP

619400

SCREW,NEEDLE SET

619820

SCREW

620244

SPREADER, 6Z2869

620270

LOOPER,CHAINSTITCH, 6Z1484

© 2004 Atlanta Attachment Company

660296

CUTTER,UPPER, 6Z3282

660297

CUTTER,LOWER, 6Z1296

660462

LOOPER,CHAINSTITCH, 6Z1472

730141

CUTTER,LOWER

PSM-130

NEEDLE,SIZE 21, 6Z2718

PFM 1000

ALL PURPOSE HIGH SPEED MATTRESS PANEL FLANGE MACHINE

006360

CUTTER,UPPER SERRATED, 6Z6360

007175

FOOT,PRESSER, 6Z7175

202691

CUSHION,RUBBER

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

© 2004 Atlanta Attachment Company

610135

SCREW

610140

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

610420

SCREW

610520

SPRING

610560

SCREW,NEEDLE PLATE

610600

WRENCH,ALLEN

610760

GUIDE/SPRING

610960

PIN,LINK

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

© 2004 Atlanta Attachment Company

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

612240

COLLAR

612260

CONNECTION

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

© 2004 Atlanta Attachment Company

613060

PIN,UPPER CUTTER LEVER

613160

STUD,LOWER CUTTER CLAMP

613200

REGULATOR

613340

GEAR,WORM

613360

WHEEL,WORM

613460

PIPE,OIL SPLASH, COMPLETE

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

613780

WASHER

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

614000

LOOPER HOLDER, 6Z1331

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

© 2004 Atlanta Attachment Company

614200

GUARD,REAR NEEDLE

614220

GUARD,FRONT NEEDLE

614300

WASHER

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

616220

GUIDE,LOOPER THREAD

616680

NUT

616800

GASKET

617280

NEEDLE BAR, 6Z1673

617300

NEEDLE HOLDER, 6Z1720

© 2004 Atlanta Attachment Company

617420

WICK,OIL

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618380

SCREW

618420

SCREW

618440

SCREW

618480

SCREW

618520

SCREW

618540

SCREW

© 2004 Atlanta Attachment Company

618640

SCREW

618660

SCREW,STOP

618700

SCREW

618720

SCREW

618740

SCREW,SPRING SEAT

618920

SCREW,STOP

618960

BOLT

618980

SCREW

619080

SCREW

619120

SCREW

619140

SCREW,BUSHING

619240

SCREW

619320

NUT,CLAMP STUD

619340

SCREW

© 2004 Atlanta Attachment Company

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

619420

SCREW

619480

SCREW,PIN

619520

SCREW,LINK PIN

619600

SCREW

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

620134

STUD,ECCENTRIC, 6Z0788

620135

LINK,BEAM CONNECTOR, 6Z0656

© 2004 Atlanta Attachment Company

620150

PIN,LONG PIVOT, 6Z1407

620175

PIN,PIVOT,6Z1946

620177

LINK,TOP FEED CONNECTOR, 6Z3190

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

620238

LOOPER,OVEREDGE (REWORKED, 6Z1443

620244

SPREADER, 6Z2869

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630103

NEEDLE GUARD,INSIDE, 6Z1879

630104

NEEDLE GUARD,OUTSIDE, 6Z1266

630113

NEEDLE HOLDER,RIGHT, 6Z2255

630115

LINK,PIN CONNECTION, 6Z1908

630117

HOLDER,TOP FEED, 6Z3534

© 2004 Atlanta Attachment Company

630118

LINK,CONNECTOR, 6Z0660

630127

T NUT,UPPER CUTTER

630128

CUTTER,UPPER

630140

BEAM,BYPASS, 6Z0490

630144

ARM,PRESSER FOOT, 6Z2036

630145

TOP FEED MAIN SECTION, 6Z3207

630148

EXT,EDGE TRIM CUTTER, 6Z0793

630150

CUTTER,LOWER

630155

PIN,ECCENTRIC, 6Z0784

630304

SPRING,PRESSURE, 6Z3358

630305

HOUSING,PRESSURE, 6Z1256

630307

BASE,PRESSURE SPRING, 6Z2103

640002

SCREW

640012

CLAMP,NEEDLE BAR, 6Z1642

© 2004 Atlanta Attachment Company

640024

BUSHING,FRONT OIL SEAL

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

640053

NUT

640068

STAND,FIVE SPOOL THREAD

660001

PLATE,THROAT,3/4'

660002

PLATE,THROAT,1' MOD

660003

FEED DOG,LOWER FRONT

660004

FEED,LOWER FRONT,1'

660005

FEED DOG,MAIN,3/4'

660006

FEED DOG,LWR REAR,1', MOD

660007

FEED,TOP,3/4' MODEL

660008

FOOT,TOP FEED,1' MOD

© 2004 Atlanta Attachment Company

660009

PRESSER FOOT ASSY,3/4'

660016

BAR,PRESSER

660022

EXTENSION,3/4' & 1'

660024

BUSHING,LOWER,3/4' & 1'

660039

CHAINFINGER,NEEDLE PLATE, 6Z0526

660042

LINKAGE ASSY,1000

PFM 2002

FLANGE MACHINE

005284

EXTENSION,PRESSER FOOT, 6Z5284

005855

HOLDER,TOP FEED, 6Z5855

006360

CUTTER,UPPER SERRATED, 6Z6360

007175

FOOT,PRESSER, 6Z7175

202691

CUSHION,RUBBER

620150

PIN,LONG PIVOT, 6Z1407

© 2004 Atlanta Attachment Company

620195

SHIELD,OIL, 6Z1855

620244

SPREADER, 6Z2869

630128

CUTTER,UPPER

630155

PIN,ECCENTRIC, 6Z0784

660039

CHAINFINGER,NEEDLE PLATE, 6Z0526

660055

PIN,PIVOT,LONG

660070

GUARD,REAR NEEDLE

660071

GUARD,FRONT NEEDLE

660520

GUARD,FRONT NEEDLE

730125

NEEDLE HOLDER

730132

SPREADER

730180

LOOPER,OVEREDGE

800867

CUTTER,LOWER

800959

EXTENSION

© 2004 Atlanta Attachment Company

800962

FEED,LOWER REAR MAIN

800978

PLATE,FRONT ADAPTOR

801366

PLATE,THROAT,2002

801446

NEEDLE GUARD,REAR

801457

FEED DOG,DIFFERENTIAL

801458

LOOPER,CHAINSTITCH

801758

NEEDLE HOLDER,RIGHT

802381

BEAM,TOP FEED

802579

EXTENSION

802697

ARM,PRESSER FOOT,2002

802773

TOP FEED

802794

BEAM,TOP FEED,2002

© 2004 Atlanta Attachment Company

PFM515

FLANGE MACHINE

202691

CUSHION,RUBBER

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

610135

SCREW

610140

SCREW

610180

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

610420

SCREW

610480

WASHER

© 2004 Atlanta Attachment Company

610520

SPRING

610560

SCREW,NEEDLE PLATE

610600

WRENCH,ALLEN

610760

GUIDE/SPRING

610940

SCREW

610960

PIN,LINK

611240

CUTTER,UPPER, 6Z0507

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

© 2004 Atlanta Attachment Company

612240

COLLAR

612260

CONNECTION

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

613060

PIN,UPPER CUTTER LEVER

613140

CUTTER,LOWER STEEL, 6Z2931

613160

STUD,LOWER CUTTER CLAMP

613200

REGULATOR

© 2004 Atlanta Attachment Company

613360

WHEEL,WORM

613460

PIPE,OIL SPLASH, COMPLETE

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

613720

CUTTER,LOWER, 6Z0506

613780

WASHER

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

613920

BUSHING,NEEDLE BAR, 6Z1521

614000

LOOPER HOLDER, 6Z1331

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

614200

GUARD,REAR NEEDLE

614220

GUARD,FRONT NEEDLE

© 2004 Atlanta Attachment Company

614300

WASHER

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

616220

GUIDE,LOOPER THREAD

616240

COVER,FRONT LEFT

616680

NUT

616800

GASKET

617040

PIN,HINGE

617280

NEEDLE BAR, 6Z1673

617300

NEEDLE HOLDER, 6Z1720

© 2004 Atlanta Attachment Company

617420

WICK,OIL

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618380

SCREW

618420

SCREW

618440

SCREW

618480

SCREW

618520

SCREW

618540

SCREW

© 2004 Atlanta Attachment Company

618640

SCREW

618660

SCREW,STOP

618700

SCREW

618720

SCREW

618740

SCREW,SPRING SEAT

618920

SCREW,STOP

618960

BOLT

618980

SCREW

619000

SCREW

619020

SCREW,HINGE PIN

619080

SCREW

619100

SCREW,PRESSER FOOT PIN

619120

SCREW

619140

SCREW,BUSHING

© 2004 Atlanta Attachment Company

619320

NUT,CLAMP STUD

619340

SCREW

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

619420

SCREW

619480

SCREW,PIN

619520

SCREW,LINK PIN

619600

SCREW

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

© 2004 Atlanta Attachment Company

620126

BLOCK,FRONT GUIDE, 6Z1042

620134

STUD,ECCENTRIC, 6Z0788

620135

LINK,BEAM CONNECTOR, 6Z0656

620144

CONNECTOR,AUX LIFTER ARM, 6Z0209

620150

PIN,LONG PIVOT, 6Z1407

620175

PIN,PIVOT,6Z1946

620177

LINK,TOP FEED CONNECTOR, 6Z3190

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

620238

LOOPER,OVEREDGE (REWORKED, 6Z1443

620244

SPREADER, 6Z2869

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630103

NEEDLE GUARD,INSIDE, 6Z1879

© 2004 Atlanta Attachment Company

630104

NEEDLE GUARD,OUTSIDE, 6Z1266

630113

NEEDLE HOLDER,RIGHT, 6Z2255

630115

LINK,PIN CONNECTION, 6Z1908

630117

HOLDER,TOP FEED, 6Z3534

630118

LINK,CONNECTOR, 6Z0660

630120

PLATE,THROAT, UNIVERSAL, 6Z3254

630122

FEED DOG,REAR, 6Z2149

630125

FEED,LOWER FRONT, 6Z1496

630142

BLOCK,REAR RETAINING, 6Z2227

630148

EXT,EDGE TRIM CUTTER, 6Z0793

630155

PIN,ECCENTRIC, 6Z0784

630307

BASE,PRESSURE SPRING, 6Z2103

640002

SCREW

640012

CLAMP,NEEDLE BAR, 6Z1642

© 2004 Atlanta Attachment Company

640024

BUSHING,FRONT OIL SEAL

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

640053

NUT

640068

STAND,FIVE SPOOL THREAD

650002

SPRING,PRESSURE, 6Z2109

650009

PRESSER BAR ROLLER ASSY, 6Z2028

650010

TOP FEED MAIN SECTION

650011

FOOT,TOP FEED, 6Z3194

650012

STRIP,TOP FEED WEAR, 6Z2997

650013

CUSHION,TOP FEED WEAR, 6Z3354

650019

ROLLER,LIFT ARM, 6Z1354

650020

ARM,AUXILLARY LIFTER, 6Z0211

© 2004 Atlanta Attachment Company

650022

BAR,PRESSER

650025

BEAM

650027

BEAM

650028

EXTENSION

650029

FOOT,PRESSER, 6Z2083

650030

FOOT,TOP FEED WF FLANGE, 6Z2995

650031

ARM,LIFTER WF, 6X1370

650032

LINKAGE ASSY,516, 6Z1184

650042

PRESSER FOOT ASSY,6Z2038

660039

CHAINFINGER,NEEDLE PLATE, 6Z0526

PSM-130

NEEDLE,SIZE 21, 6Z2718

PSM-140

NEEDLE

© 2004 Atlanta Attachment Company

PFM516

FLANGE MACHINE

202691

CUSHION,RUBBER

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

610135

SCREW

610140

SCREW

610180

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

610420

SCREW

610480

WASHER

© 2004 Atlanta Attachment Company

610520

SPRING

610560

SCREW,NEEDLE PLATE

610600

WRENCH,ALLEN

610760

GUIDE/SPRING

610940

SCREW

610960

PIN,LINK

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

612240

COLLAR

© 2004 Atlanta Attachment Company

612260

CONNECTION

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

613060

PIN,UPPER CUTTER LEVER

613140

CUTTER,LOWER STEEL, 6Z2931

613160

STUD,LOWER CUTTER CLAMP

613200

REGULATOR

613360

WHEEL,WORM

© 2004 Atlanta Attachment Company

613460

PIPE,OIL SPLASH, COMPLETE

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

613720

CUTTER,LOWER, 6Z0506

613780

WASHER

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

613920

BUSHING,NEEDLE BAR, 6Z1521

614000

LOOPER HOLDER, 6Z1331

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

614200

GUARD,REAR NEEDLE

614220

GUARD,FRONT NEEDLE

614300

WASHER

© 2004 Atlanta Attachment Company

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

616220

GUIDE,LOOPER THREAD

616240

COVER,FRONT LEFT

616680

NUT

616800

GASKET

617040

PIN,HINGE

617280

NEEDLE BAR, 6Z1673

617300

NEEDLE HOLDER, 6Z1720

617420

WICK,OIL

© 2004 Atlanta Attachment Company

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618380

SCREW

618420

SCREW

618440

SCREW

618480

SCREW

618520

SCREW

618540

SCREW

618640

SCREW

© 2004 Atlanta Attachment Company

618660

SCREW,STOP

618700

SCREW

618720

SCREW

618740

SCREW,SPRING SEAT

618920

SCREW,STOP

618960

BOLT

618980

SCREW

619000

SCREW

619020

SCREW,HINGE PIN

619080

SCREW

619100

SCREW,PRESSER FOOT PIN

619120

SCREW

619140

SCREW,BUSHING

619320

NUT,CLAMP STUD

© 2004 Atlanta Attachment Company

619340

SCREW

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

619420

SCREW

619480

SCREW,PIN

619520

SCREW,LINK PIN

619600

SCREW

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

620126

BLOCK,FRONT GUIDE, 6Z1042

© 2004 Atlanta Attachment Company

620134

STUD,ECCENTRIC, 6Z0788

620135

LINK,BEAM CONNECTOR, 6Z0656

620144

CONNECTOR,AUX LIFTER ARM, 6Z0209

620150

PIN,LONG PIVOT, 6Z1407

620175

PIN,PIVOT,6Z1946

620177

LINK,TOP FEED CONNECTOR, 6Z3190

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

620238

LOOPER,OVEREDGE (REWORKED, 6Z1443

620244

SPREADER, 6Z2869

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630103

NEEDLE GUARD,INSIDE, 6Z1879

630104

NEEDLE GUARD,OUTSIDE, 6Z1266

© 2004 Atlanta Attachment Company

630113

NEEDLE HOLDER,RIGHT, 6Z2255

630115

LINK,PIN CONNECTION, 6Z1908

630117

HOLDER,TOP FEED, 6Z3534

630118

LINK,CONNECTOR, 6Z0660

630120

PLATE,THROAT, UNIVERSAL, 6Z3254

630122

FEED DOG,REAR, 6Z2149

630125

FEED,LOWER FRONT, 6Z1496

630142

BLOCK,REAR RETAINING, 6Z2227

630148

EXT,EDGE TRIM CUTTER, 6Z0793

630153

HIGH LIFT LINKGE ASSY,517, 6Z1183

630155

PIN,ECCENTRIC, 6Z0784

630307

BASE,PRESSURE SPRING, 6Z2103

640002

SCREW

640012

CLAMP,NEEDLE BAR, 6Z1642

© 2004 Atlanta Attachment Company

640024

BUSHING,FRONT OIL SEAL

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

640053

NUT

640068

STAND,FIVE SPOOL THREAD

650002

SPRING,PRESSURE, 6Z2109

650009

PRESSER BAR ROLLER ASSY, 6Z2028

650010

TOP FEED MAIN SECTION

650011

FOOT,TOP FEED, 6Z3194

650012

STRIP,TOP FEED WEAR, 6Z2997

650013

CUSHION,TOP FEED WEAR, 6Z3354

650019

ROLLER,LIFT ARM, 6Z1354

650020

ARM,AUXILLARY LIFTER, 6Z0211

© 2004 Atlanta Attachment Company

650022

BAR,PRESSER

650025

BEAM

650027

BEAM

650028

EXTENSION

650029

FOOT,PRESSER, 6Z2083

650030

FOOT,TOP FEED WF FLANGE, 6Z2995

650031

ARM,LIFTER WF, 6X1370

650032

LINKAGE ASSY,516, 6Z1184

650042

PRESSER FOOT ASSY,6Z2038

660039

CHAINFINGER,NEEDLE PLATE, 6Z0526

PSM-130

NEEDLE,SIZE 21, 6Z2718

PSM-140

NEEDLE

© 2004 Atlanta Attachment Company

PFM517

FLANGE MACHINE

006360

CUTTER,UPPER SERRATED, 6Z6360

202691

CUSHION,RUBBER

610060

SCREW,NEEDLE CLAMP

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

610135

SCREW

610140

SCREW

610180

SCREW

610200

SCREW

610300

TWEEZER

610400

WASHER,HINGE SCREW

610420

SCREW

© 2004 Atlanta Attachment Company

610520

SPRING

610560

SCREW,NEEDLE PLATE

610600

WRENCH,ALLEN

610760

GUIDE/SPRING

610960

PIN,LINK

611240

CUTTER,UPPER, 6Z0507

611520

SCREW,OIL SPLASH

611600

WICK,OIL

611620

SCREW

611720

GUIDE

611740

RING,RETAINING

611860

SPRING,LOCK

611920

GUIDE

612240

COLLAR

© 2004 Atlanta Attachment Company

612260

CONNECTION

612300

SEAL,FRONT BUSHING OIL

612480

BEARING,NEEDLE

612520

LEVER,LOOPER HOLDER, 6Z1433

612540

TAKE-UP,LOOPER THREAD

612560

GUARD,THREAD, 6Z1134

612580

BRKT,LOOPER THREAD GUIDE

612620

CONNECTION,FEED DRIVE

612820

LINK,DIFF FEED REGULATING

613060

PIN,UPPER CUTTER LEVER

613160

STUD,LOWER CUTTER CLAMP

613200

REGULATOR

613360

WHEEL,WORM

613460

PIPE,OIL SPLASH, COMPLETE

© 2004 Atlanta Attachment Company

613640

WASHER,CLAMP SCREW

613700

EYELET,TAKE-UP

613780

WASHER

613880

PUMP,GEAR,COMPLETE

613900

BUSHING,NEEDLE BAR, 6Z3298

613920

BUSHING,NEEDLE BAR, 6Z1521

614000

LOOPER HOLDER, 6Z1331

614040

BRKT,NEEDLE GUARD, 6Z2222

614060

THREAD GUIDE

614200

GUARD,REAR NEEDLE

614220

GUARD,FRONT NEEDLE

614300

WASHER

614760

PIN,FEED DRIVE CONNECTION

615160

GUARD,FEED BAR OIL SPLASH

© 2004 Atlanta Attachment Company

615180

PLATE,INSERT

615200

GASKET

615560

CRANK, 6Z0702

615980

GASKET

616220

GUIDE,LOOPER THREAD

616680

NUT

616800

GASKET

617280

NEEDLE BAR, 6Z1673

617300

NEEDLE HOLDER, 6Z1720

617420

WICK,OIL

617440

SCREW,BUSHING

617540

SCREW,THRUST WASHER

618120

SCREW,SPACER

618220

SCREW,REGULATOR

© 2004 Atlanta Attachment Company

618280

NUT

618300

NUT,LOOPER THREAD TENSION

618340

SCREW

618380

SCREW

618420

SCREW

618440

SCREW

618480

SCREW

618520

SCREW

618540

SCREW

618640

SCREW

618660

SCREW,STOP

618700

SCREW

618720

SCREW

618740

SCREW,SPRING SEAT

© 2004 Atlanta Attachment Company

618920

SCREW,STOP

618960

BOLT

618980

SCREW

619000

SCREW

619080

SCREW

619120

SCREW

619140

SCREW,BUSHING

619320

NUT,CLAMP STUD

619340

SCREW

619360

SCREW,CLAMP

619400

SCREW,NEEDLE SET

619420

SCREW

619440

SCREW,NEELDE PLATE, OLD ST

619480

SCREW,PIN

© 2004 Atlanta Attachment Company

619520

SCREW,LINK PIN

619600

SCREW

619640

SCREW

619700

SCREW,CLAMP

619720

SCREW

620028

BEARING,NEEDLE

620033

SCREW,SET

620042

ECCENTRIC,FEED REGULATING

620126

BLOCK,FRONT GUIDE, 6Z1042

620134

STUD,ECCENTRIC, 6Z0788

620135

LINK,BEAM CONNECTOR, 6Z0656

620144

CONNECTOR,AUX LIFTER ARM, 6Z0209

620150

PIN,LONG PIVOT, 6Z1407

620175

PIN,PIVOT,6Z1946

© 2004 Atlanta Attachment Company

620177

LINK,TOP FEED CONNECTOR, 6Z3190

620195

SHIELD,OIL, 6Z1855

620217

LINK,STITCH, 6Z2937

620238

LOOPER,OVEREDGE (REWORKED, 6Z1443

620244

SPREADER, 6Z2869

620270

LOOPER,CHAINSTITCH, 6Z1484

629860

SCREW,GUIDE

630103

NEEDLE GUARD,INSIDE, 6Z1879

630104

NEEDLE GUARD,OUTSIDE, 6Z1266

630113

NEEDLE HOLDER,RIGHT, 6Z2255

630115

LINK,PIN CONNECTION, 6Z1908

630117

HOLDER,TOP FEED, 6Z3534

630118

LINK,CONNECTOR, 6Z0660

630120

PLATE,THROAT, UNIVERSAL, 6Z3254

© 2004 Atlanta Attachment Company

630122

FEED DOG,REAR, 6Z2149

630123

FOOT,HD TOP FEED

630125

FEED,LOWER FRONT, 6Z1496

630127

T NUT,UPPER CUTTER

630128

CUTTER,UPPER

630138

PIN,PIVOT,CONN LINK

630140

BEAM,BYPASS, 6Z0490

630142

BLOCK,REAR RETAINING, 6Z2227

630144

ARM,PRESSER FOOT, 6Z2036

630145

TOP FEED MAIN SECTION, 6Z3207

630148

EXT,EDGE TRIM CUTTER, 6Z0793

630149

EXTENSION,HD,517

630150

CUTTER,LOWER

630151

FOOT,LEFT PRESSER

© 2004 Atlanta Attachment Company

630152

ARM,AUX LIFTER, 6Z0214

630155

PIN,ECCENTRIC, 6Z0784

630157

PRESSER FOOT BASE ASSY

630304

SPRING,PRESSURE, 6Z3358

630305

HOUSING,PRESSURE, 6Z1256

630307

BASE,PRESSURE SPRING, 6Z2103

640002

SCREW

640011

CHAINFINGER,NEEDLE PLATE

640012

CLAMP,NEEDLE BAR, 6Z1642

640024

BUSHING,FRONT OIL SEAL

640037

CLAMP,FILTER

640038

FILTER,OUTSIDE

640039

FILTER,INSIDE

640053

NUT

© 2004 Atlanta Attachment Company

640068

STAND,FIVE SPOOL THREAD

660039

CHAINFINGER,NEEDLE PLATE, 6Z0526

PSM-130

NEEDLE,SIZE 21, 6Z2718

PSM-160

NEEDLE,#23, 6Z0122

PLS10730

LONG ARM LABEL SEWER

135X17#21

NEEDLE

135X17#22

NEEDLE

210530

BOBBIN

210533

HOOK BASE,KOBAN

210764

FINGER,BOBBIN CASE

210884

NEEDLE BAR

224441

CABE,BOBBIN,TOWA

© 2004 Atlanta Attachment Company

PNR / PRTE

TAPE EDGE CLOSING MACHINE

268382

300W LOOPER

415045

FRAME,NEEDLE BAR ROCK

802678

FEED DOG (REPLACES

91-059-493-05

FEED DOG

91-149-219-91

FOOT,PRESSER,LIFTING

91-149-220-91

FOOT,PRESSER, VIBRATING

91-150-809-05

PLATE,NEEDLE

91-177-868-91

LOOPER W/NEEDLE GUARD

91-178-339-91

SPREADER

91-266-545-91

NEEDLE BAR

91-266-783-91

FRAME,ROCKER,NEEDLE BAR

PNR-413

FOOT,TOP FEED

© 2004 Atlanta Attachment Company

PNR-421

FEED DOG,OLD STYLE

PNR-433

FOOT,VIBRATING PRESSER

PNR-470

NEEDLE

PNR-470A

NEEDLE

PNR-482

NEEDLE BAR

PRTE-510

PLATE,THROAT

PRTE-516

SPREADER (REWORKED)

POQ30

REPAIR QUILT MACHINE

135X17#21

NEEDLE

135X17#22

NEEDLE

610120

SCREW,FEED DOG

720126

BASE,HOOK

© 2004 Atlanta Attachment Company

720127

CASE,BOBBIN,TOWA

720131

FINGER,BOBBIN CASE

720139

BOBBIN

PSB700

BLINDSTITCH MACHINE

2200

LOOPER

2201

LOOPER

700590

FEED DOG,PBS700

701270

NEEDLE GUARD

701330

FOOT,PRESSER

BSP-05

U-JOINT,FIXED

© 2004 Atlanta Attachment Company

PTS515-SS

GUSSETT MACHINE FOR PILLOW TOP SYSTEM

610100

SCREW,FEED DOG

610120

SCREW,FEED DOG

611240

CUTTER,UPPER, 6Z0507

612420

LOOPER,OVEREDGE, 6Z2146

613720

CUTTER,LOWER, 6Z0506

613850

GUARD,FRONT NEEDLE, 6Z2154

618340

SCREW

619120

SCREW

619400

SCREW,NEEDLE SET

620047

GUARD,FRONT NEEDLE, 6Z1047

620244

SPREADER, 6Z2869

620270

LOOPER,CHAINSTITCH, 6Z1484

© 2004 Atlanta Attachment Company

660261

PLATE,NEEDLE

PSM-130

NEEDLE,SIZE 21, 6Z2718

© 2004 Atlanta Attachment Company

Is Your Sewing Equipment Down Because You Need Replacement Parts?

Contact Atlanta Parts Depot and Test Our *SuddenService*® Guarantee

72 Hours or FREE!*

We also stock replacement parts for many competitors' machines.

* As the leading supplier of automated sewing workstations, we are proud to offer this 72 hours or FREE policy. AAC pledges unequaled service and support to our valued customers. We pledge to maintain inventories of the recommended spare parts for our automated workstations and to ship those replacement parts within 72 hours. If the expendable replacement parts are not shipped within 72 hours they will be... **Free of Charge!**

Contact sales for the recommended spare parts list and the model workstations covered.

www.atlantapartsdepot.com • sales@atlantapartsdepot.com

Atlanta Parts Depot is a division of Atlanta Attachment Company®

© 2009 Atlanta Attachment Company. All rights reserved. 09082082809

Atlanta Parts Depot™
362 Industrial Park Drive
Lawrenceville, GA 30046
1-866-885-5100