

Circular Collar Guiding Attachment

- Easy to adjust
- Unlimited neck sizes
- Consistent edge guide
- Low cost
- Available for all cylinder arm machines


OPERATION

The operator loads the collar onto the rollers which are adjustable for size. After the collar is loaded the shirt is positioned over the collar and sewing cycle begins. The operator may stop to add a label. This device ensures that the collar stretch is evenly distributed around the neck of the shirt. Quality and production is greatly increased.

OPTIONS

- Label holder
- Stationary or pneumatic models
- Label pick-up pneumatic model

Images may include options.



SPECIFICATIONS

Voltage (v/ph/hz)	220v 1ph
Current (amps)	3
Air pressure (psi)	90
Air consumption (cfm)	2

www.atlatt.com • sales@atlatt.com

PATENTS: Our equipment may be covered by one or more patents. Please go to the following web page for an up-to-date patent list: www.atlatt.com/patents.php
© 2018 Atlanta Attachment Co. 17168042718

362 Industrial Park Drive
Lawrenceville, GA 30046 USA
+1 (770) 963-7369 • FAX +1 (770) 963-7641



Atlanta Attachment Company

The Company that
Sudden Service
built